



Relay code
1 = +24V 0 = 0V

Filter	FIL SEL ₀	FIL SEL ₁	FIL SEL ₂	FIL SEL ₃
1	0	1	0	0
2	1	1	1	0
3	1	0	0	0
5	1	1	0	0
6	0	1	1	0
8	0	0	0	0
MF	0	1	0	1

Components inside this area are only mounted when used for 628.