

BIAS control settings and voltage selected

BIAS	Volts	BIAS	Volts	BIAS	Volts	BIAS	Volts	BIAS	Volts
1	-0.0	21	-2.9	41	-9.4	61	-18.5	81	-29.2
2	-0.1	22	-3.1	42	-9.8	62	-19.0	82	-29.8
3	-0.1	23	-3.4	43	-10.2	63	-19.5	83	-30.4
4	-0.2	24	-3.7	44	-10.6	64	-20.1	84	-30.9
5	-0.3	25	-3.9	45	-11.1	65	-20.6	85	-31.5
6	-0.4	26	-4.2	46	-11.5	66	-21.6	86	-32.1
7	-0.5	27	-4.5	47	-11.9	67	-21.6	87	-32.6
8	-0.6	28	-4.8	48	-12.4	68	-22.2	88	-33.2
9	-0.7	29	-5.1	49	-12.8	69	-22.7	89	-33.7
10	-0.8	30	-5.4	50	-13.3	70	-23.2	90	-34.3
11	-0.9	31	-5.8	51	-13.7	71	-23.8	91	-34.9
12	-1.1	32	-6.1	52	-14.2	72	-24.3	92	-35.4
13	-1.3	33	-6.4	53	-14.6	73	-24.8	93	-36.0
14	-1.4	34	-6.8	54	-15.1	74	-25.4	94	-36.6
15	-1.6	35	-7.1	55	-15.6	75	-25.9	95	-37.1
16	-1.8	36	-7.5	56	-16.1	76	-26.5	96	-37.7
17	-2.0	37	-7.9	57	-16.5	77	-27.0	97	-38.3
18	-2.2	38	-8.2	58	-17.0	78	-27.6	98	-38.8
19	-2.4	39	-8.6	59	-17.5	79	-28.1	99	-39.4
20	-2.7	40	-9.0	60	-18.0	80	-28.7	100	-40.0

FILAMENT switch (left)
 FILAMENT switch (right)
 Pin selected in tube socket

A	B	C	D	E	F	G	H	J	K
P	R	S	T	U	V	W	X	Y	Z
None	1	2	3	4	5	6	7	8	9