



DECODER TABLE	FUNCTION SELECT (TTY1 ONLY)	TTY SELECT
1 DECODER 1	1 MAGNET ONLY	1 TTY1 ONLY
2 DECODER 2	2 KEYBOARD ONLY	2 TTY2 ONLY
3 DECODER 3	3 TAPE READER ONLY	3 BOTH TTYs
4 DECODER 4	4 MAGNET & KEYBOARD	
5 DECODER 5	5 MAGNET & TAPE READER	
6 INTERNAL LOOP	6 MAGNET, KEYBOARD AND READER	

**5 decoders - TTY1 - KB1 - TAPE1 / TTY2 SWITCH  
with TTL normal/negated outputs  
and internal 40mA loop**

**TITLE:** CommRTTY4

**Document Number:** \_\_\_\_\_ **REV:** 4

**Date:** 14/01/22 17:16 **Sheet:** 1/1