

COMMUNICATIONS RECEIVER  
TYPE RA.17L

Operating and Maintenance Instructions

Technical Handbooks Department

©RACAL ENGINEERING LIMITED

Western Road,  
Bracknell, Berkshire  
England.

OM45-4-61-1000

PRINTED IN ENGLAND



THE RACAL COMMUNICATIONS RECEIVER  
TYPE R.A.17

# LIST OF CONTENTS

Front view of Receiver Type RA.17

## PART 1

### TECHNICAL DETAILS AND OPERATION

- SECTION 1 Introduction
- SECTION 2 Installation
- SECTION 3 Operation
- SECTION 4 Brief Technical Description
- SECTION 5 Detailed Circuit Description

## PART 2

### MAINTENANCE

- SECTION 1 Spurious Responses
- SECTION 2 Valve Data
- SECTION 3 Fault Location
- SECTION 4 Representative Test Data
- SECTION 5 Alignment Procedures
- SECTION 6 Dismantling and Replacement Procedures
- SECTION 7 Illustrations
- SECTION 8 List of Circuit Components

**PART 1**  
**TECHNICAL DETAILS**  
**AND**  
**OPERATION**

# PART 1

## TECHNICAL DETAILS AND OPERATION

### INDEX

	<i>Page</i>	
SECTION 1	INTRODUCTION . . . . .	9
1.1	General Description . . . . .	9
1.2	North American Version . . . . .	9
1.3	Constructional Details . . . . .	9
1.4	Technical Specification . . . . .	9
SECTION 2	INSTALLATION :—	
2.1	Supply . . . . .	11
2.2	Fuses . . . . .	11
2.3	Aerial . . . . .	11
2.4	Audio Outputs . . . . .	11
2.5	100 KC/S I.F. Output . . . . .	11
2.6	Automatic Volume Control . . . . .	11
SECTION 3	OPERATION :—	
3.1	Function of Controls . . . . .	13
3.2	Preliminary Setting-Up . . . . .	14
3.3	Film Scale Calibration . . . . .	14
3.4	B.F.O. Calibration . . . . .	14
3.5	Tuning . . . . .	14
3.6	" S " Meter . . . . .	14
SECTION 4	BRIEF TECHNICAL DESCRIPTION :—	
4.1	Signal Input . . . . .	15
4.2	First Mixer . . . . .	15
4.3	Harmonic Generator and Mixer . . . . .	15
4.4	Second Mixer . . . . .	15
4.5	Third Mixer . . . . .	15
4.6	Third I.F. Stage . . . . .	15
4.7	A.F. Stages . . . . .	15
4.8	Crystal Calibrator . . . . .	15
SECTION 5	DETAILED CIRCUIT DESCRIPTION :—	
5.1	Aerial Circuit . . . . .	19
5.2	R.F. Amplifier . . . . .	19
5.3	30 Mc/s Low-Pass Filter . . . . .	19
5.4	First Variable Frequency Oscillator . . . . .	19
5.5	First Mixer . . . . .	19
5.6	40 Mc/s Band-Pass Filter . . . . .	19
5.7	1 Mc/s Crystal Oscillator . . . . .	19
5.8	Harmonic Generator . . . . .	20
5.9	32 Mc/s Low-Pass Filter . . . . .	20
5.10	Harmonic Mixer . . . . .	20
5.11	2-Stage 37.5 Mc/s Amplifier (1) . . . . .	20
5.12	37.5 Mc/s Band-Pass Filter . . . . .	20
5.13	37.5 Mc/s Amplifier (2) . . . . .	20
5.14	Second Mixer . . . . .	21
5.15	2-3 Mc/s Tuned Band-Pass Filter . . . . .	21
5.16	Third Mixer . . . . .	21
5.17	Second Variable Frequency Oscillator . . . . .	21
5.18	Crystal Filter . . . . .	21
5.19	100 kc/s L-C Filter . . . . .	21
5.20	First 100 kc/s I.F. Amplifier . . . . .	22
5.21	Second 100 kc/s I.F. Amplifier . . . . .	22
5.22	Diode Detector . . . . .	22
5.23	Noise Limiter . . . . .	22
5.24	A.V.C. and T.C. Diode . . . . .	23
5.25	Audio Output . . . . .	23
5.26	A.F. Line Output . . . . .	23
5.27	Beat Frequency Oscillator . . . . .	23
5.28	100 kc/s I.F. Output . . . . .	23
5.29	Crystal Calibrator . . . . .	24
5.30	Power Supplies . . . . .	24
5.31	System Switch . . . . .	24
5.32	" S " Meter . . . . .	24

# SECTION 1

## INTRODUCTION

### 1.1 GENERAL DESCRIPTION

The Communications Receiver Type RA.17 has been designed for use as a general purpose receiver which will provide a high order of sensitivity, selectivity and stability. The receiver covers a frequency range from 1.0 to 30.0 Mc/s and extending, with slightly degraded performance, down to 500 kc/s.

A built-in crystal-controlled calibrator provides reference signals at each 100 kc/s division to permit exact alignment of the scale pointer. Two independent i.f. outputs, in parallel, at 100 kc/s are provided for external use if required. A number of audio outputs are available providing flexibility during operation; a small loudspeaker is fitted for monitoring purposes.

The receiver is designed to operate from 100–125 volts and 200–250 volts, 45–65 c/s mains supply. The power consumption is approximately 100 watts.

### 1.2 NORTH AMERICAN VERSION

North American versions of the RA.17 receiver are identical to the Standard model but include minor variations in detail to comply with North American practice. Certain tubes are changed to ensure that the set employs types commercially available in North America; this entails slight circuit changes to allow for differences in the tube operating voltages. The level meter circuits are modified to include a calibrated "S" meter range. The a.f. output stage is modified to give a maximum output of 1 watt. Coaxial connections are changed from British to North American standards and the supply connection comprises a lead directly connected to the set in place of the fixed plug and free socket fitted to the British version.

These instructions cover both types of receiver. Where applicable, attention is drawn to the differences between the two versions.

### 1.3 CONSTRUCTIONAL DETAILS

The receiver is designed for both bench (table) and rack mounting. The front panel is painted Light Battleship Grey (British Standard Specification 381C, colour 697) and has been carefully designed to minimise operator fatigue.

The dimensions of the  $\frac{1}{8}$ -in. thick front panel conform with the requirements for mounting in a standard 19-in. rack.

For bench mounting, the receiver is fitted in a robust steel cabinet which has a rear opening to enable the operator to gain easy access to the power input socket (Standard version only), the fuses and the termination strips.

A dust cover is provided with both models. This may be removed from cabinet-mounted receivers in conditions of high ambient temperature.

The chassis and major modules are of cast construction thus ensuring maximum rigidity and effective electrical screening.

Each receiver is supplied with three keys to facilitate removal of the control knobs, a plastic trimming tool and free coaxial terminations for aerial and i.f. connections. Extra sleeves are provided with the terminations for alternative coaxial cable sizes.

### 1.4 TECHNICAL SPECIFICATION

Frequency Range	1–30 Mc/s. Range extends to 0.5 Mc/s with slight degradation of performance.
Stability	The average receiver, after warm-up time of 1 to 2 hours, will remain tuned to within 50 c/s of the selected frequency under conditions of constant supply voltage and ambient temperature.
Input Impedance	75 $\Omega$ unbalanced.
Tuning	Effective scale length of approximately 145 feet, i.e. about 6 inches of scale length corresponds to 100 kc/s. Frequency increments remain substantially constant over the entire range.
Calibration	A 100 kc/s signal derived from a 1 Mc/s crystal oscillator having an accuracy of 5 parts in 10 <sup>6</sup> provides check points at 100 kc/s intervals.
Sensitivity	A1 reception, bandwidth 3 kc/s: 1 $\mu$ V for 18dB signal-to-noise ratio. A2 reception, 30% modulated, bandwidth 3 kc/s: 3 $\mu$ V for 18dB signal-to-noise ratio.
Intermodulation	More than 100dB down for interfering signals at least 10% removed from the wanted signal.

<b>Cross Modulation</b>	For wanted signal levels between $3\mu\text{V}$ and $1\text{mV}$ , an interfering signal $10\text{ kc/s}$ removed and modulated $30\%$ must have a level greater than $50\text{dB}$ above that of the wanted signal to produce a cross modulation of $3\%$ . The ratio of wanted to unwanted signal is improved, up to $10\%$ off tune, at the rate of $3\text{dB}$ per cent.		
<b>Blocking</b>	With similar conditions to those for cross modulation, an unwanted signal $f_2$ must be $60\text{dB}$ greater before the audio output of the wanted signal $f_1$ is reduced by $3\text{dB}$ due to blocking.		
<b>Selectivity</b>	Six alternative i.f. bandwidths are obtained by means of a selector switch. Filter details are:		
		-6dB	-66dB
	1.	13 kc/s	28 kc/s
	2.	6.5 kc/s	20 kc/s
	3.	3.0 kc/s	15 kc/s
	4.	1.2 kc/s	8 kc/s
	5.	0.3 kc/s	Less than 2 kc/s
	6.	0.10 kc/s	Less than 1.5 kc/s
	Bandwidths 5 and 6 are obtained with crystal-lattice filters; differences in centre frequencies of these bandwidth settings do not exceed $50\text{ c/s}$ .		
<b>I.F. Output</b>	$100\text{ kc/s}$ at $75\Omega$ impedance. Level $0.2\text{V}$ approx. with a.v.c. in operation. Two outlets in parallel are provided.		
<b>Image and Spurious Responses</b>	With wideband or tuned input, external image signals are at least $60\text{dB}$ down. Internally generated spurious responses are below noise level in all cases.		
<b>Noise Factor</b>	Better than $7\text{dB}$ throughout entire range.		
<b>B.F.O. Range</b>	$\pm 8\text{ kc/s}$ .		
<b>B.F.O. Stability</b>	With constant ambient temperature and supply voltage, drift after warm-up time of 1 to 2 hours does not exceed $50\text{ c/s}$ . For input level variations from $10\mu\text{V}$ to $1\text{mV}$ , b.f.o. drift is negligible.		
<b>Automatic Volume Control</b>	A.V.C. is applied to the r.f. and the final i.f. stages. An increase in signal level of $20\text{dB}$ above $1\mu\text{V}$ improves the signal-to-noise ratio by $18\text{dB}$ . An increase in signal level of $100\text{dB}$ above $1\mu\text{V}$ increases the a.f. output by less than $7\text{dB}$ .		
<b>A.V.C. Time Constants</b>	Short: Charge— $25$ milliseconds. Discharge— $200$ milliseconds. Long: Charge— $200$ milliseconds. Discharge— $1$ second.		
<b>A.F. Response</b>	With $13\text{ kc/s}$ bandwidth, response remains within $\pm 4\text{dB}$ from $250\text{ c/s}$ to $6000\text{ c/s}$ .		
<b>A.F. Output</b>	<ol style="list-style-type: none"> <li>1. <math>2\frac{1}{2}</math>-in. loudspeaker (<math>50\text{mW}</math>) (<math>1\text{W}</math>, North American version) on front panel (switched).</li> <li>2. Two headphone sockets in parallel on front panel. (See Note).</li> <li>3. Three independent outputs of <math>3\text{mW}</math> at <math>600\Omega</math> at rear of chassis.</li> <li>4. One output of <math>10\text{mW}</math> at <math>600\Omega</math>. Preset level is independent of A.F. GAIN control setting.</li> <li>5. One output of <math>50\text{mW}</math> (<math>1\text{W}</math>, North American version) at <math>3\Omega</math>.</li> </ol> <p>Note: The two headphone sockets are connected across the loudspeaker on the British version and across one of the <math>600\Omega</math>, <math>3\text{mW}</math> outlets on the North American version of the receiver.</p>		
<b>Distortion</b>	Not greater than $5\%$ at $50\text{mW}$ output. ( $1\text{W}$ , North American version)		
<b>Hum Level</b>	With A.F. GAIN control at maximum, the hum level is never worse than $40\text{dB}$ below rated output ( $50\text{mW}$ or $1\text{W}$ respectively).		
<b>Noise Limiter</b>	A series noise limiter circuit can be switched into operation to provide limiting at modulation levels exceeding $30\%$ .		
<b>Meter Indication</b>	Alternative switching for indication of signal carrier level or a.f. output level. An 'S' meter is incorporated in the North American version of the receiver.		
<b>Power Supply</b>	$100\text{--}125\text{V}$ and $200\text{--}250\text{V}$ , $45\text{--}65\text{ c/s}$ . Power consumption $100\text{W}$ approx.		
<b>Dimensions</b>	Height	Width	Depth
For rack mounting	$10\frac{1}{2}$	19	$20\frac{1}{8}$ in.
(fitted dust cover)	26.7	48.25	51 cm.
Fitted cabinet	12	$20\frac{1}{2}$	$21\frac{7}{8}$ in.
	30.5	52	55.6 cm.
<b>Weight</b>			
Rack mounted	67 lb. (30.5 kg).		
In cabinet	97 lb. (44 kg.)		

## SECTION 2

### INSTALLATION

After carefully unpacking the receiver, remove the dust cover and make sure that all valves and screening cans are firmly in place and that no packing material remains within the tuning mechanism.

#### 2.1 SUPPLY

Ascertain that the main transformer is set to the appropriate voltage tapping. This is carried out by means of the plug-in links in Standard models and by soldered connections to the transformer in the North American versions. Connect a 3-core power lead (not provided) to the free 3-pin socket supplied and attach this to the input power plug (PL10). On North American versions, a power cable is permanently fitted. Check that the terminals HT.1 and HT.2 situated on the main chassis are linked (unless the L.F. Converter is in use). Note that a form of receiver muting can be obtained by opening this link when the associated transmitter is keyed.

Connect the power lead to the mains supply.

#### 2.2 FUSES

Ensure that the rating of the supply fuse and the h.t. fuse is correct viz:

Supply fuse 2A.

H.T. fuse 350mA (North American version 250mA, anti surge).

#### 2.3 AERIAL

The impedance at the aerial (antenna) input plug is designed to match into a  $75\Omega$  unbalanced transmission line. The cable termination supplied with the receiver is provided with alternative sleeves to enable it to be used with a type UR.18 or UR.70 cable or similar cables of nominal  $\frac{1}{2}$ -in. or  $\frac{1}{4}$ -in. respectively.

#### 2.4 AUDIO OUTPUTS

(a) The two headphone sockets situated on the front panel are connected across the  $3\Omega$  speaker.

*Note:* On the North American receiver, the headphone sockets are connected across one of the  $600\Omega$  3mW. outlets.

(b) The following outputs are connected to the terminal strip situated on the rear of the receiver :—

(i) Three  $600\Omega$  outlets at 3mW.

(ii) One  $3\Omega$  outlet at 50mW (1W, North American version).

(iii) One  $600\Omega$  outlet at 10mW. This output is controlled by a pre-set A.F. LEVEL control on the front panel and is independent of the outputs previously described.

#### 2.5 100 KC/S I.F. OUTPUT

The connection consists of two coaxial plugs connected in parallel to the 100 kc/s output. The total load should not be less than  $70\Omega$  (e.g. with one outlet loaded by  $75\Omega$ , the other can be used as a high impedance source).

#### 2.6 AUTOMATIC VOLUME CONTROL

The a.v.c. line is brought out to the terminal strip on the rear of the chassis for such applications as diversity reception.



## SECTION 3

### OPERATION

References to the controls are in capitals and are in accordance with the panel titles adjacent to them. Control names on the North American versions are shown in brackets when they differ from the standard titles.

It should be noted that the method of operation of the receiver, which is extremely simple, depends largely upon the purpose for which the receiver is being employed. The instructions given below are concerned with tuning the receiver to a signal of known frequency; also, notes are included on the use of the various controls.

#### 3.1 FUNCTION OF CONTROLS

- MAINS (POWER)** Makes and breaks the power supply to the mains transformer.
- AE. (ANT.) RANGE MC/S** This control enables the selection of any one of six aerial ranges plus WIDEBAND position.
- AE. (ANT.) ATTENUATOR** This control enables the operator to reduce the level of all incoming signals when strong unwanted signals are present which cannot be rejected sufficiently by tuning the aerial; the input level can also be reduced if the required signal is causing overloading in the early stages of the receiver.
- MEGACYCLES** This scale should be checked periodically to ensure that its setting is reasonably central with respect to the band in use. This is indicated by a reduction of signal or noise on either side of the correct setting.
- SYSTEM** This switch provides facilities for STANDBY, MANUAL, A.V.C., CALIBRATION and CHECK B.F.O.
- BANDWIDTH** The two crystal filters determining the bandwidth are adjusted to ensure that their centre frequencies are all within 50 c/s, thus any bandwidth can be selected without retuning the receiver. Six bandwidths are provided as follows:  
13 kc/s, 6.5 kc/s, 3 kc/s and 1.2 kc/s (L-C); 300 c/s and 100 c/s (crystal).
- A.F. GAIN** The A.F. Gain control adjusts the audio output.
- KILOCYCLES** The calibration of this scale may be checked at 100 kc/s intervals by setting the system switch to the CAL position.
- B.F.O.** The B.F.O. ON/OFF switch makes or breaks h.t. to the beat frequency oscillator.
- B.F.O. NOTE KC/S** The b.f.o. is exactly tuned to a central point on the i.f. amplifier response when the B.F.O. NOTE KC/S control is set to zero-beat with the calibrator. Having standardized the b.f.o. frequency, the frequency of an incoming signal may be accurately measured by setting the KILOCYCLES control to a zero-beat position; the b.f.o. should be detuned in order to produce an acceptable note for c.w. reception.
- AE. (ANT.) TUNE** If maximum sensitivity is not required, the aerial need not be tuned unless strong unwanted signals are present. It should be noted that the presence of very strong signals anywhere within the spectrum may cause cross-modulation unless the aerial is tuned. Under these conditions, CARE MUST BE TAKEN TO AVOID TUNING THE INPUT TO THE INTERFERING SIGNALS instead of the signal required. Familiarity with the tuning controls will facilitate this.
- I.F. GAIN** The I.F. GAIN control is operative both in the MAN. and the A.V.C. positions of the System switch. In the MAN. position of the System switch, the setting of the control should always be at a minimum consistent with satisfactory a.f. level. The following should be noted when the System switch is in the A.V.C. position. Reducing the i.f. gain results in a reduction of a.v.c. loop gain together with a degraded a.v.c. characteristic. Therefore when in the A.V.C. position, it is desirable that the I.F. GAIN control be set to maximum. A possible exception of this occurs when receiving interrupted signals in which the carrier is periodically switched off; in this case, receiver noise could be troublesome during the quiet intervals.
- A.V.C.** The choice of time-constant depends largely on conditions. The LONG time-constant (1 second) should be employed with voice signals; the SHORT time-constant may be used with high speed telegraphy or signals. For slow speed telegraphy, the MAN. position of the System switch should be used (refer to I.F. GAIN).

<b>A.F. LEVEL</b>	The preset control sets the a.f. level in a separate a.f. stage for feeding a 600Ω 10mW line. It is unaffected by the position of the main A.F. GAIN control. IT IS MOST IMPORTANT that the A.F. LEVEL is not turned towards its maximum position unless the 10mW 600Ω winding is suitably terminated.
<b>LIMITER</b>	When switched into use, the LIMITER reduces the effects of noise peaks exceeding the level of a 30% modulated signal. It does not introduce noticeable distortion below a 30% modulation level.
<b>METER</b>	With the METER switch in the R.F. LEVEL position, the meter indicates the signal diode current. In the A.F. LEVEL position, the 10mW 600Ω output only is monitored. A calibration mark is provided at 10mW.
<b>SPEAKER</b>	The loudspeaker may be switched ON or OFF as required. The two telephone jack sockets remain in circuit in either position of the SPEAKER switch.

### 3.2 PRELIMINARY SETTING-UP

Switch on the supply by means of the MAINS (POWER) switch. Allow a few minutes for the receiver to warm up.

Set the AE. (ANT.) RANGE MC/S switch to WIDEBAND. Switch the AE. (ANT.) ATTENUATOR to MIN. Set the A.F. GAIN control to its mid-position. Turn the System switch to MAN. Switch the LIMITER and B.F.O. off.

Select a BANDWIDTH of 3 or 6.5 KC/S. Rotate the I.F. GAIN control to three-quarters of fully clockwise.

### 3.3 FILM SCALE CALIBRATION

Set the System switch to CAL. Select a BANDWIDTH of 3 KC/S.

Set the KILOCYCLES scale to that 100 kc/s point which is nearest to the frequency required and adjust the control accurately until a zero-beat note is obtained. Move the milled cursor slide on the dial escutcheon so that the pointer coincides exactly with the selected 100 kc/s division.

Restore all other controls to the preliminary setting shown in Section 3.2 above.

### 3.4 B.F.O. CALIBRATION

Switch on the b.f.o. and set the System switch to CHECK B.F.O.

Adjust the B.F.O. NOTE KC/S control to zero-beat.

Restore all other controls to the preliminary setting shown in Section 3.2 above.

### 3.5 TUNING

Set the MEGACYCLES dial to the required integer. The tuning of this control is quite flat and the optimum position may be found by adjusting the control to the point at which the receiver noise is greatest.

Set the KILOCYCLES scale to the required frequency.

Set the AE. (ANT.) RANGE MC/S switch to the correct frequency band. Adjust the AE. (ANT.) TUNE control for maximum noise.

It should now be possible to identify the desired signal. Switch on the b.f.o. if the required signal is not modulated.

Switch on the b.f.o. and set the calibrated B.F.O. NOTE KC/S control to the zero position, then adjust finally for a zero-beat note.

If it is desired to operate the receiver on c.w., adjust the B.F.O. NOTE KC/S control to the most acceptable audio-beat note. Set the BANDWIDTH control for optimum reception. Set the A.F. GAIN to MAX. (consistent with no over-loading) and adjust the output level with the I.F. GAIN control.

For m.c.w. or r.t. reception, switch the b.f.o. off. Adjust the I.F. and A.F. GAIN controls as for c.w. reception. (Refer to 3.1, I.F. GAIN.)

Set the System switch to A.V.C. and select a SHORT or LONG time-constant as required.

Set the BANDWIDTH control to the optimum position.

### 3.6 "S" METER

The "S" meter in North American versions should be correctly set to zero in order to obtain the maximum accuracy of calibration.

With no antenna connected, set the ANT. ATTENUATOR to MAX. Set the System switch to A.V.C. Turn the I.F. GAIN control to the maximum clockwise position. Note: Unless the I.F. GAIN control is in the maximum position, the "S" meter calibration is upset.

Remove the plated cap below the meter.

Adjust the setting of the balance control (accessible through the hole in the panel) by means of a screwdriver until the meter reads zero.

## SECTION 4

### BRIEF TECHNICAL DESCRIPTION

This section describes briefly, with the aid of the block diagram in Fig. 1, the basic theory of operation. For a more detailed explanation of the receiver, Section 5 (DETAILED CIRCUIT DESCRIPTION) should be consulted.

#### 4.1 SIGNAL INPUT

The aerial loading (75Ω unbalanced) is designed for optimum performance when the input circuits are tuned. With the AE. (ANT.) RANGE MC/S switch set to WIDEBAND, the input impedance is high unless the AE. (ANT.) ATTENUATOR is in use.

#### 4.2 FIRST MIXER

Input signals between 0.98 and 30 Mc/s are fed via an r.f. amplifier and a 30 Mc/s low-pass filter to the first mixer (M1) where they are mixed with the output from a variable frequency oscillator VFO-1 (MEGACYCLES tuning). This oscillator has a frequency range of 40.5 to 69.5 Mc/s. The first i.f. stage is in effect a band-pass filter tuned to 40 Mc/s ± 650 kc/s. Thus, according to the setting of VFO-1, any spectrum of signals 1 Mc/s wide and existing in the range 0.98 to 30 Mc/s can be mixed in M1 to produce an output acceptable to the first i.f. band-pass filter.

It should be noted at this stage that the exact setting of VFO-1 is determined by conditions in the second and fourth mixer circuits ; these restrict the possible settings to positions 1 Mc/s apart (e.g. 40.5, 41.5, 42.5 Mc/s, etc.).

#### 4.3 HARMONIC GENERATOR AND MIXER

The output from a 1 Mc/s crystal oscillator is connected to a harmonic generator. The harmonics derived from this stage are passed through a 32 Mc/s low-pass filter and mixed with the output from VFO-1 in the fourth mixer (M4). This mixer provides an output at 37.5 Mc/s which is amplified before passing through a band-pass filter tuned to 37.5 Mc/s with a bandwidth of ± 150 kc/s.

The presence of this filter restricts the setting of VFO-1 to an exact number of Mc/s plus 37.5 Mc/s in order to give an output acceptable to the filter and amplifier. As a result, the first v.f.o. must be tuned in 1 Mc/s steps.

#### 4.4 SECOND MIXER

The 40 Mc/s first i.f. signal is mixed in the second mixer (M2) with the 37.5 Mc/s output from M4 in order to produce an output consisting of a 1 Mc/s spectrum in the frequency range 2-3 Mc/s (second i.f.).

To clarify this method of operation, some examples of dial settings and intermediate frequencies corresponding to various incoming signals are tabulated below :—

Dial Mc/s	Settings kc/s	Signal Freq. $f_s$ Mc/s	VFO-1 $f_o$ Mc/s	Xtal Harmonic $nf_c$ Mc/s	1st I.F. $f_o - f_s$	Het. Freq. $f_o - nf_c$ (M4 output)	2nd I.F. $nf_c - f_s$
4	1,000	5.0	44.5	7th	39.5	37.5	2.0
5	0	5.0	45.5	8th	40.5	37.5	3.0
18	600	18.6	58.5	21st	39.9	37.5	2.4

Frequency drift of VFO-1 within the limits of the 37.5 Mc/s filter bandwidth, does not affect the frequency stability of the receiver. A change in this oscillator frequency will alter the first i.f. to the same extent and in the same sense as the nominal 37.5 Mc/s signal from M4. Therefore the difference frequency from M2 will remain constant.

#### 4.5 THIRD MIXER

The 2-3 Mc/s receiver, which follows M2, is preceded by a tuned three stage band-pass filter ganged to the second variable frequency oscillator VFO-2 (KILOCYCLES tuning). This oscillator is temperature compensated and the output is mixed in the third mixer (M3) with the 2-3 Mc/s output from the band-pass filter to provide the third and final intermediate frequency of 100 kc/s.

#### 4.6 THIRD I.F. STAGE

The final i.f. stages are preceded by crystal lattice and L-C filters which provide six alternative bandwidths. Separate signal and a.v.c. diodes are employed and alternative switched time-constants give the optimum conditions for telegraphy and telephony reception. An additional i.f. amplifier is incorporated to give an independent output at 100 kc/s.

#### 4.7 A.F. STAGES

Two independent audio frequency stages are incorporated for either line output or headphone sockets and internal loudspeaker ; each stage is provided with a level control (see TECHNICAL SPECIFICATION).

#### 4.8 CRYSTAL CALIBRATOR

A crystal calibrator unit is incorporated to enable the scale of VFO-2 to be checked at 100 kc/s intervals. These check points are obtained from a regenerative divider controlled by the 1 Mc/s crystal oscillator.




FIG. 1 BLOCK DIAGRAM OF THE RECEIVER TYPE RA.17

## SECTION 5

### DETAILED CIRCUIT DESCRIPTION

Reference should be made to the circuit diagram at the end of this handbook.

#### 5.1 AERIAL CIRCUIT

A 75 $\Omega$  unbalanced aerial source is connected to the tuned r.f. amplifier through a three-section 30 Mc/s low-pass filter and a five-position attenuator covering a range of 0 to 40 dB. Switch S2 selects wideband operation or any one of the six double-tuned aerial coils LA-9 for tuned operation. These aerial coils are aligned by means of dust iron cores. The aerial is tuned by a capacitor C18A/B which is switched out of circuit in the wideband position.

#### 5.2 R.F. AMPLIFIER

The incoming signal is fed via C28 and grid stopper R25 to the grid of V3B; the r.f. stage (V3) employs a variable- $\mu$ , low-noise double-triode; the two halves of the valve are connected in cascade so as to utilize the low-noise high-gain properties of the valve. A delayed a.v.c. voltage, derived from a shunt diode network, is applied to the grid of V3B when the signal level is approximately 10 $\mu$ V. The capacitors C40 and C41 ensure that the cathode is adequately decoupled over the wide frequency range. Ferrite beads have been fitted to the heater lead, connected to pin 4, the anode of V3A and the cathode of V3B adjacent to C41, to prevent parasitic oscillations occurring.

#### 5.3 30 Mc/s LOW-PASS FILTER

The amplified signal is passed to a 30 Mc/s low-pass filter which has a substantially flat response over the frequency range. L27, C47 and R28 constitute the first 'L half-section' of the filter. The signal is then fed at low impedance (680 $\Omega$ ) through the coupling capacitor C74 and the grid stopper R45 to the control grid of V7, the first mixer stage. The input capacitance of V7 forms the capacitance to chassis between L15 and L17 required to complete the filter network.

**Note :** This capacitance is not critical, therefore no adjustment will be necessary should V7 be changed.

#### 5.4 FIRST VARIABLE FREQUENCY OSCILLATOR (VFO-1)

This circuit comprises a cathode-coupled Hartley oscillator stage (V5) which may be continuously tuned over the frequency range of 40.5-69.5 Mc/s. The frequency determining components are an inductance L36 and a variable capacitance C76. Alignment is accomplished by adjusting the aluminium core of L36 and the trimming capacitor C77. The variable capacitor C76 is coupled to the Mc/s dial which is calibrated from 0 to 29 Mc/s. The anode load consists of L20, a compensating inductance which is wound on a 470 $\Omega$  resistor R18. The oscillator is coupled via C85 to the signal grid of the first mixer stage V7 and also via C42 to the control grid of the harmonic mixer V4.

**Note :** The Mc/s dial calibration may be affected if V5 is changed. The necessary correction may be made by adjusting C77 with the Mc/s dial set to 29 Mc/s. (See Part 2, Section 5, para. 5.9).

#### 5.5 FIRST MIXER (M1)

The outputs from the 30 Mc/s low-pass filter and the variable frequency oscillator VFO-1 are fed to the signal grid of the mixer stage (V7) which produces a signal at 40 Mc/s. The signal is then passed to a 40 Mc/s band-pass filter which forms the anode load of this stage.

#### 5.6 40 Mc/s BAND-PASS FILTER

The 40 Mc/s band-pass filter consists of eight over-coupled tuned circuits connected in cascade and is tuned by the trimming capacitors C21, C33, C43, C53, C61, C70, C79 and C88. This filter, which has a passband of 40 Mc/s  $\pm$  650 kc/s, ensures that only the required 1 Mc/s spectrum of signals is passed to the second mixer stage. This filter is deliberately set to a slightly wider passband than is theoretically required, to allow for possible drift in VFO-1.

#### 5.7 1 Mc/s CRYSTAL OSCILLATOR

The frequency of the crystal oscillator V1, which is a cathode-coupled Colpitts circuit, may be set precisely to 1 Mc/s by adjusting the trimming capacitor C2. The anode coil L2 which is adjusted to resonate at 1 Mc/s by means of a dust iron core is electron coupled to the oscillator. The fixed capacitors C9, C10 and C11 complete the tuned circuit. The output from V1 is capacitance-coupled to the harmonic generator V2, coaxial plug PL3A for feeding a 1 Mc/s input into the I.F. converter, and also to the first grid of the mixer valve V13 via PL2/SK2.

## 5.8 HARMONIC GENERATOR

The 1 Mc/s signal is fed through the coupling capacitor C8 to the control grid of the harmonic generator (V2). Megacycle harmonics are produced in this stage by operating the valve in a non-linear state. A suitable bias potential is produced due to the time constant of C8 and R13. The screen grid is not de-coupled.

## 5.9 32 Mc/s LOW-PASS FILTER

The megacycle harmonics are fed through a 32 Mc/s low-pass filter circuit to prevent harmonics other than those required from passing to the harmonic mixer (V4). Limited control over the cut-off frequency is provided by C7 which is adjusted to equalize the output from the filter at the harmonic frequencies corresponding to 28 and 29 Mc/s on the MEGACYCLE dial.

## 5.10 HARMONIC MIXER (M4)

The outputs from the 32 Mc/s low-pass filter and VFO-1 are mixed in the harmonic mixer (M4) by applying the filtered megacycle harmonics to the suppressor grid and the output from the VFO-1 to the control grid. The 37.5 Mc/s output is selected by the tuned anode load, consisting of a fixed capacitor C50 and an inductance L28 which may be adjusted by means of a dust iron core, and coupled by C51 to V6. R36 is a grid stopper.

## 5.11 2-STAGE 37.5 Mc/s AMPLIFIER (1)

The anode load of V6 is a tuned circuit consisting of a fixed capacitor C67 and an inductor L33 which is tuned to 37.5 Mc/s. Frequency adjustment is by the dust iron core in L33. This stage feeds the amplified signal via C68 to the following stage V8. The 37.5 Mc/s signal is then passed to the 37.5 Mc/s band-pass filter. The anode load of this stage is provided by this filter.

## 5.12 37.5 Mc/s BAND-PASS FILTER

The 37.5 Mc/s band-pass filter consists of eight under-coupled tuned circuits arranged in cascade. These filter sections may be tuned by C24, C35, C45, C55, C63, C72, C81 and C90 respectively. This filter, which has a passband of 300 kc/s, allows for possible drift in VFO-1. The narrow passband and high rejection to frequencies outside the passband prevent spurious signals from reaching the second mixer stage (V9).

## 5.13 37.5 Mc/s AMPLIFIER (2)

The filtered 37.5 Mc/s signal is further amplified by V10 before being passed to the second mixer stage (V9). To prevent interaction between the 40 Mc/s band-pass filter and the 37.5 Mc/s tuned circuit (L50 and C113) and to enable either circuit to be adjusted without affecting the other, a balancing circuit is included which is shown in a simplified form in figure 2.




FIGURE 2

The 40 Mc/s signal is introduced into the 37.5 Mc/s tuned circuit at a point of zero r.f. potential since L50 is centre tapped and C108 is adjusted to be equal to the total of the capacitances of V10 anode to ground, C107 and the input capacitance of V9.

Notes : The anode load of V10 is adjusted to 37.5 Mc/s by adjusting the dust iron core in L50.  
The balancing circuit will not be affected if V9 or V10 is changed.

#### 5.14 SECOND MIXER (M2)

This mixer (V9) produces the second intermediate frequency of 2-3 Mc/s by mixing the 40 Mc/s i.f. and the 37.5 Mc/s signal. The anode choke L51 and the tuned circuit formed by C116 and L52 remove the 37.5 Mc/s frequency and other h.f. components, so that only the second i.f. is passed to the 2-3 Mc/s band-pass filter preceding the third mixer stage. The series tuned circuit is tuned to 37.5 Mc/s by adjusting the dust iron core in L52.

#### 5.15 2-3 Mc/s TUNED BAND-PASS FILTER

This filter (which is ganged to the second Variable Frequency Oscillator) consists of three tuned band-pass filter sections as follows :—

- (a) An inductor L59 and a variable capacitor C129. A fixed capacitor C127 and a trimmer C128 complete this section. L59 is tapped to provide an input connection via the coaxial plug PL5 so that the 2-3 Mc/s low impedance output of the L.F. Converter may be connected.
- (b) A variable inductor L58 is connected in series with a coupling coil L60 and a variable capacitor C126. A fixed capacitor C124 and a trimmer C125 are connected in parallel with C126.
- (c) An inductor L57 and a variable capacitor C123 in parallel with a fixed capacitor C121 and a trimmer C122 form the final section.

The correct bandwidth is obtained by adjusting the dust iron cores and the trimming capacitors C128, C125 and C122 respectively.

#### 5.16 THIRD MIXER

The output from the 2-3 Mc/s band-pass filter is directly coupled to the signal grid of a pentagrid valve V11 and the second VFO output (2.1 to 3.1 Mc/s) is fed through the coupling capacitor C143 to the oscillator grid. The resistor R68 completes the d.c. path from this grid to earth. The 100 kc/s output obtained from this mixer stage is then fed via PL6, SK6 and a screened cable to the crystal filter unit.

**Note :** The resistors R67 and R72 are grid stoppers.

#### 5.17 SECOND VARIABLE FREQUENCY OSCILLATOR (VFO-2)

The second Variable Frequency Oscillator, covering a frequency range of 2.1 to 3.1 Mc/s, is an electron coupled Hartley circuit. The oscillation frequency is determined by an inductance L55 (which can be adjusted by means of a ferrite core), a fixed capacitor C137, a trimming capacitor C136 and a variable capacitor C139 which is ganged to the tuned band-pass filter. The KILOCYCLES scale which is calibrated between 0 and 1,000 kc/s is coupled to this ganged capacitor. The output from VFO-2 is resistance-capacitance coupled (R76 C143) to the third mixer stage (V11). An additional output from the cathode of VFO-2, is fed directly to a coaxial plug PL11 for feeding auxiliary units.

#### 5.18 CRYSTAL FILTER

Six alternative switched i.f. bandwidths are available as follows:—

100 c/s } 300 c/s } Crystal	1.2 kc/s } 3.0 kc/s } 6.5 kc/s } 13.0 kc/s } L-C
--------------------------------	-----------------------------------------------------------

In the crystal positions the third mixer anode is connected to L48 in the crystal filter. L47 and L49 provide a balanced output which is tuned by capacitors C109 and C110. In the 100 c/s position, the balanced output is connected via crystals XL2 and XL5 to the first tuned section of the 100 kc/s L-C filter. The differential trimmer C118 is the phasing control for this bandwidth. XL3, XL6 and capacitor C119 form a similar circuit for the 300 c/s position. Damping resistors R64 and R65 are connected across the tuned circuits to obtain the required bandwidth.

In the four L-C bandwidth positions the crystal filter is by-passed and the anode of the third mixer valve (V11) is connected directly to the first tuned section of the 100 kc/s L-C filter.

#### 5.19 100 kc/s L-C FILTER

##### (i) L-C Bandwidths

This filter consists of four tuned circuits arranged in cascade. In the L-C bandwidth positions, the signal is fed to the tuned circuit formed by L61 and the combination of the capacitors C145, C146, C146A and C147. The second section consists of L62 and L63 in series with C152, C152A and C153. The final section consisting of L68 and L71 in series with C161 and C162, is damped by the series resistors R86, R87, R87A and R88 according to the bandwidth. In the L-C positions the output is taken from a capacitive divider formed by C161 and C161A with C170, to equalize the gains in the L-C and crystal bandwidth positions.

The L-C bandwidths are obtained by varying the degree of coupling between each section of the filter in addition to the damping resistors in the final stage. The capacitor C175 is included to compensate for the effective reduction of the input capacitance of V14, appearing across the tuned circuit, when switching from crystal to L-C positions.

### (ii) Crystal Bandwidths

To maintain the input capacitance of the L-C filter, in the crystal positions, a trimming capacitor C148 is switched into circuit. This trimmer is adjusted to be equal to the output capacitance of V11 and the screened cable.

In the crystal bandwidth positions, the L-C filter is operating in its narrow bandwidth position, *i.e.* 1.2 kc/s.

**Note :** The damping resistors R77 and R80 are disconnected except during filter alignment.

### 5.20 FIRST 100 kc/s I.F. AMPLIFIER

The output from the L-C filter is passed through a coupling capacitor C164 to the control grid of the pentode amplifier valve V14. This grid is returned via R96 to the a.v.c. line which is filtered at this point by R102 and C173. The screen potential is derived from a potential divider formed by R93, R94 and R97. This stage is coupled to the second i.f. amplifier and the i.f. output stage by a double tuned transformer having an over-coupled characteristic.

### 5.21 SECOND 100 kc/s I.F. AMPLIFIER

The signal from the first i.f. transformer is fed through the grid stopper R114 to the control grid of the second i.f. amplifier. H.T. is supplied to the screen via the dropping resistor R113 and is de-coupled by C181. The anode load is a tuned circuit consisting of L77, C192 and C191. This circuit is heavily damped by R112. The secondary winding L78 and L79 is tuned by C195A and C195B with R120A as a damping resistor. The output is fed to the diode detector anode.

### 5.22 DIODE DETECTOR

The low potential end of L79 is connected through the r.f. filter (C209, R128, C210, R129 and C211) to the diode load R130. With the meter switched to R.F. LEVEL the meter indicates the detector diode current. The resistor R131 is included to complete the diode detector circuit when the meter is switched out of circuit.

### 5.23 NOISE LIMITER

The noise limiter diode (pins 2 and 5 of V21) is connected in a series circuit to operate at approximately 30% modulation. Its operation is explained with reference to Figure 3.




FIGURE 3



The d.c. path from point A is through R134, R135, the diode and R137. The a.f. signal path from the detector diode load is through C216, the diode and C218 when S8 is open. In the presence of a signal, a negative potential varying with the depth of modulation, will be developed at point A thus causing the diode to conduct. The negative potential at B, will be lower than that at A and will be maintained at a constant level due to the long time constant of R134 and C217. R135 allows the cathode potential to vary in sympathy with the modulation provided the modulation depth does not exceed 30%. The potential appearing at the cathode of the noise limiter diode therefore consists of a steady negative potential with the modulation superimposed. When noise impulses corresponding to high modulation peaks appear at point A and via C216 at point C, the voltage across the diode changes sign thereby causing the diode to stop conducting and open-circuit the a.f. signal path. With S8 in the OFF position the limiter is inoperative.

#### 5.24 A.V.C. AND T.C. DIODE

The signal appearing at the anode of V16 is passed through the capacitor C193 to the anode of the a.v.c. diode. The diode load is formed by R116. A positive potential derived from R120, R121 and R122, supplies the required a.v.c. delay voltage to the cathode of this diode. When the A.V.C. switch is in the SHORT position and the System switch set to a position in which the a.v.c. is operative, i.e. A.V.C., CAL or CHECK B.F.O., the anode of the a.v.c. diode is connected to the a.v.c. line via L81 and R127. The choke L81 is tuned by C203 to a frequency slightly below 100 kc/s so that it presents a small capacitance at 100 kc/s, thus R127 is prevented from shunting the diode load. When the A.V.C. switch is in the LONG position the a.v.c. de-coupling capacitors C182 and C173 are charged through R127 and the Time Constant diode. When the signal level falls, the capacitors C182 and C173 discharge through R118, R127 and L81 into the diode load resistor R116. The a.v.c. potential is brought out via R123 to the tag strip at the rear of the receiver for external use if required. With the System switch set to the MANUAL position, the a.v.c. line is connected to the I.F. GAIN control RV1, thus the gain of the 100 kc/s amplifiers may be varied by adjusting the negative potential applied to the a.v.c. line.

#### 5.25 AUDIO OUTPUT

Audio frequencies are applied to the control grid of V22 (V23B, North American version) via RV2 the R.F. GAIN control. The output transformer (T2) provides four separate outputs as follows: 50mW (1W, North American version) into 3Ω, and three windings supplying 3mW into 600Ω.

The headphone jacks JK1 and JK2 and the internal loudspeaker (which may be switched out of circuit by operating S11) are connected across the 3Ω winding.

#### 5.26 A.F. LINE OUTPUT

The audio frequencies are also applied to the grid of V23 (V23A, North American version) via RV3, the A.F. LEVEL control; this control presets the level from the output transformer T3. The transformer provides a 10mW output at 600Ω which is suitable for direct connection to landlines. A bridge rectifier MR1 is connected across the output via R142 and R143. The meter may be switched across the rectifier circuit so that the operator can monitor the a.f. output.

**Note :** The red line on the meter scale corresponds to 10mW output into 600Ω.

#### 5.27 BEAT FREQUENCY OSCILLATOR

The beat frequency oscillator (V19) employs an electron-coupled Hartley circuit. The oscillation frequency is determined by a fixed inductor L82 and a variable capacitor C200 in parallel with C202 and C201. The trimming capacitor C201 is adjusted to produce an output frequency of precisely 100 kc/s when the beat frequency oscillator frequency control is set to zero. Bias is applied to this valve by C199 and R125.

The b.f.o. output is coupled to the diode detector anode via C215. The b.f.o. is supplied with h.t. via S7 except when the System switch is in the CAL or STANDBY positions.

#### 5.28 100 kc/s I.F. OUTPUT

The control grid of V17 is connected to the secondary of the first 100 kc/s i.f. transformer which feeds the stage with the 100 kc/s signal. The screen resistor R108 and the cathode bias resistor R115 are of the same values as used in the second 100 kc/s i.f. amplifier, hence the a.v.c. characteristic of this stage is identical to that of the main receiver. The anode load resistor R109 feeds the auto transformer L76 via the blocking capacitor C189. This transformer provides a 70Ω output at PL8 and PL9 for external applications.

**Note :** PL8 and PL9 are connected in parallel, therefore only one 100 kc/s output is available at 75Ω, and to avoid a mis-match the other connection should be made at high impedance.

## 5.29 CRYSTAL CALIBRATOR

The crystal calibrator, controlled by the 1 Mc/s crystal, feeds signals at 100 kc/s intervals to the signal grid of the third mixer stage to provide calibration check points.

The 1 Mc/s signal, fed through PL2, is connected through SK2 and the grid stopper R83 to the first grid of the mixer valve V13. The anode load consists of a 100 kc/s tuned circuit (L70 C167) and is coupled to the control grid of V15 through the capacitor C168. The anode load of V15 (L75 C177) is tuned to 900 kc/s and is coupled via C178 to the third grid of V13. V15 is heavily biased so that it functions as a frequency multiplier.

An output of 900 kc/s, appearing across the tuned circuit (L75 C177) is coupled to grid 3 of V13 thereby producing a difference frequency of 100 kc/s relative to the 1 Mc/s input. The 100 kc/s output appears across the anode tuned circuit (L70 C167) and is fed to the control grid of V15. The ninth harmonic is selected in turn by the anode tuned circuit (L75 C177) of V15 and fed back to the third grid of V13 to provide the beat frequency of 100 kc/s with the 1 Mc/s input. This crystal-controlled regenerative circuit is thus self-maintaining. The 100 kc/s output is obtained from the coil L69 which is mutually coupled to L70 and fed via the octal plug (PL7) to the third mixer V11.

## 5.30 POWER SUPPLIES

The conventional bi-phase half-wave rectifier circuit, employing a capacitor input filter, provides 220 volts h.t. supply. A  $165\Omega$  resistor R124 is connected between the negative line of the power supply and earth thus providing a negative 25V d.c. supply for gain control purposes. The resistor R136 has been included to limit the peak current of V20 to a safe value. To remove mains-borne interference the capacitors C224 and C225 are included. All valve heaters and the scale illuminating lamp are supplied from the 6.3V 7A winding. The mains transformer T1 has input taps at 0, -5, -10, 110, 125, 210, 230 and 250 volts and is connected to the supply via F1 (2A), S10 and a three-pin Mk. IV plug and socket (PL10, SK10); this does not apply to North American versions of the receiver.

## 5.31 SYSTEM SWITCH

The following conditions exist for each setting of the System switch. The link on the h.t. adaptor terminals is assumed to be in position.

- (a) **STANDBY** S5A disconnects the h.t. from all stages and connects R119A across the h.t. as a compensating load.
- (b) **MANUAL**
  - (i) The h.t. is passed through S5A, S5B and S5C to all stages except the calibrator unit.
  - (ii) S5F connects h.t. to the b.f.o. when S7 is switched on.
  - (iii) The a.v.c. line is disconnected from the a.v.c. diode by S5D and connected to the I.F. GAIN control (RV1) by S5E.
- (c) **A.V.C.**
  - (i) (b) (i) and (b) (ii) applicable.
  - (ii) S5E renders the I.F. GAIN control inoperative.
  - (iii) S5D connects the a.v.c. line to the a.v.c. diode.
- (d) **CAL.**
  - (i) H.T. is applied via S5A, S5B and S5F to all stages except :—
    - The r.f. amplifier (V3)
    - The first v.f.o. (V5)
    - The first mixer (V7)
    - The second mixer (V9)
    - The final 37.5 Mc/s amplifier (V10)
    - The b.f.o.
  - (ii) (c) (ii) and (c) (iii) applicable.
- (e) **CHECK BFO**
  - (i) (d) (i) applicable except that h.t. is also applied to the b.f.o.
  - (ii) (c) (ii) and (c) (iii) applicable.

## 5.32 "S" METER

Suitable circuitry is included in North American versions only of the receiver. The meter is connected between the cathode of V16 and a point of preset (RV4) positive potential. It is calibrated to provide a reading of "S1" for a  $1.25\mu\text{V}$  signal and ascending "S" points in approximately 4dB steps. Above "S9", divisions are in increments of 10dB. It should be remembered that only with the I.F. GAIN control at maximum is the correct calibration maintained.

PART 2  
MAINTENANCE

# PART 2

## MAINTENANCE

### INDEX

		<i>Page</i>
	WARNING . . . . .	29
	TEST EQUIPMENT FOR MAINTENANCE . . . . .	30
SECTION 1	SPURIOUS RESPONSES :—	
1.1	Origins of Spurious Responses . . . . .	31
1.2	Checks for Spurious Responses . . . . .	31
SECTION 2	VALVE DATA :—	
2.1	Valve Connections (British Version) . . . . .	33
2.2	Valve Complement and Typical D.C. Voltages (British Version) . . . . .	33
2.3	Valve Connections (North American Version) . . . . .	34
2.4	Valve Complement and Typical D.C. Voltages (North American Version) . . . . .	34
SECTION 3	FAULT DIAGNOSIS :—	
3.1	Introduction . . . . .	37
3.2	Test Equipment Requirements . . . . .	37
3.3	Fault Diagnosis . . . . .	37
SECTION 4	REPRESENTATIVE TEST DATA . . . . .	39
SECTION 5	ALIGNMENT PROCEDURES :—	
5.1	General . . . . .	41
5.2	100 kc/s I.F. Strip . . . . .	41
5.3	Second V.F.O. . . . .	42
5.4	B.F.O. . . . .	43
5.5	Second I.F. Circuit . . . . .	43
5.6	37·5 Mc/s Filter and Amplifier . . . . .	43
5.7	1 Mc/s Crystal Oscillator . . . . .	43
5.8	Second Mixer Drive Level . . . . .	43
5.9	First V.F.O. Calibration . . . . .	43
5.10	Aerial Circuit . . . . .	44
5.11	Crystal Calibrator . . . . .	44
5.12	40 Mc/s Filter . . . . .	44
SECTION 6	DISMANTLING AND REPLACEMENT PROCEDURES :—	
6.1	Unit Breakdown . . . . .	45
6.2	Dismantling Instructions . . . . .	45
6.3	Valve Replacement . . . . .	46
SECTION 7	ILLUSTRATIONS—INDEX . . . . .	47
SECTION 8	LIST OF CIRCUIT COMPONENTS :—	49
8.1	Resistors . . . . .	51
8.2	Potentiometers . . . . .	54
8.3	Capacitors . . . . .	54
8.4	Switches . . . . .	59
8.5	Plugs and Sockets . . . . .	60
8.6	Valves (British) . . . . .	61
8.7	Valves (American) . . . . .	61
8.8	Valve and Crystal Holders . . . . .	61
8.9	Inductances . . . . .	62
8.10	Transformers . . . . .	64
8.11	Rectifiers . . . . .	64
8.12	Loudspeakers . . . . .	65
8.13	Meters . . . . .	65
8.14	Crystals . . . . .	65
8.15	Fuses and Fuseholders . . . . .	65
8.16	Lamp and Holder . . . . .	65
8.17	Voltage Selectors . . . . .	65
8.18	Supplementary Components and Sub-Assemblies . . . . .	65
8.19	Main Sub-Units . . . . .	67

## **WARNING**

The Receiver will, under normal conditions, remain in alignment over an extremely long period of time, consequently ALL POSSIBILITY OF OTHER CAUSES OF LOW SENSITIVITY SHOULD BE ELIMINATED BEFORE RE-ALIGNMENT IS CONSIDERED, and should then only be undertaken by order of the Engineer responsible for the maintenance of the equipment.

Should it become necessary to re-align any part of the receiver only a very small angular adjustment of the trimmers should be necessary unless units have been changed.

## TEST EQUIPMENT REQUIRED FOR MAINTENANCE

The following items of test gear are required to carry out the maintenance described in this part of the handbook :—

- (a) Valve voltmeter reading up to 5·0V at frequencies up to 70 Mc/s
- (b) Signal generator capable of operating on fundamental frequencies up to 40 Mc/s
- (c) Digital frequency meter measuring frequencies at least up to 100 kc/s
- (d) Multi-meter measuring a.c. and d.c. quantities up to 500V with resistance of 20,000 $\Omega$  per volt
- (e) Heterodyne wavemeter measuring 40–70 Mc/s
- (f) Miscellaneous: viz. 0·1 $\mu$ F capacitor, 4·7k $\Omega$  resistor and 12pF trimmer capacitor.

**Note :** Major users of the RA.17 Receiver are advised to obtain factory-type test jigs for alignment of the various units. Details of these jigs and specially designed test gear will be supplied on request. A supplement to Section 5 (Alignment Procedures) describing the employment of this test gear can be made available to such users.

## SECTION 1

### SPURIOUS RESPONSES

#### 1.1 ORIGINS OF SPURIOUS RESPONSES

In a highly sensitive receiver, precautions against internally generated spurious responses are essential. To this end, the various sections of the receiver have been carefully screened and the power supplies filtered.

Any reduction in the screening efficiency or the failure of any filtering component may result in spurious signals being generated. It is therefore essential to ensure that the bonding surfaces are clean and that all securing screws are tight. Spurious responses in the receiver may occur from the following main causes:—

- (a) 37.5 Mc/s break-through from the second mixer V9 to the third mixer V11
- (b) Break-through of 1 Mc/s harmonics
- (c) Break-through of b.f.o. harmonics
- (d) Responses at 2.550 and 3.050 Mc/s due to second v.f.o. break-through.

#### 1.2 CHECKS FOR SPURIOUS RESPONSES

Spurious responses are measured relative to receiver noise in the following manner:—

When a response is located, the receiver is de-tuned from it just sufficiently to render the beat note inaudible. The i.f. gain is then adjusted to provide a convenient noise reference output (1mW) and the receiver re-tuned to the spurious signal for maximum output. The dB rise in audio output is a measure of the spurious signal level relative to receiver noise.

Standard conditions of test :

- No connection to aerial socket
- System switch to MAN
- I.F. GAIN at MAX
- B.F.O. on
- 3 kc/s bandwidth
- AE (ANT.) ATTENUATOR at MIN.

##### (a) 37.5 Mc/s Break-through to Third Mixer

Switch AE (ANT.) RANGE to WIDEBAND.

This response will be indicated as a beat note which varies rapidly in frequency with respect to the KILOCYCLES scale, *i.e.* a change of 1 kc/s on the scale results in a much larger change in the note. It will also move along the KILOCYCLES scale if the MEGACYCLES dial is adjusted slightly. This response may be eliminated by adjusting the 37.5 Mc/s trap (L52 at second mixer anode).

##### (b) 1 Mc/s Harmonic Break-through

Switch AE (ANT.) RANGE to WIDEBAND.

1 Mc/s break-through responses appear at 0 and 1,000 on the KILOCYCLES scale at each setting of the MEGACYCLES dial and are generally more prominent with wideband input. If the response is dependent upon the setting of the MEGACYCLES dial, the 1 Mc/s spectrum is probably breaking through to the first mixer stage. If the response is independent of the MEGACYCLES dial setting, it is due either to break-through of the second and/or third harmonic to the second or third mixer stage. Remove second mixer valve to eliminate this stage and so determine in which stage the break-through occurs.

##### (c) First V.F.O. Harmonics

Spurious responses may occur at 4.5, 5.5 and/or 17.5 Mc/s, if C42A and/or C194A are open-circuit. These responses are caused by the harmonics of the first v.f.o. breaking through to the second mixer stage and beating with the harmonics of the 37.5 Mc/s heterodyne voltage.

##### (d) B.F.O. Harmonics

These responses may be detected at 100 kc/s intervals between 1 and 1.5 Mc/s when the b.f.o. frequency is 100 kc/s and the receiver aerial input is tuned.

##### (e) Second V.F.O. Break-through

Responses may occur at 2.550 and 3.050 Mc/s with tuned aerial input.

Ascertain that the first and second v.f.o. are not in contact, that the v.f.o. chassis is well bonded to the main chassis and the fixing screws are tight.

**Notes:** A failure in any one of the following capacitors C66, C92, C96, C97, C98, C103 or C104 may result in increased 'end of band' responses. These responses will disappear when the MEGACYCLE dial is de-tuned.

The failure of C117, C154, C155, C207, C208 or C214 can result in increased 'end of band' responses, or b.f.o. harmonic break-through. De-tuning the MEGACYCLES dial will have no effect.

## SECTION 2

### VALVE DATA

Details of valves used in the British and American receiver are shown below. A key to the valve base connections is provided in Figure 4. The location of valves in the receiver is shown in Figure 5.

#### 2.1 VALVE CONNECTIONS (British Version)

Pin No.	CV138	CV140	CV1377	CV4012	CV454	CV2209	CV3998	CV5331
	EF91	EB91	GZ34	EK90	EF93	6F33	E180F	ECC189
1	Grid 1	Cathode 1	N.C.	Grid 1	Grid 1	Grid 1	Cathode	Anode 2
2	Cathode	Anode 2	Heater	Cathode & Grid 5	Grid 3	Cathode	Grid 1	Grid 2
3	Heater	Heater	Omitted	Heater	Heater	Heater	Cathode	Cathode 2
4	Heater	Heater	Anode	Heater	Heater	Heater	Heater	Heater
5	Anode	Cathode 2	Omitted	Anode	Anode	Anode	Heater	Heater
6	Grid 3 & Screen	Screen	Anode	Grid 2 & Grid 4	Grid 2	Grid 3 & Diode	I.C.	Anode 1
7	Grid 2	Anode 1	Omitted	Grid 3	Cathode	Grid 2	Anode	Grid 1
8	—	—	Heater	—	—	—	Grid 3 & Screen	Cathode 1
9	—	—	—	—	—	—	Grid 2	Screen
Base	B7G	B7G	Int. Octal	B7G	B7G	B7G	B9A	B9A

#### 2.2 VALVE COMPLEMENT AND TYPICAL D.C. VOLTAGES (British Version)

Cct. Ref.	Function	CV No.	Equivalent	Anode	Screen	Cathode	Cct. Ref.
V1	Crystal Oscillator	138	√ EF91	175 (5)	175 (7)	40 (2)	V1
V2	Harmonic Generator	138	√ EF91	195 (5)	70 (7)	—	V2
V3	R.F. Amplifier	5331	√ ECC189	185 (1)	—	1.0 (8)	V3
				95 (2) Grid			
				95 (6)			
V4	Harmonic Mixer	2209	√ 6F33	200 (5)	150 (7)	1.95 (2)	V4
V5	First V.F.O.	138	√ EF91	210 (5)	200 (7)	—	V5
V6	37.5 Mc/s Amplifier	138	√ EF91	205 (5)	150 (7)	1.15 (2)	V6
V7	First Mixer	3998	√ E180F	190 (7)	140 (9)	0.95 (1)	V7
V8	37.5 Mc/s Amplifier	138	√ EF91	200 (5)	185 (7)	1.8 (2)	V8
V9	Second Mixer	3998	√ E180F	200 (7)	155 (9)	1.1 (1)	V9
V10	37.5 Mc/s Amplifier	138	√ EF91	205 (5)	200 (7)	1.85 (2)	V10
V11	Third Mixer	4012	√ EK90	210 (5)	85 (6)	1.18 (2)	V11
V12	Second V.F.O.	138	√ EF91	175 (5)	115 (7)	—	V12
V13	Calibrator	4012	√ EK90	250 (5)	90 (6)	2.0 (2)	V13
V14	First I.F. Amplifier	454	√ EF93	190 (5)	65 (6)	0.8 (7)	V14
V15	Calibrator	454	√ EF93	230 (5)	130 (6)	6.0 (7)	V15
V16	Second I.F. Amplifier	454	√ EF93	200 (5)	95 (6)	1.45 (7)	V16
V17	I.F. Output	454	√ EF93	170 (5)	105 (6)	1.35 (7)	V17
V18	A.V.C. and T.C.	140	√ EB91	—	—	28.0 (1)	V18
V19	B.F.O.	138	√ EF91	180 (5)	220 (7)	—	V19
V20	Power Rectifier	1377	GZ34	250 r.m.s. (6)	—	250 (8)	V20
				250 r.m.s. (4)			
V21	Detector and Noise Limiter	140	√ EB91	—	—	—	V21
V22	Audio Output	138	√ EF91	210 (5)	220 (7)	2.1 (2)	V22
V23	A.F. Output	138	√ EF91	210 (5)	220 (7)	2.1 (2)	V23
V24		469	EA76	—	—	—	V24



### 2.3 VALVE CONNECTIONS (North American Version)

Pin No.	6AU6	6SE8	6688	6AS6	6BE6	6BA6	6AL5
1	Grid 1	Anode 2	Cathode	Grid 1	Grid 1	Grid 1	Cathode 1
2	Grid 3 & Screen	Grid 2	Grid 1	Cathode	Cathode & Grid 5	Grid 3 & Screen	Anode 2
3	Heater	Cathode 2	Cathode	Heater	Heater	Heater	Heater
4	Heater	Heater	Heater	Heater	Heater	Heater	Heater
5	Anode	Heater	Heater	Anode	Anode	Anode	Cathode 2
6	Grid 2	Anode 1	I.C.	Grid 2	Grid 2 & Grid 4	Grid 2	Screen
7	Cathode	Grid 1	Anode	Grid 3	Grid 3	Cathode	Anode 1
8	—	Cathode 1	Grid 3 & Screen	—	—	—	—
9	—	Screen	Grid 2	—	—	—	—
Base	B7G	B9A	B9A	B7G	B7A	B7G	B7G




### 2.4 VALVE COMPLEMENT AND TYPICAL D.C. VOLTAGES (North American Version)

<i>Cct. Ref.</i>	<i>Function</i>	<i>Type</i>	<i>Anode</i>	<i>Screen</i>	<i>Cathode</i>	<i>Cct. Ref.</i>
V1	Crystal Oscillator	6AU6	175 (5)	175 (6)	45.0 (7)	V1
V2	Harmonic Generator	6AU6	195 (5)	40.0 (6)	—	V2
V3	R.F. Amplifier	6ES8	190 (1) (2) 100 (6)	—	1.0 (8)	V3
V4	Harmonic Mixer	6AS6	165 (5)	120 (6)	2.0 (2)	V4
V5	First V.F.O.	6AU6	215 (5)	155 (6)	—	V5
V6	37.5 Mc/s Amplifier	6AU6	205 (5)	105 (6)	0.85 (7)	V6
V7	First Mixer	6688	195 (7)	145 (9)	0.86 (1)	V7
V8	37.5 Mc/s Amplifier	6AU6	205 (5)	110 (6)	0.81 (7)	V8
V9	Second Mixer	6688	195 (7)	155 (9)	0.91 (1)	V9
V10	37.5 Mc/s Amplifier	6AU6	210 (5)	115 (6)	0.91 (7)	V10
V11	Third Mixer	6BE6	220 (5)	88 (6)	1.25 (2)	V11
V12	Second V.F.O.	6AU6	170 (5)	105 (6)	—	V12
V13	Calibrator	6BE6	245 (5)	100 (6)	2.05 (2)	V13
V14	First I.F. Amplifier	6BA6	195 (5)	60 (6)	0.75 (7)	V14
V15	Calibrator	6BA6	240 (5)	120 (6)	7.0 (7)	V15
V16	Second I.F. Amplifier	6BA6	195 (5)	95 (6)	1.55 (7)	V16
V17	I.F. Output	6BA6	160 (5)	95 (6)	1.6 (7)	V17
V18	A.V.C. and T.C.	6AL5	—	—	27.5 (1)	V18
V19	B.F.O.	6AU6	190 (5)	150 (6)	—	V19
V21	Detector and Noise Limiter	6AL5	—	—	—	V21
V22	Audio Output	6AQ5	175 (5)	180 (6)	8.0 (2)	V22
V23	Audio Amplifier and A.F. Output	12AT7	220 (1) 110 (6)	—	3.0 (3) 1.65 (8)	V23
V24			—	—	—	V24

Voltages were obtained from a B9A or B7G stand-off valve base using a 20,000Ω/volt meter on the optimum range in each case. Valve pin numbers are indicated in brackets.

The receiver was set as follows:

- System switch to MAN.
- I.F. and A.F. GAIN to MAX.
- No signal i.e. 1st and 2nd v.f.o. off tune.
- LIMITER off.
- B.F.O. off except for checking V19.
- System switch to CAL. in order to check V13 and V15 only.



## VALVE BASE CONNECTIONS

(ALL VALVE HOLDERS VIEWED FROM UNDERSIDE)

FIGURE 4





FIGURE 5



126015

Typical selectivity curves

Fig.6

## SECTION 3

### FAULT DIAGNOSIS

#### 3.1 INTRODUCTION

The following notes and test procedures enable the faulty section of the receiver to be determined with the minimum of delay. Unless otherwise stated the meter on the front panel is used for measuring purposes. This is set to R.F. LEVEL and the reference figure is  $100\mu\text{A}$  for all sensitivity tests.

Since the audio stages of the receiver are conventional and accessible, normal practice will serve to trace any fault which may occur in this section.

#### 3.2 TEST EQUIPMENT REQUIREMENTS

The following test equipment will be required:

- (1) Valve Voltmeter.
- (2) 12pF trimmer capacitor.
- (3) Signal generator.

**Note:** The input capacitance of the valve voltmeter must be padded to 12pF by the trimmer or alternatively by a fixed capacitor. Before the valve or the trimmer or the fixed capacitor can be selected, the input capacitance of the valve voltmeter must be known. If the trimmer is used, this should be connected across a capacitance bridge and set to the required value.

#### 3.3 FAULT DIAGNOSIS

Set the controls on the front panel as follows:—

- R.F. GAIN to max.
- I.F. GAIN to max.
- B.F.O. switch to off.
- LIMITER switch to OFF.
- System switch to MAN.

Remove the valve V12 and crystal XL1 and connect the output of the signal generator via a  $0.1\mu\text{F}$  capacitor to pin 5 (anode) of the valve holder V12.

Set the BANDWIDTH control to 100 c/s and tune the signal generator for maximum indication in the r.f. level meter at 100 kc/s. The sensitivity should be approximately as follows:—

3 kc/s less than $200\mu\text{V}$	} To be within 10dB of sensitivity measured on 3 kc/s position.
100 c/s	
300 c/s	
1.2 kc/s	
6.5 kc/s	
13.0 kc/s	

In the event of the figures above not being realized, the renewal of one or more of the following valves will probably effect an improvement:

- V11 3rd mixer.
- V14 first i.f. amplifier.
- V16 second i.f. amplifier.

Refit the valve V12 and connect the output of the signal generator to test point TP3. Set the BANDWIDTH control to 3 kc/s. Tune the generator for maximum at each of the following kc/s scale settings.

Receiver kc/s scale	Signal generator
100	2.9 Mc/s less than $10\mu\text{V}$
500	2.5 Mc/s less than $10\mu\text{V}$
800	2.2 Mc/s less than $10\mu\text{V}$

The maximum difference between check points should not exceed 3dB. The renewal of V11 or V9 will probably effect an improvement if this figure is not met, providing that the conditions outlined in previous paragraphs have been achieved. If the figures vary by more than 3dB between check points, the 2-3 Mc/s band-pass filter C122, C125, C128, L57, L58 and L59/60 should be carefully re-aligned as detailed under "Alignment Procedures" (Section 5, para. 5.5).

Refit the crystal XL1 and check the 1 Mc/s output (PL3A at the rear of the receiver) with the valve voltmeter to ensure that there is at least 2V output.

Remove the valve V9 and connect the valve voltmeter to test point TP3. Tune the MEGACYCLES dial slowly through each Mc/s point when at least 2V should be indicated on the voltmeter at each point. Absence of drive at this point or a low reading indicates a possible fault in any one of the following valves or the associated circuitry:

V2, V4, V6, V8, V10 and V5.

With V9 and the crystal XL1 removed and the valve voltmeter connected to TP3, connect the output of the signal generator at a frequency of 3.5 Mc/s to the aerial socket. With the AE. RANGE switch set to WIDEBAND and the AE. ATTENUATOR set to MIN, peak the MEGACYCLES tuning at 3 Mc/s for maximum on the valve voltmeter. The input required for 0.5V should be less than 250mV. If this figure cannot be achieved V1 and V7 may have low emission or a fault may exist in the associated circuit.

Low r.f. channel gain may be caused by a failure in the 40 Mc/s band-pass filter. This, however, is extremely unlikely and no attempt should be made to touch this section unless a wobulator is available.

The aerial, r.f. circuits and low-pass filter may be by-passed by feeding in a signal to test point TP2 on the first v.f.o. chassis.

Should the fault be traced to a section where alignment will be affected by servicing, reference should be made to the relevant part in Section 5.

Voltages on valves where the bases are inaccessible are measured by the use of short "stand offs".

## SECTION 4

### REPRESENTATIVE TEST DATA

<i>Signal Input to :</i>	<i>Frequency</i>	<i>Input</i>	<i>Output</i>	<i>Remarks</i>
(a) Grid V22	1,000 c/s	0.3V	50mW in 3Ω	} AUDIO GAIN MAX. A.F. LEVEL MAX. I.F. GAIN MIN. B.F.O. off. LIMITER off.
Grid V23	1,000 c/s	0.35V	10mW in 600Ω (Output to line)	
(b) Grid V16	100 kc/s c.w.	360mV	100μA R.F. level	} B.F.O. off. System Switch MAN. I.F. GAIN MAX. 1 Mc/s crystal removed. Mc/s scale set to 20. BANDWIDTH 3 kc/s.
Grid V14	100 kc/s c.w.	850μV	100μA R.F. level	
Anode Connection of V12 via 0.1μF with valve removed	100 kc/s c.w.	100μV	100μA R.F. level	
(c) Grid of second mixer (TP3)	2.2 Mc/s c.w. 2.5 Mc/s c.w. 2.9 Mc/s c.w.	7μV 7.5μV 7μV	100μA R.F. level 100μA R.F. level 100μA R.F. level	} Image response ( <i>i.e.</i> receiver frequency plus 200 kc/s) should be at least 60dB down.
(d) Aerial input (WIDEBAND)	3.5 Mc/s c.w.	250mV	0.5V at TP2	} WIDEBAND INPUT. AE (ANT.) ATTENUATOR MIN. V5 and V7 removed. Valve voltmeter input shunt- ed to 12pF.
(e) Aerial Input (WIDEBAND)	3.5 Mc/s c.w.	250mV	0.5V at TP3	} WIDEBAND INPUT. AE (ANT.) ATTENUATOR MIN. V5 and V7 replaced. V9 and 1 Mc/s crystal re- moved. Valve voltmeter input shunt- ed to 12pF. MEGACYCLES scale 3.
(f) Grid V10 Grid V8 TP1	37.5 Mc/s c.w.	40mV 25mV 2.8mV	1V at TP3	} V9 and V5 and 1 Mc/s crystal removed. Valve voltmeter input shunt- ed to 12pF.

(g) With the 1 Mc/s crystal in place, the output at plugs PL2 and PL3 should be approximately 2 volts.

(h) The level of the 37.5 Mc/s drive at TP3 should be between 2 and 10 volts at any MEGACYCLE setting.

## SECTION 5

### ALIGNMENT PROCEDURES

#### 5.1 GENERAL

The receiver will, under normal conditions, maintain the factory alignment over an extremely long period of time. Consequently ALL POSSIBILITY OF OTHER CAUSES OF TROUBLE SHOULD BE ELIMINATED BEFORE RE-ALIGNMENT IS CONSIDERED.

If it becomes necessary to re-align any part of the receiver, only a very small angular adjustment of any trimmer should be necessary. The signal generator must have a high degree of frequency resetting accuracy and be very stable.

Unless otherwise stated, the panel-mounted R.F. Level meter is used as the output indicator.

#### 5.2 100 kc/s I.F. STRIP

##### (a) First and Second I.F. Amplifier

Remove the second v.f.o. valve V12. Set the System switch to MAN, the I.F. GAIN to MAX and the meter switch to R.F. LEVEL. Connect the signal generator (100 kc/s c.w.) via a  $0.1\mu\text{F}$  capacitor to the grid of V16 (Pin 1). Adjust C195B to obtain maximum indication on the meter. The output from the generator required to produce  $100\mu\text{A}$  deflection on the meter should be approximately 320mV. Connect the signal generator via a  $0.1\mu\text{F}$  capacitor to the grid of V14 (Pin 1) and connect a  $4.7\text{k}\Omega$  damping resistor across L72. Adjust C179 and C195B to give maximum indication.

Remove the  $4.7\text{k}\Omega$  resistor from L72 and connect it across L73. Adjust C171 for maximum indication. Remove the  $4.7\text{k}\Omega$  resistor. The signal generator output required to produce a  $100\mu\text{A}$  deflection should be approximately  $800\mu\text{V}$ . Tune the signal generator through the passband and note the 'double peak' response. The peak separation should be approximately 9 kc/s and be symmetrical about 100 kc/s. If the peak amplitudes differ, slight re-adjustment of C195B will compensate for this. The 6dB bandwidth should be approximately 14 kc/s.

##### (b) 100 kc/s (L-C) Filter

Remove the second v.f.o. valve V12 and set the controls as in 5.2 (a). Connect the output of the signal generator (100 kc/s) via a  $0.1\mu\text{F}$  capacitor to pin 5 (anode) of V12. Remove the L-C filter can. Locate the two red free-ended leads connected at one end of the trimming capacitors C153 and C158 in the second and third sections of the filter and connect the free ends to their respective  $470\text{k}\Omega$  damping resistor R77 and R80 at the terminal post ends. Replace the filter can. Set the bandwidth to 100 c/s. Tune the signal generator to give maximum indication in the R.F. LEVEL meter then switch to 1.2 kc/s. The frequency of this setting should be within  $\pm 100$  c/s of 100 kc/s. Adjust the trimming capacitors C162, C158, C153 and C147 in this order several times until maximum output is obtained.

Remove the L-C filter can and disconnect the red leads from the terminal post ends of the  $470\text{k}\Omega$  resistors. Replace the filter can. Set the controls of the signal generator for an output of  $225\mu\text{V}$  approximately for  $100\mu\text{A}$  in the R.F. LEVEL meter. Check that the bandwidths agree (approximately) with the following figures:—

—6dB	—66dB	Sensitivity for $100\mu\text{A}$
100 c/s	Less than 1.5 kc/s	$150\mu\text{V}$
300 c/s	Less than 2.0 kc/s	$200\mu\text{V}$
1.2 kc/s	8 kc/s	$225\mu\text{V}$
3.0 kc/s	15 kc/s	$160\mu\text{V}$
6.5 kc/s	20 kc/s	$200\mu\text{V}$
13.0 kc/s	28 kc/s	$350\mu\text{V}$

##### (c) Crystal Filter

Remove the second v.f.o. valve V12 and set the controls as in 5.2 (a). Set the BANDWIDTH switch to 300 c/s. Connect the signal generator via a  $0.1\mu\text{F}$  capacitor to pin 5 (anode) of V12. Tune the signal generator slowly through the pass-band and observe the crystal responses (f1 and f2). Care must be taken as the tuning of these is very sharp. Retune the signal generator to the mean of f1 and f2 and adjust C110 and C148 for maximum output. Reset the signal generator frequency to 100 kc/s and adjust the output to produce a reading of  $100\mu\text{A}$ . Set the generator frequency to 101,025 c/s, increase the output by 66dB and adjust the phasing control C119 to obtain minimum output (i.e. the point of rejection occurs). Increase the generator frequency slowly and ascertain that the meter reading does not exceed  $100\mu\text{A}$ . Slowly decrease the signal frequency until  $100\mu\text{A}$  reading is obtained and check that the frequency is not greater than 100,900 c/s. Tune through the pass-band, adjusting the signal generator output as necessary to avoid meter damage. Note the highest frequency at which a signal generator output equal to that used at 101,025 c/s gives an output of  $100\mu\text{A}$ . This frequency should not be less than 99,100 c/s.

Slowly decrease the signal frequency and ensure that the output does not rise above  $100\mu\text{A}$ . Decrease the generator output by 66dB and re-check the frequency response within the pass-band, re-adjusting C110 and C148 if necessary. Set the signal generator frequency to 100 kc/s and adjust the output for  $100\mu\text{A}$  level. Increase the signal generator output by 6dB and check the bandwidth for  $100\mu\text{A}$  output. The bandwidth should be between 270 and 330 c/s and the mid-position should not deviate from 100 kc/s by more than 25 c/s. The sensitivity should be approximately  $200\mu\text{V}$  for  $100\mu\text{A}$  deflection.

Switch the BANDWIDTH control to 100 c/s. Repeat the procedure with signal generator frequency settings of 100,925 c/s, 100,800 c/s and 99,200 c/s. Adjust the phasing capacitor C118 only. The 6dB bandwidth should be between 80 and 120 c/s, and the deviation from the mean less than 25 c/s. For 100 $\mu$ A output, the input should be approximately 150 $\mu$ A.

Disconnect the signal generator and refit V12.

#### (d) Use of Digital Frequency Meter

The alignment of the i.f. strip and in particular the crystal filter involves the measurement of frequencies to far greater accuracies than those normally obtainable from signal generators. A digital frequency meter should therefore be employed. The equipment should be connected to SK8 or SK9. The exact frequency passing through the circuit will be displayed on the indicator panel. Should the level of output at any time during the alignment procedure be insufficient to drive the frequency meter, the signal generator output can be increased to obtain the frequency check but must be restored to the lower value for level measurements. When such increases are made, the meter on the receiver panel should be switched to A.F. LEVEL to avoid damage.

### 5.3 SECOND V.F.O.

#### (a) Minor Corrections

The variable capacitor has been carefully adjusted and should not be readjusted unless absolutely necessary. Minor corrections can be made as follows:—

- (i) Set the System switch to CAL.
- (ii) Set the KILOCYCLES cursor in line with the MEGACYCLES cursor (*i.e.* central).
- (iii) Ensure that the B.F.O. switch is off.
- (iv) Rotate the I.F. GAIN to MAX.
- (v) Set the BANDWIDTH switch to 3 KC/S.
- (vi) Set the KILOCYCLES scale to zero (0 KC/S) and adjust the capacitor C136 to give zero-beat note in the loudspeaker.  
**Note:** The capacitor C136 is obscured by V16.
- (vii) Set the KILOCYCLES scale to that zero-beat point which is nearest to the 1,000 KC/S position.
- (viii) Lock the drive sprocket.
- (ix) Adjust the position of the film scale to produce correct calibration.  
**Note:** When moving the film scale relative to the sprockets, grip both sides of the film scale in order to create a loop which will allow the film to slide round the drive sprocket; the drive sprocket is on the left when facing the receiver and hence movement of the film scale will have to be to the left.
- (x) Repeat (vi) to (ix) until an adequate degree of accuracy is obtained.

**Important Note:** The tuning slug of L55 has been sealed by the manufacturer and must not be touched under any circumstances.




FIGURE 7



#### (b) Replacement of Ganged Capacitor

The procedure described below should not normally be carried out unless the ganged capacitor is being replaced. Before electrical adjustment, the following mechanical points should be verified :—

- (i) Set the KILOCYCLES scale against the mechanical end stop at the 1,000 kc/s end and check that the ganged capacitor is set as shown in Figure 7.
- (ii) Check that the distance from the cursor to the extreme end of the scale, adjacent to the 1,000 kc/s point, is approximately  $\frac{1}{2}$ -in. Should this distance vary appreciably from  $\frac{1}{2}$ -in., carefully lift the scale from the drive and move the scale round to the required position.
- (iii) Whenever the film scale is replaced, endeavour to re-align by adjusting the film to the correct position before trimming.

The procedure for electrical adjustment is carried out as follows :—

- (iv) Proceed as in 5.3 (a) above.
- (v) Check the calibration of the v.f.o. at 100 kc/s intervals; if the error exceeds 1 kc/s, adjust carefully the two outer plates of the rotor of the oscillator section of the ganged capacitor in order to correct the calibration.

**Note:** The oscillator capacitor C139 is the second section from the rear of the ganged capacitor unit.

#### 5.4 B.F.O.

Set the System switch to the CHECK B.F.O. position. Switch the meter switch to R.F. LEVEL. Switch the b.f.o. on and set the b.f.o. frequency control knob to zero. Adjust C201 as necessary to obtain zero-beat. Observe that the meter reads approximately half f.s.d.

If the b.f.o. frequency control knob has been removed, adjust the frequency capacitor for zero-beat with the identification mark on the shaft uppermost. Replace the knob so that the pointer indicates zero.

#### 5.5 SECOND I.F. CIRCUIT

Set the System switch to MAN. Remove the 1 Mc/s crystal. Set the I.F. GAIN to MAX. Set the METER switch to R.F. LEVEL. Connect the signal generator (c.w. output) to TP3. Alignment frequencies are 2.2 and 2.9 Mc/s which correspond to 800 and 100 kc/s respectively on the KILOCYCLES dial. Adjust C122, C125 and C128 at 100 kc/s and L57, L58 and L59 at 800 kc/s. Repeat as necessary until alignment is correct at both ends of the band. The input required for 100 $\mu$ A meter deflection should be between 5 and 10 $\mu$ V.

#### 5.6 37.5 Mc/s FILTER AND AMPLIFIER

Remove the 1 Mc/s crystal, second mixer valve V9 and the first v.f.o. valve V5. Check that all the screening covers are in place. Connect a suitable valve voltmeter, shunted to 12pF, to TP3. Inject an accurate 37.5 Mc/s signal at TP1. Ensure the valve voltmeter and signal generator leads are short to avoid regeneration. Adjust L50, C90, C81, C72, C63, C55, C45, C35, C24, L28 and L33 in that order, several times, to obtain maximum output. The input required to produce 1V should be approximately 2.5mV. The 6dB bandwidth of the 37.5 Mc/s chain should lie between 229–300 kc/s. The bandwidth at 40dB should not exceed 750 kc/s. The mean of the frequencies corresponding to the 6dB points should not deviate from 37.5 Mc/s by more than 20 kc/s and by more than 25 kc/s at 40dB bandwidth.

C108 is adjusted to avoid interaction between the 37.5 and 40 Mc/s filters and should not normally require further adjustment. Replace the 1 Mc/s crystal, the second mixer and the first v.f.o. valve.

#### 5.7 1 Mc/s CRYSTAL OSCILLATOR

Connect the valve voltmeter to the 1 Mc/s output plug PL2 and adjust L2 for maximum output (2–3V). C2 may be adjusted to 'pull' the crystal to the correct frequency. Adjustment of the crystal frequency should not be attempted unless a standard of accuracy better than one part in 10<sup>7</sup> is available.

#### 5.8 SECOND MIXER DRIVE LEVEL

Remove the second mixer valve V9. Connect the valve voltmeter, shunted to 12pF, to TP3. Tune through each megacycle calibration point and check that the level of each output lies between 2 and 10V. To equalise the drive at 28 and 29 Mc/s carefully adjust C7.

#### 5.9 FIRST V.F.O. CALIBRATION

Slacken off the mechanical end-stop until it is inoperative. Set C76 to maximum capacity and ensure that the calibration mark at the zero end of the MEGACYCLES dial coincides with the cursor. Tighten end-stop after moving the scale free from the stop. Check that the mechanical stops operate before the capacitor end-stops become effective at both ends of the band.

To readjust the first v.f.o. calibration, a heterodyne wavemeter should be employed. This is coupled very loosely to V7 by placing its input lead in the vicinity of the valve base. The 1 Mc/s crystal and V12 should be removed.

Set the wavemeter to 40.5 Mc/s and the MEGACYCLES dial to zero. Adjust L36 for zero-beat. Change the wavemeter setting to 69.5 Mc/s and the MEGACYCLES dial to 29. Adjust C77 for zero-beat. Repeat adjustment as necessary. Check the frequency calibration at 1 Mc/s intervals and ensure that the megacycle positions are reasonably central on the scale markings. Remove the first mixer valve V7 and connect the valve voltmeter, shunted to 12pF, between TP2 and the chassis. Check that the valve voltmeter indicates at least 1.5V over the range. Replace the 1 Mc/s crystal, V12 and V7.

## 5.10 AERIAL CIRCUIT

Remove the first v.f.o. valve V5 and the first mixer valve V7 and set the receiver controls as follows:—

- AE. ATTENUATOR to MIN.
- AE. RANGE Mc/s to 0.5 Mc/s
- System switch to MAN.
- I.F. GAIN to MAX.

Remove the screening cover from around C18A/B and connect a 1 kilohm resistor across the secondary section (C18B rear section). Set the AE. TUNE control to approximately  $\frac{3}{4}$ ths of its travel in a clockwise direction.

Connect the valve voltmeter, shunted to 12pF, between TP2 and chassis. Connect the output of the signal generator to the aerial input socket. Set the generator for a frequency of 0.5 Mc/s.

Remove the top core from the transformer L9 and adjust the primary core for a maximum deflection in the valve voltmeter. (The position of this core should be such that it tunes at a point nearest the bottom of the transformer).

Remove the 1 kilohm resistor from the secondary section and connect it across the primary section of C18.

Refit top core (secondary) and adjust it for a maximum deflection in the valve voltmeter.

Remove the 1 kilohm resistor from the primary of C18.

Reset the signal generator frequency to 1 Mc/s and adjust the AE. TUNE control (C18) for maximum output in the valve voltmeter then adjust the trimmer capacitor C232 for a maximum deflection in the valve voltmeter also check for symmetrical response.

Repeat the above procedure for the AE. RANGE switch settings and frequencies listed below.

AE. RANGE	ALIGNMENT FREQUENCY		INDUCTANCE
	Primary	Secondary	
1-2	1 Mc/s	2 Mc/s	L8
2-4	2 Mc/s	4 Mc/s	L7
4-8	4 Mc/s	8 Mc/s	L6
8-16	8 Mc/s	16 Mc/s	L5
16-30	13 Mc/s (C18 at max.)	30 Mc/s	L4

Maximum voltage input for 0.5 volt output.

AE. RANGE	L.F.	H.F.
0.5-1 Mc/s	6mV	6mV
1-2 Mc/s	7mV	7 mV
2-4 Mc/s	10mV	10mV
4-8 Mc/s	12mV	16mV
8-16 Mc/s	22mV	26mV
16-30 Mc/s	22mV	30mV

## 5.11 CRYSTAL CALIBRATOR

Should no output be obtained from this unit when the System switch is in the CAL position and the KILOCYCLES scale set at a 100 kc/s check point, or if spurious responses are obtained over the kilocycles range, proceed as follows:—

Set the KILOCYCLES scale to a 100 kc/s point and check the tuning of L70 by carefully rotating the core a half-turn either side of the setting. If the signal does not appear, restore the core to its original setting and repeat the check with L75. If the signal is heard, the cores of L70 and L75 should be set to the centre of the range of adjustment over which a clean signal is produced.

Should a major fault be suspected, or if L70 or L75 have been inadvertently misaligned, it will be necessary to remove the unit and make up an extension cable so that the unit may be operated outside the receiver. The crystal calibrator may be aligned as follows:—

Remove V13 and connect the valve voltmeter probe to grid 3 (Pin 7). Inject a 900 kc/s c.w. signal, from the signal generator, at the grid of V15 (Pin 1) and adjust L75 for maximum output. Disconnect the valve voltmeter and the signal generator, replace V13 and remove V15. Connect the signal generator to grid 1 (Pin 1) of V13 and the valve voltmeter to the grid 1 connection (Pin 1) of V15. Set the signal generator to 100 kc/s c.w. and adjust L70 for maximum indication on the valve voltmeter. Disconnect the valve voltmeter and the generator. Replace V15. Connect the coaxial connector to SK2 on the receiver.

The output should be approximately 0.2V measured between Pin 6 of the octal plug and earth.

## 5.12 40 Mc/s FILTER

This filter is over-coupled and cannot be readily aligned without a 40 Mc/s sweep oscillator. Readjustment therefore should not be attempted unless the specially designed test equipment and factory-type alignment jigs are available.

## SECTION 6

### DISMANTLING AND REPLACEMENT PROCEDURES

#### 6.1 UNIT BREAKDOWN

The receiver may be rapidly dismantled to six sub-units as follows:—

1. **Front Panel**
  - (1) Tuning escutcheon.
  - (2) Loudspeaker and escutcheon.
  - (3) Output level meter.
2. **Second Variable Frequency Oscillator**
  - (1) 2-3 Mc/s band-pass filter.
  - (2) Second v.f.o. (V12).
  - (3) Third mixer (V11).
3. **First Variable Frequency Oscillator**
  - (1) R.F. amplifier (V3).
  - (2) First v.f.o. (V5).
  - (3) First mixer (V7).
4. **100 Kc/s I.F. Strip**
  - (1) Beat frequency oscillator (V19).
  - (2) Crystal filter.
  - (3) L-C filter.
  - (4) First and second i.f. amplifiers (V14 and V16).
  - (5) A.V.C. and T.C. stages (V18).
  - (6) Detector and noise limiter (V21).
  - (7) 100 kc/s output (V17).
5. **Crystal Calibrator (V13 and V15).**
6. **Main Chassis**
  - (1) Aerial (antenna) attenuator.
  - (2) Crystal oscillator (V1).
  - (3) Harmonic generator (V2).
  - (4) 30 and 32 Mc/s low-pass filters.
  - (5) 37.5 and 40 Mc/s band-pass filters.
  - (6) Harmonic mixer (V4).
  - (7) The 37.5 Mc/s amplifiers (V6, (V8) and (V10).
  - (8) Second mixer (V9).
  - (9) A.F. output stages (V22) and (V23).
  - (10) Power supplies (V20).

#### 6.2 DISMANTLING AND REPLACEMENT INSTRUCTIONS

1. **Front Panel**
  - (1) Remove all control knobs.
  - (2) Unscrew the eight instrument head panel fixing screws.  
**Note:** The two at the bottom of the front panel, adjacent to the jack sockets are secured to the main chassis with nuts.
  - (3) Carefully withdraw the front panel and unsolder the connections to the meter and speaker switches; alternatively, the number of wires to be unsoldered can be minimised (loudspeaker only) by removing the securing nuts on the SPEAKER and METER switches and also the nuts securing the solder tags on the rear of the meter. The panel may now be completely removed.  
**Note:** When replacing the B.F.O. NOTE control knob, ensure that the identification mark on the shaft is uppermost and that the pointer indicates zero when zero-beat is obtained.
2. **Second Variable Frequency Oscillator**
  - (1) Remove the bottom cover.
  - (2) Unsolder the three connections on the 4-way tag strip, adjacent to the terminal strip, situated in compartment 6 (see illustration 1: Key to Under-chassis Layout).
  - (3) Remove the front panel: see 1 above.
  - (4) Withdraw the Crystal Calibrator Unit by slackening the knurled nuts, disconnecting the coaxial cable and unplugging the unit.
  - (5) Unbolt the cable cleat securing the dial light cable.
  - (6) Unclip the lampholder.
  - (7) Disconnect the coaxial cables.
  - (8) Remove the screws securing the Megacycles dial to the boss and withdraw the dial.  
**Note:** Do not unscrew the boss from the shaft. Unscrew the second v.f.o. cover and the two unit retaining screws (indicated in illustration 7).

- (9) The v.f.o. may now be withdrawn vertically. When servicing this assembly, clean the wormwheel and the split gear on the ganged capacitor shaft with carbontetrachloride, then apply with a brush, to the wormwheel only (illustration 6), a thin coating of Molybdenum Disulphide grease (Rocol "Molypad").

(a) Removal of Kilocycles film scale:—

- (i) Rotate the KILOCYCLES knob to the 1000 KC/S end stop.
- (ii) Remove the front panel:—see 1 above.
- (iii) While firmly holding the two gears situated above the film bobbins, remove the plate carrying the fibre idler gear.
- (iv) Allow the two gears to unwind slowly.
- (v) Unwind the film scale.

(b) To fit a new film scale:—

- (i) Pass the 1000 KC/S end round the drive sprocket and wrap the end round the split pin on the inner bobbin; rotate this bobbin until most of the film scale is wound.
- (ii) Wrap the other end of the film scale round the split pin on the other bobbin, and rotate the bobbin counter-clockwise until the film scale is taut.
- (iii) Wind the gears in opposite directions for  $\frac{3}{4}$  to 1 turn, and while holding the gears under tension re-engage the idler gear.
- (iv) Secure the plate by the two fixing screws.
- (v) To check calibration, see second v.f.o. alignment procedure (Section 5.3).

(c) Ganged Capacitor

**Note:** Refer to the second v.f.o. alignment procedure (Section 5.3) before attempting to replace the ganged capacitor.

- (i) Remove the second v.f.o. from the receiver in accordance with the instructions above.
- (ii) Remove the KILOCYCLES scale.
- (iii) Unscrew the remaining cover plate and the under chassis screen.
- (iv) Unsolder the capacitor connections.
- (v) Remove the drive gear and collet.
- (vi) Unscrew the three fixing screws holding the capacitor to the bracket; ensure that the anti-backlash gears are loaded.

### 3. First Variable Frequency Oscillator

- (1) Remove the front panel, the bottom cover and the screens from compartments 3, 8 and 13. (See illustration 1: Key to Under-Chassis Layout).
- (2) Unsolder the connecting wires from the two turret lugs situated in compartment 3, the leads to the turret lug in compartment 8, the pin connections in compartment 5 and the screened cable in compartment 13.
- (3) Unscrew the three fixing screws on the top of the unit.

(a) To fit a new chain:—

- (i) Take a 63-link length of chain.
- (ii) Hold chain tension sprocket down towards the chassis, and fit new chain round the two chain wheels.
- (iii) Release the tension sprocket ensuring that it holds the chain under tension. See Front Panel instructions regarding refitting of B.F.O. NOTE control knob: Section 6.2.

### 4. 100 Kc/s I.F. Strip

- (1) Remove the left-hand gusset plate adjacent to the unit.
- (2) Unsolder the leads to the 4 and 12-way tag strips and the 100 KC/S OUTPUT plugs.
- (3) Disconnect the coaxial lead to the second v.f.o.
- (4) Remove the six screws securing this unit to the main chassis.

**Note:** Removal of the I.F. GAIN control on the b.f.o. assembly is necessary in order to obtain access to one of the six securing screws.

(a) Beat Frequency Oscillator

- (i) Remove Front Panel.
- (ii) Remove bottom cover.
- (iii) Disconnect leads from I.F. GAIN potentiometer.
- (iv) Remove side plates adjacent to i.f. strip.
- (v) Remove screw securing cable cleat situated adjacent to 150mH choke assembly on underside of i.f. strip.
- (vi) Disconnect red-white lead of b.f.o. cableform from terminal on adjacent 12-way tag strip.
- (vii) Withdraw red-white lead from cableform.
- (viii) Disconnect brown leads from pin 4 of V18 socket.
- (ix) Disconnect yellow leads from pin 7 of V21 socket.
- (x) Remove remaining three 6 B.A. screws and crinkle washers to release b.f.o. assembly from i.f. strip chassis.

### 6.3 VALVE REPLACEMENT


With the exception of V5, replacement of valves will not affect receiver alignment. When V5 is replaced refer to Part 1, Section 5.

## SECTION 7

### ILLUSTRATIONS

	<i>Illustration</i>
Key to Under-Chassis Layout . . . . .	1
Chassis Assembly, Top . . . . .	2
Chassis Assembly, Underside . . . . .	3
Crystal Oscillator and Harmonic Filter System, Underside . . . . .	4
First V.F.O. Unit, Underside . . . . .	5
Second V.F.O. Unit, Front . . . . .	6
Second V.F.O. Unit, Rear . . . . .	7
Second V.F.O. Unit, Underside . . . . .	8
100 kc/s I.F. Strip, Right Side . . . . .	9
100 kc/s I.F. Strip, Left Side . . . . .	10
B.F.O. Unit, Underside . . . . .	11
Crystal Calibrator Unit, Underside . . . . .	12


ILLUSTRATION 1



- 1 100kc/s IF
- 2 SECOND MIXER
- 3 40Mc/s. IF
- 4 HARMONIC FILTER
- 5 FIRST VFO SUPPLY FILTER
- 6 SYSTEM COMPARTMENT
- 7 CRYSTAL OSCILLATOR AND HARMONIC GENERATOR
- 8 HARMONIC MIXER AND 37.5Mc/s. AMPLIFIER
- 9 SUPPLY FILTER FOR 7 & 8
- 10 37.5Mc/s BAND PASS FILTER
- 11 POWER SUPPLIES
- 12 AUDIO STAGES
- 13 AERIAL ATTENUATOR

KEY TO UNDER-CHASSIS LAYOUT

ILLUSTRATION 2




CHASSIS ASSEMBLY (TOP)






ILLUSTRATION 4




CRYSTAL OSCILLATOR AND HARMONIC FILTER SYSTEM (UNDERSIDE)

ILLUSTRATION 5




FIRST VFO UNIT (UNDERSIDE)

ILLUSTRATION 6



SECOND VFO UNIT (FRONT)


ILLUSTRATION 7



⊙ UNIT RETAINING SCREWS


SECOND VFO UNIT (REAR)

ILLUSTRATION 8



SECOND VFO UNIT (UNDERSIDE)


ILLUSTRATION 9



\* FITTED FROM SERIAL No 3737  
 Y FITTED UP TO SERIAL No 3736


100 kc/s I.F. STRIP (RIGHT SIDE)

ILLUSTRATION 10




100 kc/s I.F. STRIP (LEFT SIDE)

ILLUSTRATION 11



BFO UNIT (UNDERSIDE)

ILLUSTRATION 12



CRYSTAL CALIBRATOR UNIT (UNDERSIDE)



## SECTION 8

### LIST OF CIRCUIT COMPONENTS, SUPPLEMENTARY COMPONENTS, SUB-ASSEMBLIES AND SUB-UNITS

- 8.1 Resistors
- 8.2 Potentiometers
- 8.3 Capacitors
- 8.4 Switches
- 8.5 Plugs and Sockets
- 8.6 Valves (British)
- 8.7 Valves (American)
- 8.8 Valve and Crystal Holders
- 8.9 Inductances
- 8.10 Transformers
- 8.11 Rectifier
- 8.12 Loudspeakers
- 8.13 Meters
- 8.14 Crystals
- 8.15 Fuses and Fuseholders
- 8.16 Lamp and Holder
- 8.17 Voltage Selectors
- 8.18 Supplementary Components,  
and Sub-Assemblies
- 8.19 Main Sub-Units

**Joint-Service Numbers**  
**(also known as CCA or NATO Stock Numbers)**

Commercial and private users will note that the above numbers have been included in this section ; these are for assisting Service users in the provisioning of spare components.

Note: It is recommended that users quote the Serial No. of the equipment on all orders for spare parts.

\* Indicates component used in RA.17L Receivers only.

† Indicates component used in RA.17C-12 Receivers only.

### 8.1 RESISTORS

<i>Cct. Ref.</i>	<i>Value</i>	<i>Description</i>	<i>Rating</i>	<i>Tol.</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>
R1	100kΩ	Carbon	$\frac{1}{4}$ W	10%	5905-99-022-3038	Erie 9
R2	100Ω	Carbon	$\frac{1}{4}$ W	10%	022-1110	" 9
R3	150Ω	Carbon	$\frac{1}{4}$ W	10%	022-1131	" 9
R4	100Ω	Carbon	$\frac{1}{4}$ W	10%	022-1110	" 9
R5	150Ω	Carbon	$\frac{1}{4}$ W	10%	022-1131	" 9
R6	4.7kΩ	Carbon	$\frac{1}{2}$ W	10%	022-2090	" 8
R7	150Ω	Carbon	$\frac{1}{4}$ W	10%	022-1131	" 9
R8	150Ω	Carbon	$\frac{1}{4}$ W	10%	022-1131	" 9
R9	10kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2132	" 8
R10	150Ω	Carbon	$\frac{1}{4}$ W	10%	022-1131	" 9
R11	150Ω	Carbon	$\frac{1}{4}$ W	10%	022-1131	" 9
R12	100kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3038	" 9
R13	22kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2173	" 9
R14	150Ω	Carbon	$\frac{1}{4}$ W	10%	022-1131	" 9
R15	100Ω	Carbon	$\frac{1}{4}$ W	10%	022-1110	" 9
R15A	75Ω	Carbon	$\frac{1}{4}$ W	10%	022-3038	" 9
R16	680Ω	Carbon	$\frac{1}{4}$ W	10%	022-1215	" 9
R17	1kΩ	Carbon	$\frac{1}{2}$ W	10%	022-2006	" 8
R18	470Ω	Carbon	$\frac{1}{2}$ W	10%	022-1195	" 8
(Assy. with L20)						
R19	270kΩ	Carbon	$\frac{1}{4}$ W	10%		" 9
R20	1kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2005	" 9
R21	330Ω	Carbon	$\frac{1}{4}$ W	10%	022-1173	" 9
R22*	180Ω	Carbon	$\frac{1}{4}$ W	10%	022-1143	" 9
R22†	470Ω	Carbon	$\frac{1}{4}$ W	10%	022-1143	" 9
R23	82Ω	Carbon	$\frac{1}{4}$ W	10%	022-3029	" 9
R24	10kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2131	" 9
R25	10Ω	Carbon	$\frac{1}{4}$ W	10%	022-1002	" 9
R26	10Ω	Carbon	$\frac{1}{4}$ W	10%	022-1002	" 9
R27	10Ω	Carbon	$\frac{1}{4}$ W	10%	022-1022	" 9
R28	680Ω	Carbon	$\frac{1}{4}$ W	10%	022-1215	" 9
R29*	1kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2005	" 9
R29†	4.7kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2005	" 9
R30	220Ω	Carbon	$\frac{1}{4}$ W	10%	022-1152	" 9
R31	470Ω	Carbon	$\frac{1}{4}$ W	10%	022-1194	" 9
R32	100kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3038	" 9
R32A	100kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3038	" 9
R32B	10kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2131	" 9
R33	10kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2131	" 9
R34	470kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3122	" 9
R35	DELETED					
R36	10Ω	Carbon	$\frac{1}{4}$ W	10%	022-1002	" 9
R37	1kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2005	" 9
R38*	220Ω	Carbon	$\frac{1}{4}$ W	10%	022-1152	" 9
R38†	120Ω	Carbon	$\frac{1}{4}$ W	10%	022-1122	" 9
R39*	1kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2005	" 9
R39†	18kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2164	" 9
R40	10Ω	Carbon	$\frac{1}{4}$ W	10%	022-1002	" 9
R41*	47kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2215	" 9
R41†	10kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2131	" 9
R42	47kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2215	" 9
R43*	2.2kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2047	" 9
R43†	470kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3122	" 9

### 8.1 RESISTORS (continued)

<i>Cct. Ref.</i>	<i>Value</i>	<i>Description</i>	<i>Rating</i>	<i>Tol.</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
R44*	10kΩ	Carbon	$\frac{1}{4}$ W	10%	5905-99-022-2131	Erie	9
R44†	47kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2215	"	9
R45	10Ω	Carbon	$\frac{1}{4}$ W	10%	022-1002	"	9
R46	100kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3038	"	9
R47	56Ω	Carbon	$\frac{1}{4}$ W	10%	022-1080	"	9
R48	10Ω	Carbon	$\frac{1}{4}$ W	10%	022-1002	"	9
R49*	220Ω	Carbon	$\frac{1}{4}$ W	10%	022-1152	"	9
R49†	120Ω	Carbon	$\frac{1}{4}$ W	10%	022-1122	"	9
R50	2·2kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2047	"	9
R51	1kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2005	"	9
R52	15kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2152	"	9
R53	470Ω	Carbon	$\frac{1}{4}$ W	10%	022-1194	"	9
R54	100Ω	Carbon	$\frac{1}{2}$ W	10%	022-1111	"	8
R55	1kΩ	Carbon	$\frac{1}{2}$ W	10%	022-2006	"	8
R56	15kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2152	"	9
R57	10Ω	Carbon	$\frac{1}{4}$ W	10%	022-1002	"	9
R58	470kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3122	"	9
R59	56Ω	Carbon	$\frac{1}{4}$ W	10%	022-1080	"	9
R60*	220Ω	Carbon	$\frac{1}{4}$ W	10%	022-1152	"	9
R60†	102Ω	Carbon	$\frac{1}{4}$ W	10%	022-1122	"	9
R61	470Ω	Carbon	$\frac{1}{4}$ W	10%	022-1194	"	9
R62*	10kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2131	"	9
R62†	47kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2215	"	9
R63	DELETED						
R64	330kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3101	"	9
R65	100kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3038	"	9
R66	1kΩ	Carbon	$\frac{1}{2}$ W	10%	022-2006	"	8
R67	470Ω	Carbon	$\frac{1}{4}$ W	10%	022-1194	"	9
R68	22kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2173	"	9
R69	18kΩ	Carbon	$\frac{1}{2}$ W	10%	022-2165	"	8
R70*	470kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3122	"	9
R70†	82kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3029	"	9
R71	12kΩ	Wirewound	3W	5%	011-3346	Painton	P306
R72	470Ω	Carbon	$\frac{1}{4}$ W	10%	022-1194	Erie	9
R73	470Ω	Carbon	$\frac{1}{4}$ W	10%	022-1194	"	9
R74	150Ω	Carbon	$\frac{1}{4}$ W	10%	022-1131	"	9
R75	8·2kΩ	Carbon	$\frac{1}{2}$ W	10%	022-2123	"	8
R76*	33kΩ	Carbon	$\frac{1}{2}$ W	10%	022-2195	"	8
(Fitted up to Ser. No. 3736)							
R76†	DELETED						
R76A*	82kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3029	"	9
R76A†	47kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2215	"	9
R77	470Ω	Carbon	$\frac{1}{4}$ W	10%	022-3122	"	9
R78	1kΩ	Carbon	$\frac{1}{2}$ W	10%	022-2006	"	8
R79	2·2kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2047	"	8
R80	470kΩ	Carbon	$\frac{1}{4}$ W	10%	022-3122	"	9
R81	2·2kΩ	Carbon	$\frac{1}{2}$ W	10%	022-2048	"	8
R81A	1·5kΩ	Carbon	$\frac{1}{4}$ W	10%		"	9
R81B	10mΩ	Carbon	$\frac{1}{4}$ W	10%		"	9
R81C	10mΩ	Carbon	$\frac{1}{4}$ W	10%		"	9
R82	DELETED						
R83	4·7kΩ	Carbon	$\frac{1}{4}$ W	10%	022-2089	"	9
R84	1MΩ	Carbon	$\frac{1}{4}$ W	10%	022-3164	"	9
R85	220Ω	Carbon	$\frac{1}{4}$ W	10%	022-1152	"	9
R86	22Ω	Carbon	$\frac{1}{4}$ W	10%	022-1026	"	9
R87	120Ω	Carbon	$\frac{1}{4}$ W	10%	022-1122	"	9
R87A	68Ω	Carbon	$\frac{1}{4}$ W	10%	022-1089	"	9
R88	330Ω	Carbon	$\frac{1}{4}$ W	10%	022-1173	"	9
R89	2·2kΩ	Carbon	$\frac{1}{2}$ W	10%	022-2048	"	8

8.1 RESISTORS (continued)

<i>Cct. Ref.</i>	<i>Value</i>	<i>Description</i>	<i>Rating</i>	<i>Tol.</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
R90	4.7kΩ	Carbon	¼W	10%	5905-99-022-2090	Erie	8
R91	4.7kΩ	Carbon	½W	10%	022-2090	"	8
R91A	470kΩ	Carbon	¼W	10%	022-3122	"	9
R92	270kΩ	Carbon	¼W	10%	022-3092	"	9
R93	47kΩ	Carbon	½W	10%	022-2216	"	8
R94	47kΩ	Carbon	½W	10%	022-2216	"	8
R95	100Ω	Carbon	¼W	10%	022-1110	"	9
R96	470kΩ	Carbon	¼W	10%	022-3122	"	9
R97	15kΩ	Carbon	½W	10%	022-2153	"	8
R97A*	39kΩ	Carbon	¼W	10%		"	9
(Fitted from Ser. No. 3737)							
R97A†	39kΩ	Carbon	¼W	10%		"	9
R98	2.2kΩ	Carbon	¼W	10%	022-2047	"	9
R99	22kΩ	Carbon	¼W	10%	022-2173	"	9
R100	22kΩ	Carbon	¼W	10%	022-2173	"	9
R101	120Ω	Carbon	¼W	10%	022-1122	"	9
R102	82kΩ	Carbon	¼W	10%	022-3029	"	9
R103	2.2kΩ	Carbon	¼W	10%	022-2047	"	9
R104	1MΩ	Carbon	¼W	10%	022-3164	"	9
R105	1kΩ	Carbon	¼W	10%	022-2005	"	9
R106	68kΩ	Carbon	½W	10%	022-3018	"	8
R107	2.2kΩ	Carbon	½W	10%	022-2048	"	8
R108	33kΩ	Carbon	½W	10%	022-2195	"	8
R109	4.7kΩ	Carbon	½W	10%	022-2090	"	8
R110	100Ω	Carbon	¼W	10%	022-1110	"	9
R111	2.2kΩ	Carbon	½W	10%	022-2048	"	8
R112	47kΩ	Carbon	¼W	10%	022-2215	"	9
R113	33kΩ	Carbon	½W	10%	022-2195	"	8
R114	100Ω	Carbon	¼W	10%	022-1110	"	9
R115	150Ω	Carbon	¼W	10%	022-1131	"	9
R116	470kΩ	Carbon	¼W	10%	022-3122	"	99
R117	150Ω	Carbon	¼W	10%	022-1131	"	9
R118	2.2MΩ	Carbon	¼W	10%	022-3206	"	9
R119	470kΩ	Carbon	¼W	10%	022-3122	"	9
R119A	10kΩ	Wirewound	10W	5%	011-3088	Zenith	TG214
R120	100kΩ	Carbon	½W	10%	022-3039	Erie	8
R120A	27kΩ	Carbon	¼W	10%	022-2185	"	9
R121	100kΩ	Carbon	½W	10%	022-3039	"	8
R122	6.8kΩ	Carbon	¼W	10%	022-2110	"	9
R123	82kΩ	Carbon	½W	10%	022-3030	"	8
R124	165Ω	Wirewound	10W	5%	972-8311	"	Style X
R125	47kΩ	Carbon	¼W	10%	022-2215	"	9
R126	100Ω	Carbon	¼W	10%	022-1110	"	9
R127	82kΩ	Carbon	¼W	10%	022-3029	"	9
R128	18kΩ	Carbon	¼W	10%	022-2164	"	9
R129	18kΩ	Carbon	¼W	10%	022-2164	"	9
R130	82kΩ	Carbon	¼W	10%	022-3029	"	9
R131	4.7kΩ	Carbon	¼W	10%	022-2089	"	9
R132	1kΩ	Carbon	¼W	10%	022-2005	"	9
R133	4.7kΩ	Carbon	¼W	10%	022-2089	"	9
R133A†	27kΩ	Carbon	¼W	10%	022-2185	"	9
R134	1MΩ	Carbon	¼W	10%	022-3164	"	9
R135	1.2MΩ	Carbon	¼W	10%	022-3176	"	9
R135A†	100kΩ	Carbon	¼W	10%	022-3038	"	9
R136	47Ω	Wirewound	3W	5%	011-3288	Welwyn	AW3115
R136A	8.2kΩ	Carbon	¼W	10%	022-2123	Erie	8
R137	1.5MΩ	Carbon	¼W	10%	022-3185	"	9
R137A*	100kΩ	Carbon	¼W	10%	022-3038	"	9
R137B*	100kΩ	Carbon	¼W	10%	022-3038	"	9

### 8.1 RESISTORS (continued)

<i>Cct. Ref.</i>	<i>Value</i>	<i>Description</i>	<i>Rating</i>	<i>Tol.</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
R138	120Ω	Carbon	¼W	10%	5905-99-022-1122	Erie	9
R138A†	100kΩ	Carbon	½W	10%	022-3039	"	8
R138B†	1·3kΩ	Carbon	3W	5%		Painton	P.306
R139	120Ω	Carbon	¼W	10%	022-1122	Erie	9
R139A†	470kΩ	Carbon	¼W	10%	022-3122	"	9
R140*	220Ω	Carbon	¼W	10%	022-1152	"	9
R140†	270Ω	Carbon	¼W	10%		"	8
R140A†	4·7kΩ	Carbon	¼W	10%		"	16
R140B†	2·2kΩ	Carbon	¼W	10%		"	16
R141*	220Ω	Carbon	¼W	10%	022-1152	"	9
R141†	680Ω	Carbon	¼W			"	9
R142	1·2kΩ	Carbon	¼W	10%	022-2017	"	9
R143	1·2kΩ	Carbon	¼W	10%	022-2017	"	9
R144*	10Ω	Carbon	¼W	10%	022-1002	"	9
R144†	DELETED						
R144A†	10Ω	Carbon	¼W	10%	002-1002	"	9

### 8.2 POTENTIOMETERS

RV1	1kΩ	Wirewound			5905-99-972-8314	Colvern	CLR3001/21
RV2	2MΩ	Composition log/law 1" spindle			940-9134	AB Metals Clarostat	37
RV3	2MΩ	Composition log/law ⅝" spindle, slotted			940-9135	AB Metals Clarostat	37
RV4†	1kΩ	Wirewound				Colvern	CLR1189/155

### 8.3 CAPACITORS

C1	2·7pF	Ceramic	750V	10%	5910-99-911-8271	Erie	P100K
C2	33pF	Trimmer			016-0047	Wingrove & Rogers	C31-01/1
C3	220pF	Silver/Mica	350V	10%	940-9085	Lemco	1106S
C4	14·7pF	Ceramic	750V	10%	011-8301	Erie	N750K
C5	14·7pF	Ceramic	750V	10%	011-8301	"	N750K
C6	14·7pF	Ceramic	750V	10%	011-8301	"	N750K
C7*	10pF	Trimmer			911-4011	Wingrove & Rogers	C32-01
C7†	Piece of twisted wire						
C8	10pF	Ceramic	750V	5%	013-2425	Erie	P100K
C9	100pF	Silver/Mica	350V	10%	911-6929	Lemco	1106S
C10	0·01μF	Paper	400V	20%	011-5827	Hunt	W97/BM21Z
C11	0·005μF	Paper	400V	20%	011-5824	"	W97/BM20Z
C12	14·7pF	Ceramic	750V	10%	011-8301	Erie	N750K
C13	14·7pF	Ceramic	750V	20%	011-8301	"	N750K
C14	0·01μF	Paper	400V	20%	011-5827	Hunt	W97/BM21Z
C15	10pF	Ceramic	750V	5%	013-2425	Erie	P100K
C16	0·01μF	Paper	400V	20%	011-5827	Hunt	W97/BM21Z
C17	0·001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C18A	212pF	Variable (2 gang)				Racal	AD15451
C18B	See C18A						
C18C	6·8pF	Ceramic	750V	5%		Erie	P100K
C19	10pF	Ceramic	750V	5%	011-2425	"	P100K
C20	10pF	Ceramic	750V	5%	011-2425	"	P100K
C21	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C22	33pF	Silver/Mica	350V	5%	911-4291	Lemco	1106S
C23	0·001μF	Ceramic	350V		911-4892	Erie	K3500/AD

### 8.3 CAPACITORS (continued)

<i>Cct. Ref.</i>	<i>Value</i>	<i>Description</i>	<i>Rating</i>	<i>Tol.</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
C24	18pF	Trimmer, with acetate case	1000V		5910-99-972-8322	Oxley	A15/13.2
C25	15pF	Silver/Mica	350V	5%	911-6850	Lemco	1106S
C26	0.05 $\mu$ F	Paper	350V	20%	011-5559	Hunt	W49/B511K
C27	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C28	220pF	Silver/Mica	350V	10%	940-9085	Lemco	1106S
C29	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C30	0.001 $\mu$ F	Ceramic	350V		911-4892	"	K3500/AD
C31	10pF	Ceramic	750V	5%	013-2425	"	P100K
C32	10pF	Ceramic	750V	5%	013-2425	"	P100K
C33	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C34	39pF	Silver/Mica	350V	5%	911-6837	Lemco	1106S
C35	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C36	33pF	Silver/Mica	350V	5%	911-4291	Lemco	1106S
C37	0.001 $\mu$ F	Ceramic	350V	20%	911-4892	Erie	K3500/AD
C38	0.001 $\mu$ F	Ceramic	350V		911-4892	"	K3500/AD
C39	0.1 $\mu$ F	Paper	150V	20%	011-5560	Hunt	W49/B500KY
C40	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C41	0.1 $\mu$ F	Paper	150V	20%	011-5560	Hunt	W49/B500KY
C42	220pF	Silver/Mica	350V	10%	940-9085	Lemco	1106S
C42A	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C43	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C44	39pF	Silver/Mica	350V	5%	911-6837	Lemco	1106S
C45	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C46	33pF	Silver/Mica	350V	5%	911-4291	Lemco	1106S
C47	8.2pF	Ceramic	750V	10%	013-2424	Erie	P100K
C48	0.001 $\mu$ F	Ceramic	350V		911-4892	"	K3500/AD
C49	0.01 $\mu$ F	Paper	400V	20%	011-5827	Hunt	W97/BM21Z
C49A	0.05 $\mu$ F	Paper	350V	20%	011-5559	"	W49/B511K
C50	82pF	Silver/Mica	350V	5%	911-6952	Lemco	1106S
C51	220pF	Silver/Mica	350V	2%	911-6839	"	1106S
C52	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C53	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C54	39pF	Silver/Mica	350V	5%	911-6837	Lemco	1106S
C55	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C56	33pF	Silver/Mica	350V	5%	911-4291	Lemco	1106S
C57	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C58	0.001 $\mu$ F	Ceramic	350V		911-4892	"	K3500/AD
C59	0.001 $\mu$ F	Ceramic	350V		911-4892	"	K3500/AD
C60	0.001 $\mu$ F	Ceramic	350V		911-4892	"	K3500/AD
C61	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C62	39pF	Silver/Mica	350V	5%	911-6837	Lemco	1106S
C63	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C64	33pF	Silver/Mica	350V	5%	911-4291	Lemco	1106S
C65	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C66	0.001 $\mu$ F	Ceramic	350V		911-4892	"	K3500/AD
C67	82pF	Silver/Mica	350V	5%	911-6952	Lemco	1106S
C68	220pF	Silver/Mica	350V	2%	911-6839	"	1106S
C69	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C70	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2

### 8.3 CAPACITORS (continued)

<i>Cat. Ref.</i>	<i>Value</i>	<i>Description</i>	<i>Rating</i>	<i>Tol.</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
C71	39pF	Silver/Mica	350V	5%	5910-99-911-6837	Lemco	1106S
C72	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C73	33pF	Silver/Mica	350V	5%	911-4291	Lemco	1106S
C74	220pF	Silver/Mica	350V	10%	940-9085	"	1106S
C75*	47pF	Ceramic	750V	5%	013-2288	Erie	N750K
C75†	220pF	Silver/Mica	350V	10%	940-9085	Lemco	1106S
C76	100pF	Variable				Wingrove & Rogers	C1601
C77	33pF	Trimmer			016-0047	Wingrove & Rogers	10/012SLF
C78	0.001μF	Ceramic	350V		911-4892	Erie	C31-01/1
C79	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	K3500/AD A15/13.2
C80	39pF	Silver/Mica	350V	5%	911-6837	Lemco	1106S
C81	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C82	33pF	Silver/Mica	350V	5%	911-4291	Lemco	1106S
C83	0.001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C84	0.001μF	Ceramic	350V		911-4892	"	K3500/AD
C85	3.3pF	Ceramic	750V	10%	013-2419	"	P100K
C86	0.001μF	Ceramic	350V		911-4892	"	K3500/AD
C87	0.001μF	Ceramic	350V		911-4892	"	K3500/AD
C88	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C89	33pF	Silver/Mica	350V	5%	911-4291	Lemco	1106S
C90	18pF	Trimmer, with acetate case	1000V		972-8322	Oxley	A15/13.2
C91	15pF	Silver/Mica	350V	±1pF	911-6850	Lemco	1106S
C92	0.001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C93	0.001μF	Ceramic	350V		911-4892	"	K3500/AD
C94	0.001μF	Ceramic	350V		911-4892	"	K3500/AD
C95	0.01μF	Paper	400V	20%	011-5287	Hunt	W97/BM21Z
C95A	0.001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C96	0.001μF	Ceramic	350V		911-4892	"	K3500/AD
C97	0.25μF	Paper	150V	20%	011-5563	Hunt	W49/B501
C98	0.01μF	Paper	400V	20%	011-5827	"	W97/BM21Z
C98A	0.001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C99	0.001μF	Ceramic	350V		911-4892	"	K3500/AD
C100	0.001μF	Ceramic	350V		911-4892	"	K3500/AD
C101	0.05μF	Paper	350V	20%	011-5559	Hunt	W49/B511KZ
C102	0.001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C103	0.01μF	Paper	150V	20%	011-5560	Hunt	W49/B500KY
C104	0.001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C105	0.1μF	Paper	400V	20%	011-5827	Hunt	W97/BM21Z
C106	0.001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C107	220pF	Silver/Mica	350V	10%	940-9085	Lemco	1106S
C108	33pF	Trimmer			016-0047	Wingrove & Rogers	C31-01/1
C109	220pF	Silver/Mica	350V	2%	911-6839	Lemco	1106S
C110	33pF	Trimmer			016-0047	Wingrove & Rogers	C31-01/1
C111	0.001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C112	0.01μF	Paper	400V	20%	011-5827	Hunt	W97/BM21Z
C113	27pF	Ceramic	350V	5%	013-2279	Lemco	1106S
C114	0.001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C115	0.001μF	Ceramic	350V		911-4892	"	K3500/AD
C116	33pF	Silver/Mica (Assy. with L52)	350V	5%	911-4291	Lemco	1106S



### 8.3 CAPACITORS (continued)

<i>Cct. Ref.</i>	<i>Value</i>	<i>Description</i>	<i>Rating</i>	<i>Tol.</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
C117	0.01 $\mu$ F	Paper	400V	20%	5910-99-011-5827	Hunt	W97/BM21Z
C118	9.3pF	Diff. trimmer			972-8321	Oxley	Mini trimmer
C119	9.3pF	Diff. trimmer			972-8321	"	Mini trimmer
C120	DELETED						
C121	220pF	Silver/Mica	350V	2%	911-6839	Lemco	1106S
C122	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65
C123	SEE C139						
C124	220pF	Silver/Mica	350V	2%	911-6839	Lemco	1106S
C125	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65
C126	SEE C139						
C127	150pF	Silver/Mica	350V	2%	972-9056	Lemco	1006S
C127A	0.01 $\mu$ F	Paper	400V	20%	011-5827	Hunt	W97/BM21Z
C128	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65
C129	SEE C139						
C130	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C130A	0.01 $\mu$ F	Paper	400V	20%	011-5827	Hunt	W97/BM21Z
C131	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C132	0.001 $\mu$ F	Ceramic	350V		911-4892	"	K3500/AD
C133	0.001 $\mu$ F	Ceramic	350V		911-4892	"	K3500/AD
C134	2.2pF	Ceramic	750V	$\pm 25$ pF	972-8959	"	N750K
C135	0.1 $\mu$ F	Paper	350V	20%	011-5562	Hunt	W49/B512KZ
C136	50pF	Trimmer			016-0004	Wingrove & Rogers	C8-03
C137	270pF	Silver/Mica	350V	5%		Johnson Matthey	C22R
C138	DELETED						
C139	443pF	Variable air (4 Gang)			972-8958	Wingrove & Rogers	C60-04/1
C140	0.05 $\mu$ F	Paper	350V	20%	011-5559	Hunt	W49/B511KZ
C141	0.05 $\mu$ F	Paper	350V	20%	011-5559	"	W49/B511KZ
C142	0.01 $\mu$ F	Paper	400V	20%	011-5827	"	W97/BM21Z
C143	220pF	Silver/Mica	350V	5%	911-6954	Lemco	1106S
C144*	10pF	Silver/Mica	350V	$\pm 1$ pF		"	1106S
C144†	22pF	Silver/Mica	350V	$\pm 1$ pF		"	1106S
C145	6800pF	Silver/Mica	350V	5%	972-8310	Hunt	L4/37S
C146	270pF	Silver/Mica	350V	5%	972-9629	Lemco	1106S
C146A	100pF	Ceramic	350V	5%	972-8700	"	316N750
C147	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65
C148	70pF	Trimmer, 12 vane with acetate case			972-8320	"	A7/65
C149	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C150	0.1 $\mu$ F	Paper	150V	20%	011-5560	Hunt	W49/B500KY
C151	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C152	290pF	Silver/Mica	350V	5%	972-6180	Lemco	1106S
C152A	100pF	Ceramic	750V	5%	972-8700	"	316N750
C153	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65
C154	0.25 $\mu$ F	Paper	150V	20%	011-5563	Hunt	W49/B501KZ
C155	0.05 $\mu$ F	Paper	350V	20%	011-5559	"	W49/B511KZ
C156	0.01 $\mu$ F	Paper	400V	20%	011-5827	"	W97/BM21Z
C157	290pF	Silver/Mica	350V	5%	972-6180	Lemco	1106S
C157A	100pF	Ceramic	750V	5%	972-8700	"	316N750
C158	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65

### 8.3 CAPACITORS (continued)

<i>Cct. Ref.</i>	<i>Value</i>	<i>Description</i>	<i>Rating</i>	<i>Tol.</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
C159	0.05 $\mu$ F	Paper	350V	20%	5910-99-011-5559	Hunt	W49/B511KZ
C159A	0.1 $\mu$ F	Paper	150V	20%	011-5560	"	W49/B500KY
C159B	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C160	0.05 $\mu$ F	Paper	350V	20%	011-5559	Hunt	W49/B511KZ
C161	290pF	Silver/Mica	350V	5%	972-6180	Lemco	1106S
C161A	100pF	Ceramic	750V	5%	972-8700	"	316N750
C162	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65
C163	0.05 $\mu$ F	Paper	350V	20%	011-5559	Hunt	W49/B511KZ
C164	330pF	Silver/Mica	350V	10%	911-6930	Lemco	1106S
C165	0.05 $\mu$ F	Paper	350V	20%	011-5559	Hunt	W49/B511KZ
C166	0.05 $\mu$ F	Paper	350V	20%	011-5559	"	W49/B511KZ
C167	470pF	Silver/Mica	350V	5%	972-8962	Lemco	1106S
C168	10pF	Ceramic	750V	5%	013-2425	Erie	P100K
C169	0.1 $\mu$ F	Paper	150V	20%	011-5560	Hunt	W49/B500KY
C170	2700pF	Silver/Mica	350V	5%	972-8309	"	L4/37S
C170A	33pF	Silver/Mica	350V	5%	911-4291	Lemco	1106S
C171	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65
C172	120pF	Silver/Mica	350V	5%	972-8960	Lemco	1106S
C173	0.1 $\mu$ F	Paper	150V	20%	011-5560	Hunt	W49/B500KY
C174	0.05 $\mu$ F	Paper	350V	20%	011-5559	"	W49/B511KZ
C175	33pF	Ceramic	750V	5%	013-2282	Erie	N750K
C176	0.1 $\mu$ F	Paper	150V	20%	011-5560	Hunt	W49/B500KY
C177	100pF	Silver/Mica	350V	10%	911-6929	Lemco	1106S
C178	10pF	Ceramic	750V	5%	013-2425	Erie	P100K
C179	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65
C180	100pF	Silver/Mica	350V	5%	911-6953	Lemco	1106S
C181	0.05 $\mu$ F	Paper	350V	20%	011-5559	Hunt	W49/B511KZ
C182	0.1 $\mu$ F	Paper	150V	20%	011-5560	"	W49/B500KY
C183	0.05 $\mu$ F	Paper	350V	20%	011-5559	"	W49/B511KZ
V184	0.05 $\mu$ F	Paper	350V	20%	011-5559	"	W49/B511KZ
C185	0.1 $\mu$ F	Paper	150V	20%	011-5560	"	W49/B500KY
C186	0.05 $\mu$ F	Paper	350V	20%	011-5559	"	W49/B511KZ
C187	0.05 $\mu$ F	Paper	350V	20%	011-5559	"	W49/B511KZ
C188	0.05 $\mu$ F	Paper	350V	20%	011-5559	"	W49/B511KZ
C188A	1 $\mu$ F		150V	20%	011-5569	"	W49/B503KY
C189	0.01 $\mu$ F	Paper	400V	20%	011-5827	"	W49/BM21Z
C190	0.1 $\mu$ F	Paper	150V	20%	011-5560	"	W49/B500KY
C191	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65
C192	390pF	Silver/Mica	350V	5%	911-6943	Lemco	1106S
C193	100pF	Ceramic	750V	10%	011-2300	Erie	N750L
C193A	0.001 $\mu$ F	Ceramic	350V		911-4892	"	K3500/AD
C194	0.1 $\mu$ F	Paper	150V	20%	011-5560	Hunt	W49/B500KY
C194A	0.001 $\mu$ F	Ceramic	350V		911-4892	Erie	K3500/AD
C195	0.1 $\mu$ F	Paper	350V	20%	011-5562	Hunt	W49/B512KZ
C195A	390pF	Silver/Mica	350V	5%	911-6943	Lemco	1106S
C195B	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65
C196	0.5 $\mu$ F	Paper	150V	20%	011-5566	Hunt	W49/B502KY
C197	100 $\mu$ F	Electrolytic	50V		014-5515	"	L37/1 85° C JF104
C198	32+32 $\mu$ F	Electrolytic (see C206)	350V		972-8308	Plessey	CE818
C199	220pF	Silver/Mica	350V	5%	911-6954	Lemco	1106S
C200	50pF	Variable				Racal	AD.15051
C201	70pF	Trimmer, 12 vane with acetate case			972-8320	Oxley	A7/65

### 8.3 CAPACITORS (continued)

<i>Cct. Ref.</i>	<i>Value</i>	<i>Description</i>	<i>Rating</i>	<i>Tol.</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
C202	39pF	Silver/Mica	350V	±2%	5910-99-911-6837	Lemco	1106S
C203	22pF	Ceramic	750V	5%	011-2776	Erie	N750K
C204	0·1μF	Paper	150V	20%	011-5560	Hunt	W49/B500KY
C204A†	0·001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C205	0·001μF	Ceramic	350V		911-4892	"	K3500/AD
C206	SEE C198						
C207	0·05μF	Paper	350V	20%	011-5559	Hunt	W49/B511KZ
C208	0·05μF	Paper	350V	20%	011-5559	"	W49/B511KZ
C208A†	0·01μF	Paper	400V	20%	011-5827	"	BM21Z
C209	330pF	Silver/Mica	350V	10%	911-6930	Lemco	1106S
C210	330pF	Silver/Mica	350V	10%	911-6930	"	1106S
C211	330pF	Silver/Mica	350V	10%	911-6930	"	1106S
C212	0·1μF	Paper	150V	20%	011-5560	Hunt	W49/B500KY
C213	0·1μF	Paper	150V	20%	011-5560	"	W49/B500KY
C214	0·1μF	Paper	350V	20%	011-5562	"	W49/B512KZ
C215	47pF	Ceramic	750V	5%	013-2288	Erie	N750K
C216	0·01μF	Paper	400V	20%	011-5827	Hunt	W97/BM21Z
C217	0·1μF	Paper	150V	20%	011-5560	"	W49/B500KY
C217A†	0·01μF	Silver/Ceramic	750V	20%	972-8307	Lemco	420K
C218	0·01μF	Paper	400V	20%	011-5827	Hunt	W97/BM21Z
C218A*	56pF	Silver/Mica	350V	10%		Lemco	1106S
C218A†	33pF	Silver/Mica	350V	10%		"	1106S
C218B*	100pF	Silver/Mica	350V	10%	911-6929	"	1106S
C218B†	68pF	Silver/Mica	350V	10%		"	1106S
C219*	560pF	Ceramic	500V	20%		Erie	K120051A
C219†	0·001μF	Ceramic	350V		911-4892	"	K3500/AD
C220	560pF	Ceramic	500V	20%		"	K120051A
C220A†	0·1μF	Paper	150V	20%	011-5560	Hunt	W49/B500K
C221*	0·001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C221†	0·01μF	Paper	350V	20%	011-5827	Hunt	W97/BM21Z
C221A†	8μF	Electrolytic	350V	85° C		Plessey	CE502/1
C222	50μF	Electrolytic	12V		014-5200	"	CE102/2
C222A†	0·001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C222B†	0·05μF	Paper	350V	20%	011-5559	Hunt	W49/B511KZ
C223*	0·001μF	Ceramic	350V		911-4892	Erie	K3500/AD
C223†	DELETED						
C223A*	0·1μF	Paper	150V	20%	011-5560	Hunt	W49/B500KY
C223A†	DELETED						
C224	0·01μF	Silver/Ceramic	750V	20%	972-8307	Lemco	420K
C225	0·01μF	Silver/Ceramic	750V	20%	972-8307	"	420K
C226	82pF	Silver/Ceramic	750V	5%	972-9990	FEC	316N750
C227	82pF	Silver/Ceramic	750V	5%	972-9990	"	316N750
C228	82pF	Silver/Ceramic	750V	5%	972-9990	"	316N750
C229	82pF	Silver/Ceramic	750V	5%	972-9990	"	316N750
C230	82pF	Silver/Ceramic	750V	5%	972-9990	"	316N750
C231	82pF	Silver/Ceramic	750V	5%	972-9990	"	316N750
C232 to C237	22pF	Trimmer				Mullard	AC2002/22

### 8.4 SWITCHES

S1	Aerial Attenuator	5930-99-920-6716	Racal	BSW10834
S2	Frequency Selection		"	BSW13953
S3	Crystal Filter	972-8852	"	SW7
S4	100 kc/s Filter		"	SW8-9-BSW 15208
S5	System Switch	972-8851	"	SW6
S6	A.V.C.	972-8848	"	SW3
S7	B.F.O. (DPCO)	051-0554	NSF	—
S8	Noise Limiter (DPCO)	051-0554	"	—

#### 8.4 SWITCHES (continued)

<i>Cct. Ref.</i>	<i>Description</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>
S9*	Meter (DPCO)	5930-99-051-0554	NSF —
S9†	Meter (3PCO)		Racal SW63
S10	Mains (DPCO)	051-0554	NSF —
S11	Speaker (DPCO)	051-0554	" —

#### 8.5 PLUGS AND SOCKETS

PL1*	Aerial input	5935-99-054-0101	Films & Eqpts. —
PL1†	Aerial input		PL259
SK1*	Aerial input	054-9028	" " —
SK1†	Aerial input		" " SO239
PL2*	1 Mc/s output	054-0151	Power Controls —
PL2†	1 Mc/s output		Amphenol UG260B/U
SK2*	1 Mc/s Crystal calibrator	054-0155	Power Controls —
SK2†	1 Mc/s Crystal calibrator		Amphenol UG1094/U
PL3*	1 Mc/s output	054-1051	Power Controls —
PL3†	1 Mc/s output		Amphenol UG260B/U
PL3A*	1 Mc/s output	054-0152	Power Controls —
SK3*	RA.37 output	054-0155	" " —
SK3†	RA.37 output		Amphenol UG1094/U
SK3A†	1 Mc/s output		UG910/U
PL4*	2-3 Mc/s B.P. filter input	054-0151	Power Controls —
PL4†	2-3 Mc/s B.P. filter input		Amphenol UG260B/U
SK4*	2-3 Mc/s B.P. filter input	054-0155	Power Controls —
SK4†	2-3 Mc/s B.P. filter input		Amphenol UG1094/U
PL5*	RA.37 input	054-0152	Power Controls —
PL5†	Fitted on RA.37 Converter		
SK5†	RA.37 input		Amphenol UG910/U
PL6*	Crystal filter input	054-0151	Power Controls —
PL6†	Crystal filter input		Amphenol UG260B/U
SK6*	Crystal filter input	054-0155	Power Controls —
SK6†	Crystal filter input		Amphenol UG1094/U
PL7	Crystal calibrator input	940-8342	McMurdo C8/USP
SK7	Crystal calibrator input	054-0101	" X8/U
PL8*	100 kc/s i.f. output	054-0101	Films & Eqpts. —
PL8†	100 kc/s i.f. output	940-1839	" " PL259
SK8*	100 kc/s i.f. output	054-9028	" " —
SK8†	100 kc/s i.f. output	940-1837	" " SO239
PL9*	100 kc/s i.f. output	054-0101	" " —
PL9†	100 kc/s i.f. output	940-1839	" " PL259
SK9*	100 kc/s i.f. output	054-9028	" " —
SK9†	100 kc/s i.f. output	940-1837	" " SO239
PL10*	Mains input Mk. IV fixed 3-pin	056-0060	Plessey CZ48993
SK10*	Mains input Mk. IV free 3-pin	056-0100	" CZ49015
SK11†	2nd v.f.o. output		Amphenol UG1094/U
PL11*	2nd v.f.o. output	054-0151	Power Controls —
	Socket accessories set		Plessey CZ108051
JK1*	Headphone Jack	940-9312	Shipton AP61492A
JK1†	Jack		Bulgin J19
JK2*	Headphone Jack	940-9312	Shipton AP61492A
JK2†	Jack		Bulgin J19
†	Headphone Jack Plug		MIL-P-642A PJ.005B
*	Headphone Jack Plug		G.P.O. Type 316

### 8.6 VALVES (British)

<i>Cct. Ref.</i>	<i>Description</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>
V1	Pentode	CV138	EF91
V2	Pentode	CV138	EF91
V3	Double-Triode	CV5531	ECC189
V4	Pentode	CV2209	6F33
V5	Pentode	CV138	EF91
V6	Pentode	CV138	EF91
V7	Pentode	CV3998	E180F
V8	Pentode	CV138	EF91
V9	Pentode	CV3998	E180F
V10	Pentode	CV138	EF91
V11	Heptode	CV4012	6BE6W
V12	Pentode	CV138	EF91
V13	Heptode	CV4012	6BE6W
V14	Pentode	CV454	EF93
V15	Pentode	CV454	EF93
V16	Pentode	CV454	EF93
V17	Pentode	CV454	EF93
V18	Double-Diode	CV140	EB91
V19	Pentode	CV138	EF91
V20	F.W. Rectifier	CV1337	GZ34
V21	Double-Diode	CV140	EB91
V22	Pentode	CV138	EF91
V23	Pentode	CV138	EF91
V24	Diode	CV469	EA76

### 8.7 VALVES (American)

V1	Pentode	CV2524	6AU6
V2	Pentode	CV2524	6AU6
V3	Double-Triode		6ES8/ECC189
V4	Pentode	CV2522	6AS6
V5	Pentode	CV2524	6AU6
V6	Pentode	CV2524	6AU6
V7	Pentode	CV3998	6688/E180F
V8	Pentode	CV2524	6AU6
V9	Pentode	CV3998	6688/E180F
V10	Pentode	CV2524	6AU6
V11	Heptode	CV4012	6BE6W
V12	Pentode	CV2524	6AU6
V13	Heptode	CV4012	6BE6W
V14	Pentode	CV454	6BA6
V15	Pentode	CV454	6BA6
V16	Pentode	CV454	6BA6
V17	Pentode	CV454	6BA6
V18	Double-Diode	CV283	6AL5
V19	Pentode	CV2524	6AU6
V20	DELETED		
V21	Double-Diode	CV283	6AL5
V22	Output-Tetrode	CV1862	6AQ5
V23	Double triode	CV455	12AT7
V24	Diode	CV469	5704/EA76

(lifted from Ser. No. 3737)

### 8.8 VALVE AND CRYSTAL HOLDERS

XL1*	Crystal Holder	5935-99-911-6489	McMurdo	X2/UB
XL2, XL3	Valve Holder	5935-99-056-0127	"	"
XL5 and XL6	Screening Can	5960-99-056-3005	"	"
XL1 to XL3†	Crystal Holder		"	X2/UB
XL5 and XL6†				

### 8.8 VALVE AND CRYSTAL HOLDERS (continued)

<i>Cat. Ref.</i>	<i>Description</i>	<i>Joint Service No.</i>	<i>Manufacturer Type Type or Drawing No.</i>	
V1 and V2	Valve Holder	5935-99-056-0127	McMurdo	—
V2	Screening Can	5960-99-056-3003	"	—
V3	Valve Holder	5935-99-056-0131	"	—
	Screening Can	5960-99-056-3007	"	—
V4*	Valve Holder	5935-99-056-0127	"	—
*	Screening Can	5960-99-056-3003	"	—
V4†	Valve Holder	5935-99-056-0127	"	—
†	Screening Can	5960-99-056-0145	"	—
V5 and V6	Valve Holder	5935-99-056-0127	"	—
V6	Screening Can	5960-99-056-3003	"	—
V7	Valve Holder	5935-99-056-0131	"	—
	Screening Can	5960-99-056-0146	"	—
V8	Valve Holder	5935-99-056-0127	"	—
	Screening Can	5960-99-056-3003	"	—
V9	Valve Holder	5935-99-056-0131	"	—
	Screening Can	5960-99-056-0146	"	—
V10 to V19	Valve Holder	5935-99-056-0127	"	—
V19	Screening Can	5960-99-056-3003	"	—
V20*	Valve Holder	5935-99-056-0149	"	—
	Valve Retainer		"	X8/U
V20†	DELETED		Electrothermal	VR10
V21	Valve Holder	5935-99-056-0127	McMurdo	—
	Screening Can	5960-99-056-3003	"	—
V22*	Valve Holder	5935-99-056-0127	"	—
	Screening Can	5960-99-056-3003	"	—
V22†	Valve Holder	5935-99-056-0127	"	—
	Screening Can	5906-99-056-3005	"	—
V23*	Valve Holder	5935-99-056-0127	"	—
	Screening Can	5960-99-056-3003	"	—
V23†	Valve Holder	5935-99-056-0131	"	—
	Screening Can	5960-99-056-3007	"	—
V24	Diode Retaining Clip		Sealectro	B-B0147

### 8.9 INDUCTANCES

L1	0-30 Mc/s filter			
L2	Crystal anode coil	5950-99-972-9552	Racal	BD4586
L3	Common assembly with L1	5950-99-972-9565	"	AA4768
L4*	Aerial Tuning		"	BA14099
L4†	Coil Assembly 16-30 Mc/s		"	BA14986
L5*	Aerial Tuning		"	BA14988
L5†	Coil Assembly 8-16 Mcs.		"	BA14985
L6*	Aerial Tuning		"	BA14097
L6†	Coil Assembly 4-8 Mc/s		"	BA14984
L7*	Aerial Tuning		"	BA14096
L7†	Coil Assembly 2-4 Mc/s		"	BA14983
L8*	Aerial Tuning		"	BA14095
L8†	Coil Assembly 1-2 Mc/s		"	BA14982
L9*	Aerial Tuning		"	BA14094
L9†	Coil Assembly 0.5-1 Mc/s		"	BA14981
L10	Common assembly with L1		"	
L11	Common assembly with L1		"	
L12	Common assembly with L1		"	
L13*	Harmonic filter		"	
L13†	Filter Detail Assembly	5950-99-972-9553	"	AD4589
L14	Common assembly with L13		"	AD13715
L15	Common assembly with L1			
L16	Common assembly with L13			
L17	Common assembly with L1			

## 8.9 INDUCTANCES (continued)

<i>Cct. Ref.</i>	<i>Description</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
L18	Common assembly with L13			
L19	Common assembly with L13			
L20	First V.F.O. anode coil (assy. with R18)	5950-99-972-9577	Racal	AA4780
L21	Common assembly with L13			
L22	Common assembly with L13			
L23	40 Mc/s filter	5950-99-972-9560	"	AA4761
L24	37.5 Mc/s filter	972-9554	"	AA4632
L25	40 Mc/s filter	972-9560	"	AA4761
L26	37.5 Mc/s filter	972-9554	"	AA4632
L27*	R.F. Amplifier anode coil	972-9558	"	AA4759
L27†	Coil assembly R.F. Amp. anode		"	AA13759
L28*	37.5 Mc/s mixer anode	972-9562	"	AA4763
L28†	Coil assembly 37 Mc/s mixer anode		"	AA13762
L29	40 Mc/s filter	972-9560	"	AA4761
L30	37.5 Mc/s filter	972-9554	"	AA4632
L31	40 Mc/s filter	972-9560	"	AA4761
L32	37.5 Mc/s filter	972-9554	"	AA4632
L33*	37.5 Mc/s amplifier anode	972-9562	"	AA4763
L33†	Coil Assy. 37 Mc/s Amp. Anode		"	AA13762
L34	40 Mc/s filter	972-9560	"	AA4761
L35	37.5 Mc/s filter	972-9554	"	AA4632
L36*	First V.F.O.	972-9556	"	AD4667
L36†	Coil Assy. First V.F.O.		"	AA13734
L37	40 Mc/s filter	972-9560	"	AA4761
L38	37.5 Mc/s filter	972-9554	"	AA4632
L39	40 Mc/s filter	972-9560	"	AA4761
L40	37.5 Mc/s filter	972-9554	"	AA4632
L41	40 Mc/s filter	972-9560	"	AA4761
L42	37.5 Mc/s filter	972-9554	"	AA4632
L43	Choke	972-8084	Bulgin	Q602/AS9197
L44	Filter coil	972-9555	Racal	AA4655
L45	Choke	972-8084	Bulgin	Q602/AS9197
L46	Filter coil	972-9555	Racal	AA4655
L47	Crystal input transformer	972-9568	"	AA4771
L48	Crystal input transformer	972-9568	"	AA4771
L49	Crystal input transformer	972-9568	"	AA4771
L50	37.5 Mc/s tapped anode coil	972-9569	"	AA4772
L51*	Second mixer anode choke 10 Mc/s	972-9550	"	AA4765
L51†	Second mixer anode choke 10 Mc/s		"	AA13764
L52*	Second mixer trap 37.5 Mc/s	972-9549	"	AA4764
L52†	Second mixer trap 37.5 Mc/s (Assy. with C116)		"	AA13763
L53*	Filter	972-9559	"	AA4760
L53†	Filter coil assembly		"	AA13760
L54*	Filter	972-9559	"	AA4760
L54†	Filter coil assembly		"	AA13760
L55*	Coil Assy. with R70 and C144	972-9551	"	BA10906L
L55†	Coil Assy. with R70 and C144		"	BA13850
L56	Choke	972-8084	Bulgin	Q602/AS9197
L57*	2-3 Mc/s band-pass filter	972-9563	Racal	AA4766
L57†	Coil Assy. 2-3 Mc/s		"	AA13765
L58*	2-3 Mc/s band-pass filter	972-9563	"	AA4766
L58†	Coil Assy. 2-3 Mc/s		"	AA13765
L59*	2-3 Mc/s B.P. Filter Transformer	972-9564	"	AA4767
L59†	Transformer Assy. 2-3 Mc/s		"	AA13766
L60	Common assembly with L59			
L61*	First L-C filter stage		"	BA14987
L61†	First L-C filter stage		"	BA15576

## 8.9 INDUCTANCES (continued)

<i>Cct. Ref.</i>	<i>Description</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
L62	Common assembly with L61			
L63*	Second L-C filter stage		Racal	AA14988
L63†	Second L-C filter stage		"	AA15577
L64	Common assembly with L63			
L65	Choke	5950-99-972-8084	Bulgin	Q602/AS9197
L66	Filter coil	972-9555	Racal	AA4655
L67*	Third L-C filter stage		"	AA14988
L67†	Third L-C filter stage		"	AA15577
L68	Common assembly with L67			
L69	0.1 Mc/s coupling coil	5950-99-972-9574	"	AA4777
L70	Common assembly with L69	972-9574	"	AA4777
L71*	Final L-C filter stage	972-9578	"	BA4843
L71†	Final L-C filter stage		"	BA13820
L72*	100 kc/s i.f. first stage		"	pt. of BA10892
L73*				
L74*				
L72†	100 kc/s i.f. first stage		"	pt. of BA15585
L73†				
L74†				
L75	0.9 Mc/s anode coil	5950-99-972-9576	"	AA4779
L76*	I.F. output		"	pt. of BA4783
L76†	I.F. output Transformer assy.		"	pt. of BA13819
L77*	100 kc/s i.f. final stage		"	pt. of BA4942
L78*				
L79*				
L77†	100 kc/s i.f. final stage		"	pt. of BA13822
L78†				
L79†				
L80*	Smoothing choke	5950-99-972-8943	"	T1081
L80†	Smoothing choke		"	BT15422
L81*	150mH choke	972-9561	"	pt. of AA4762
L81†	150mH choke		"	AA13761
L82	B.F.O.		"	AA14150
L83	Filter coil (Aerial)	911-0554	"	AA10420
L84	Filter coil (Aerial)	911-0554	"	AA10420
L85	Filter coil (Aerial)	911-0554	"	AA10420
L86*	R.F. choke	972-8084	Bulgin	Q602/AS9197
	(fitted from Ser. No. 3737)			
L86†	R.F. choke	972-0884	"	Q602/AS9197

## 8.10 TRANSFORMERS

T1*	Mains	5950-99-911-6456	Racal	T1078
T1†	Mains		"	BT15421
			(Canadian Atlas Trans. Co. Ltd.)	
T2*	Audio Output	911-6455	Racal	T1079
T2†	Audio Output		"	BT15423
			(Canadian Atlas Trans. Co. Ltd.)	
T3*	A.F. Line Output	911-6454	Racal	T1080
T3†	A.F. Line Output		"	BT15424
			(Canadian Atlas Trans. Co. Ltd.)	

## 8.11 RECTIFIERS

MR1	Meter Rectifier	6130-99-943-6183	S.E.I. Ltd.	1mA.
MR8*	Germanium Diode		G.E.C.	GEX54
	(fitted up to Ser. No. 3736)			



## 8.12 LOUDSPEAKERS

<i>Cct. Ref.</i>	<i>Description</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
*	2½" P.M. 3Ω	5965-99-972-9307	Goodmans	T24/201/3
†	2¼" sq. 3Ω		Racal	AD15398
			N.A. ref. Marsland Eng. Ltd.	Model LS.201

## 8.13 METERS

M1*	200 microamp F.S.D.	6625-99-943-6523	Ernest Turner	W909 (with AD4868f Scale)
M1†	200 microamp		Racal	AD15397
			N.A. ref. Stark Electronic Instruments	Type MR26W200

## 8.14 CRYSTALS

XL1*	1 Mc/s ±0.005%	ZDK 1000 kc/s	Racal	BD 7822
XL1†	1 Mc/s ±0.005%		"	BD15378
			C. R. Snelgrove Co. Ltd.	
XL2*	100,036 c/s ±0.005%	5955-99-972-9799	Racal	BD7929
XL2†	100,036 c/s ±0.005%		"	BD15373
			C. R. Snelgrove Co. Ltd.	
XL3*	100,110 c/s ±0.005%	5955-99-972-9801	Racal	BD7931
XL3†	100,110 c/s ±0.005%		"	BD15372
			C. R. Snelgrove Co. Ltd.	
XL4	DELETED			
XL5*	99,964 c/s ±0.005%	5955-99-972-9800	Racal	BD7930
XL5†	99,964 c/s ±0.005%		"	BD15371
			C. R. Snelgrove Co. Ltd.	
XL6*	99,890 c/s ±0.005%	5955-99-972-9802	Racal	BD7932
XL6†	99,890 c/s ±0.005%		"	BD15369
			C. R. Snelgrove Co. Ltd.	

## 8.15 FUSES AND FUSEHOLDERS

F1	Mains Fuse, 2A	5920-99-059-0110	Belling Lee	L/1055
	Mains Fuseholder	5920-99-059-0100	" "	L/356
F2*	HT Fuse, 350mA, size 00	5920-99-972-7902	" "	L/562
	HT Fuseholder	5950-99-059-0170	" "	L/575
F2†	Fuse anti surge 250mA	5920-99-059-0100	" "	L338
	Fuseholder	5920-99-059-0100	" "	L356

## 8.16 LAMP AND HOLDER

ILP1	Mains indicating 8V 1.6W Lampholder	6240-99-995-1201 6520-99-943-6863		M.E.S.11mm Rd. M.E.S.5S
------	----------------------------------------	--------------------------------------	--	----------------------------

## 8.17 VOLTAGE SELECTORS

*Voltage selector socket with plug	5935-99-911-0472	Racal	AD11999A&B
*Voltage selector plug	5935-99-911-0472	"	AD11999/A
*Voltage selector socket		"	AD11999/B


## 8.18 SUPPLEMENTARY COMPONENTS AND SUB-ASSEMBLIES

Audio Output Terminal Block (12-way)	5940-99-943-8586	Carr Fastener	Series 77/903/12
H.T. Adaptor Terminal Block (2-way)	5940-99-943-8587	" "	Series 77/903/2M
Knobs, tuning (Mc/s and kc/s)	5355-99-943-4816	Racal	BD6781

8.18 SUPPLEMENTARY COMPONENTS AND SUB-ASSEMBLIES (continued)

<i>Cct. Ref.</i>	<i>Description</i>	<i>Joint Service No.</i>	<i>Manufacturer and Type or Drawing No.</i>	
	Knobs, control (AE. TUNE and I.F. GAIN)	5355-99-943-4818	Racal	AA6817
	Knobs, control (A.V.C. and A.F. GAIN)	5355-99-943-4819	"	AA6742
	*Knobs, control (AE. ATT., AE. RANGE, BANDWIDTH and System)		"	AA15472
	†Knobs, control (METER, ANT. ATT. and ANT. RANGE, BANDWIDTH and System)		"	BA13828
	Knob, control (B.F.O.)		"	AD13592
	Skirt (B.F.O. knob)		"	AD15049
	*Knob, tuning lock	5355-99-943-4820	"	AD6762
	†Knob, tuning lock		"	AD13784
	Chain (63 links)	4010-99-911-0581	"	AD4641
	Escutcheon, tuning with windows	5820-99-911-0550	"	BA12009
	*Escutcheon, loudspeaker	5965-99-972-9121	"	AD4848
	†Escutcheon, loudspeaker		"	AD13771
	Slider (kc/s tuning)	5355-99-943-5043	"	AD4568
	Clip and pointer assy. (kc/s tuning)	5355-99-943-5020	"	AA4566
	Film scale	5820-99-943-5022	"	BD9562
	*Cable, UR70	5355-99-6145-100298	"	CA10828/46
	†Cable, UR70	5355-99-6145-100298	"	CA13876/46
	*Trimming tool (AD7955)	5120-99-911-0558	"	DA4500/65
	†Trimming tool (AD7955)	5120-99-911-0558	"	DA13971/65
	*Allen Key $\frac{1}{16}$ " A.F.	5120-99-910-6085	"	DA4500/66
	†Allen Key $\frac{1}{16}$ " A.F.	5120-99-910-6058	"	DA13971/66
	*Allen Key $\frac{3}{16}$ " A.F.		"	DA4500/67
	†Allen Key $\frac{3}{16}$ " A.F.		"	DA13971/67
	*Allen Key 0.050" A.F.	5120-99-910-6057	"	DA4500/69
	†Allen Key 0.050" A.F.		"	DA13971/69
	Cabinet	5957-99-972-8566	"	DA15476
	Cover assembly	5820-99-943-5048	"	CA4640
	Baseplate		"	BD4580
	*Gusset Assembly R.H.	5820-99-943-5021	"	BA4508
	†Gusset Assembly R.H.		"	BA13803
	*Gusset Assembly L.H.	5820-99-943-5049	"	BA4508
	†Gusset Assembly L.H.		"	BA13802
	Screen Assembly (37.5 Mc/s Filter—long)	5999-99-972-8946	"	BA4602
	Screen Assembly (37.5 Mc/s Filter—short)	5999-99-972-8947	"	BA4603
	Screen Assembly (2nd mixer)	5999-99-972-8948	"	BA4604
	Screen Assembly (40 Mc/s Filter—long)	5999-99-972-8949	"	BA4605
	Screen Assembly (40 Mc/s Filter—short)	5999-99-972-8950	"	BA4606
	Screen Assembly (Harm. Gen.)	5999-99-972-8951	"	BA4560
	Screen Assembly (Ae. Att. Sw.)	5999-99-972-8952	"	AA4755
	*Screen Assembly (1st v.f.o.)	5999-99-972-8944	"	CA4582L
	†Screen Assembly (1st v.f.o.)		"	CA13832
	*Screen Assembly (2nd v.f.o.)	5999-99-972-8945	"	BA4581L
	†Screen Assembly (2nd v.f.o.)		"	BA13805
	*First I.F.T. assembly		"	BA10892L
	†First I.F.T. assembly		"	BA15585C12
	*Final I.F.T. assembly	5999-99-940-3480	"	BA4942L
	†Final I.F.T. assembly		"	BA13822C12
	*I.F. O/P T. assembly	5999-99-940-3482	"	BA4783L

XL2-7	VII-VI2	V13	V14	V15	V16	V17	V18	V19-V20 V21	V22-V23	VALVES & CRYSTALS
R65	C140	R80	R85	R90	R95	R100	R105	R110	R115	RESISTORS
C120-125-130	C135	C145-150	C155	C160	C165	C170	C175	C180-185	C190	CAPACITORS
L55	L60	L65	L70	L75	L80	L85	L90	L95	L100	INDUCTANCES & TRANSFORMERS
S3B	S3C	S4A	S4C	S4D	S4E	S5A-C	S6	S5D	S5E	SWITCHES
PL4-SK4	PL5	PL6	SK2	SK7	PL8-9	SK8-9	RV1	SS7	S7	MISCELLANEOUS



**NOTES**


- ALL RESISTORS ARE 1/4 WATT RATING UNLESS OTHERWISE STATED
- CAPACITOR VALUES ONE OR DECIMAL ARE MF.D. UNLESS OTHERWISE STATED
- CAPACITOR VALUES GREATER THAN ONE ARE MMFD. UNLESS OTHERWISE STATED
- C123 C126 C129 C139 ARE GANGED
- S1A & S1B ARE GANGED
- S2A, B, C & D ARE GANGED
- S3A, B, C & S4A, B, C, D ARE GANGED
- S5A, B, C, D, E & S5F ARE GANGED

DRG. No. **EC. 4500/2L**

1/15/56	2/1/56	3/1/56	4/1/56	5/1/56	6/1/56	7/1/56	8/1/56	9/1/56	10/1/56
DRN.	ENR	CHK'D.	APP'D.	DATE	DATE	DATE	DATE	DATE	DATE
RACAL ENGINEERING LTD. BRACKNELL, BERKS, ENGLAND.									<b>So2159</b>


RECEIVER TYPE RA17L

XL1	VI	V2	V3-V4	V5-V6	V7-V8	V9-V10	XL2-7
	R5	R15	R20	R25	R35	R45	R65
	C1	C5-10	C15	C20	C25	C30	C35-40
	L1	L5-10	L15	L20	L25	L30	L35
S2A	S1A	S2B	S1B	S2D	S2C	S3A	S3B
	PL1-SK1	PL2	PL3	TP1	TP2	TP3	PL4-SK4
							PL5
							C105
							C110-115
							C120-125-130
							L45
							L50
							L55
							L60
							S3C



RECEIVE

R50	R55	C95	L45	S5A	Y9-V10	XL2-7	VII-V12	V13	V14	V15	V16	V17	V18	V19-V20	V21	V22-V23	R140	R144	VALVES & CRYSTALS
C105	C110-113	C120-125-130	C135	L55	L60	S3C	S4A	S4C	S4D	S4E	S5A-C	S6	S5D	S5E	L82	T1	C220	C225	RESISTORS
L41	L42	L43	L44	L46	L47	L48	L49	L50	L51	L52	L53	L54	L55	L56	L57	L58	L59	L60	CAPACITORS
L61	L62	L63	L64	L65	L66	L67	L68	L69	L70	L71	L72	L73	L74	L75	L76	L77	L78	L79	INDUCTANCES & TRANSFORMERS
S3B	S3D	S3E	S3F	S3G	S3H	S3I	S3J	S3K	S3L	S3M	S3N	S3O	S3P	S3Q	S3R	S3S	S3T	S3U	SWITCHES
PL4-SK4	PL5	PL6	SK2	PL7-SK7	PL8-9	SK8-9	RVI	S5F	S7	S8-9	RV2-3	F1	JK1-2	PL10	MISCELLANEOUS				



**NOTES**

- 1 ALL RESISTORS ARE 1/4 WATT RATING UNLESS OTHERWISE STATED
- 2 CAPACITOR VALUES ONE OR DECIMAL ARE MFD. UNLESS OTHERWISE STATED
- 3 CAPACITOR VALUES GREATER THAN ONE ARE MMFD UNLESS OTHERWISE STATED
- 4 C123 C126 C129 C139 ARE GANGED
- 5 S1A & S1B ARE GANGED
- 6 S2A, B, C & D ARE GANGED
- 7 S3A, B, C & S4A, B, C, D ARE GANGED
- 8 S5A, B, C, D, E & S5F ARE GANGED

DRG. No. **EC. 4500/2L**


DRN. E.A.	CHK'D.	APP'D.	DATE
			20.10.50

RACAL ENGINEERING LTD.  
BRACKNELL, BERKS, ENGLAND.

**So2159**

RECEIVER TYPE RA17L

XL1	VI	V2	V3-V4	V5-V6	V7-V8	V9-V10	XL2-7	VII-V12																
R5	R10	R15	R20	R25	R30	R35	R40	R45	R50	R55	R60	R65	R70	R75										
C1	C5-10	C15	C20	C25	C30	C35-40	C45-50	C55	C60	C65	C70	C75	C80-84	C90	C95	C100	C105	C110-115	C120-125	C130	C135	C140	C145-150	C155
L1	L5-10	L15	L20	L25	L30	L35	L40	L45	L50	L55	L60	L65	L70	L75										
S2A	S1A	S2B	S1B	S2D	S2C	TP1	TP2	L40	L40	C95	C100	L45	C105	C110-115	C120-125	C130	C135	C140	C145-150	C155				
PL1-SK1	PL2	PL3	TP1	TP2	SSA	TP3	PL4-SK4	PL5	S3C	S4A	PL6	SK2	PL7											



RECEIVER TYPE RA17L