

Service documentation

Receiver type series EKD 500

EKD 511/type 1340.42 A1

EKD 512/type 1340.42 A2

Volume 1

To go with this:

Service documentation 1340.042-91700 Su 02, Vol. 2

We reserve the right to make modifications to the construction and design which serve the improvement and development of our equipment without prior notice.

Order-No. of the Service documentation 1340.042-91700 Su 02

Edition 2/1989

Volume 1

<u>Contents</u>	<u>Page</u>
1. General remarks	5
2. Test equipment and auxiliary testing means	7
3. Hints for dismounting and mounting	9
4. Hints for troubleshooting	11
5. Localization of the faulty subassembly and reestablishment of the functionability of the receiver by subassembly exchange	15
5.1. Check "power supply section"	17
5.2. Check "control unit"	18
5.3. Check "frequency processing"	21
5.4. Check "signal path"	23
6. Repair of the faulty subassembly	26
6.1. Power supply section 1340.039-01500	27
6.1.1. Input and output values	27
6.1.2. Measuring values within the power supply section	28
6.1.3. Troubleshooting table	30
6.2. Control unit 1340.041-01401	34
6.2.1. Function principle	34
6.2.2. Test and check arrangements	37
6.2.3. Repair sequence "local operation"	38
6.2.4. Repair sequence operation "external"	39
6.2.5. Control computer	40
6.2.6. Input-output logic	42
6.2.7. Keyboard	44
6.2.8. Digital display	47
6.2.9. Register and interface	48
6.3. Frequency processing	55
6.3.1. Troubleshooting sequence	55
6.3.2. Frequency processing - outline	56
6.3.3. Phase-lock loop 1 (PLL1)	58
6.3.4. Oscillator 1	60
6.3.5. Frequency divider 1	64
6.3.6. Oscillator 3 (PLL3)	66

<u>Contents</u>	<u>Page</u>
6.3.7. Phase-lock loop 2 (PLL2)	70
6.3.8. Oscillator 2	72
6.3.9. Frequency divider 2	76
6.4. Signal path	78
6.4.1. Check or correction of levelling	78
6.4.1.1. Basic amplification "signal path 1"	78
6.4.1.2. Control volume "signal path 1"	78
6.4.1.3. Mixer - symmetry	78
6.4.1.4. Basic amplification "signal path 1 and 2"	79
6.4.1.5. Levelling "A3E"	79
6.4.1.6. Changing AF line levels (max +6 dBm)	79
6.4.1.7. Balancing "control synchronism/channel A and B, manual control"	79
6.4.1.8. Balancing "automatic control/channel A and B"	80
6.4.1.9. Check "control synchronism/channel A and B, automatic control"	80
6.4.1.10. Adjustment "control start/control element 1" (mixer 1)	80
6.4.1.11. Adjustment "trigger - control amplifier"	80
6.4.1.12. Adjustment "short-time detector"	81
6.4.1.13. Balancing "display E "	81
6.4.2. Signal path 1, 1340.041-01311 or -01312	82
6.4.2.1. Preselector 1, 1340.041-01351	83
Preselector 2, 1340.041-01352	
6.4.2.2. Mixer 1, 1340.041-01353	87
Mixer 2, 1340.041-01354	
6.4.3. Signal path 2, 1340.041-01321 or -01322	88
6.4.3.1. Carrier oscillator 1340.037-01355	90
6.4.3.2. IF2/A, 1340.041-01357 or -01367	95
IF2/B, 1340.041-01356 or -01366	
6.4.3.3. Demodulator and AF section, 1340.039-01358	96
6.5. F1B-demodulator, 1340.041-01258	98
6.5.1. Check "input signal"	98
6.5.2. Check "input band-pass"	98
6.5.3. Check "limiter amplifier"	98

<u>Contents</u>	<u>Page</u>
6.4.5. Check "PLL"	98
6.5.5. Check "changeover switch for low passes 100/600 Bd"	99
6.5.6. Check "amplifier"	99
6.5.7. Check "evaluator circuit"	99
6.5.8. Check "line current for teleprinter"	99
6.5.9. Check "holding and capture range of PLL"	99
7. Measuring the main parameters	101
7.1. Frequency accuracy	101
7.1.1. Measuring and correcting with standard test conditions	101
7.1.2. Check and correction on service conditions	101
7.2. Sensitivity	103
7.3. Amplification control	106
8. Components selected by the manufacturer	109
List of terms translated	110

1. General remarks

For carrying out repair work on receivers of series EKD 500, the following unit-specific documentation is required:

- Equipment documentation series EKD 500 1340.042-91700 Eu 02 (specification, operation, maintenance) forming part of every unit supply.
- Service documentation series EKD 500 1340.042-91700 Su 02
 - Volume 1: Repair instructions
 - Volume 2: Outline of subassemblies
 - Functional diagram
 - Circuit diagrams
 - Complementation drawings

Attention!

When performing service work adhere to the safety instructions especially to those concerning

- * earthing of the unit to be repaired
- * work on open units

Repair work is only to be carried out by authorized and particularly instructed specialists being well acquainted with the analogue and digital integrated circuit engineering as well as with the work of electronic units.

Any person meeting these demands will be able to repair every subassembly.

Reestablishment of troublefree functioning of the receiver can be performed through

- * detecting and replacing the faulty subassembly (Section 5)
- * repairing the faulty subassembly (Section 6)

In case of fault indication (F1 to F4) during ROM test (A5), the complete printed circuit "Control computer" (contained in spare part list E9) is to be replaced.

The spare part assortment offered by the manufacturer is to be taken from the spare part lists which are supplied on special request.

Spare part list E1: mechanical and electrical wear parts.

Spare part list E7: complete spare subassemblies (cassettes, control unit, power supply section)

Spare part list E9: stock spares for unit-specific spare parts

Capacitors, resistors, diodes, transistors, and integrated circuits required for repair work can also be procured from other manufacturers. It is to be observed that the electrical and mechanical values are equivalent. Component replacement on the double-clad pc boards requires utmost care when soldering on the plated-through holes.

If the requirements for subassembly repair are not met, it is recommended to exchange the entire subassemblies and have them repaired in a service workshop.

Performing repair work on the basis of this service documentation requires the test equipment and auxiliary testing means listed below. In the following, the abridged designation of the instruments is used; e.g. RF generator: P4.

- P1 Counting frequency meter
 $f_e \approx 120 \text{ MHz}$
 $\Delta f/f \approx 1 \cdot 10^{-7}$
 $U_e \approx 50 \text{ mV}$
- P2 RF-mV meter with RF
measuring head and
50 ohm load
 $f = 10 \text{ kHz to } 200 \text{ MHz}$
 $U_e = 3 \text{ mV to } 10 \text{ V}$
- P3 AF-mV meter
(2x)
 $f = 5 \text{ Hz to } 200 \text{ kHz}$
 $U_e = 15 \text{ mV to } 5 \text{ V}$
 $R_e \approx 100 \text{ kohm/V}$
- P4 RF generator
 $f = 10 \text{ kHz to } 30 \text{ MHz}$
 $R_i = 75 \text{ ohm}$
 $\text{emf} = 1 \text{ } \mu\text{V to } 3 \text{ V}$
unmodulated/modulated
 $1000 \text{ Hz m} = 0.3$
- P5 Double-beam oscilloscope
 $f_e \approx 50 \text{ MHz}$
- P6 Single-beam oscilloscope
 $f_E \approx 10 \text{ MHz}$
- P7 Wobble oscillator with
display unit and probe
 $f = 100 \text{ kHz to } 200 \text{ MHz}$
- P8 Multimeter
 $R_i \approx 100 \text{ kohm/V}$
- P9 Digital voltmeter
 $U_e \approx 30 \text{ V dc}$

P 10	Tone oscillator	
	$f = 300 \text{ Hz to } 6000 \text{ Hz}$	
	$R_1 = 20 \text{ ohm}$	
	$U_a = 2 \text{ mV to } 1 \text{ V}$	
P 11	Mains control transformer	0 to 250 V/6 A
P 12	Line tester	
P 13	Test plug 'substitution - control unit'	Test cable set 1340.042-01601 (cf. equipment documentation 1340.042-01700 Eu 02 Section I 6)
	1340.042-01602	
P 14	Adapter cable 'input-output logic'	
	1340.042-01603	
P 15	Connection adapter 'control unit'	
	1340.042-01604	
RF cable (BNC-50 ohm) 2 pcs. 1340.037-01124		contained in the accessories 1340.037-10001
RF adapter 33 TGL 200-380		
		Z1 02 (4)

3. Dismounting and mounting

Pull the mains plug before starting dismounting. Loosen the red-ring marked screws provided below the handle of the plug-in. Withdraw the plug-in out of the rack by pressing the laterally arranged latches inwards.

Attention! Place the plug-in directly next to the casing and separate the BNC plug of the aerial cable from the plug-in.

After pulling the mains plug, the electric connection between the plug-in and the casing can be reestablished by means of the 30-core or 8-core adapter cable contained in the accessories.

Upon loosening the 8 screws marked with a red ring located on the right plug-in wall, the power supply section can be withdrawn upwards and connected again with the plug-in via the 16-core adapter cable contained in the accessories. An extractor, forming part of the accessories, (drwg.-No. 1340.037-02823) can be used for this purpose.

For cassette exchange, slacken per cassette 2 wing nuts provided on the rear wall of the plug-in and 2 hexagon screws (SW 8) on the front.

The front plate can be swung down by 90° thus providing access to the connections of all control elements as well as to the cassette terminals by only loosening the two screws located next to the plug-in handles.

For exchanging the "control unit" (with the front plate swung down by 90°), slacken both controls " " (13) and "changeover switch for LED row" (2) as well as the 4 fastening screws. After removing the two plug-and-socket connections X1022 and X1023 the subassembly can be lifted out.

The defective control elements

- * regulator "volume" (4)
- * regulator "RF/AF amplification" (6)
- * regulator "A1/pitch" (5)
- * changeover switch/monitoring channel (3)
- * unit switch ON/OFF (1)

can only be replaced with the "control unit" taken out of the receiver.

Access to all components of the cassettes is provided after loosening the 4 wing screws, swivelling out the two outer cassettes and unscrewing the 4 inner lids (with the pressed-in fastening points).

When a pc board is to be exchanged, take the respective cassette out of the casing and unscrew both lids. On the soldering side, slacken the 4 hexagon nuts by means of a socket wrench (7 mm). On the complementation side, remove the probably existing connections to the adjacent circuit.

The pc board can be withdrawn to the rear.

For carrying out repair work on the inner side of the rear wall of the casing, loosen the 4 hexagon nuts of the rear wall and the earth connections provided on the right inner side of the casing. Then, the rear wall of the casing can be removed.

Mounting is carried out in the reverse order.

4. Hints on troubleshooting

In case of faulty operation, fault localization is necessary for aimed repair work.

The sequence is the following:

- External fault sources in the incoming and outgoing cables are to be excluded by checking.
- Exclude wrong operation of the receiver.
- If a total breakdown is present, check the fuse link in the receiver plug-in (equipment documentation EKD 500, section III.6.1.).
- Check the functionability of the receiver (equipment documentation EKD 500, Section III.5.).
- Reestablish the functionability of the receiver by:
 - . detecting and replacing the faulty subassembly (Section 5 of this service documentation)
 - Recondition: Spare subassembly according to the
 spare part list 1340.042-00001 E7
 - . replacing the faulty component
(fault detection acc. to Section 6 of this service documentation)
- Marking of subassemblies:

All subassemblies are marked - in addition to the drwg.-No. - (referred to the electric components) with two-digit numbers. (viz. subassembly survey 1340.042-00001 U 02 (3))
- Marking of components:

All components are marked with four- (five)- digit numbers. The two first digits correspond with the code number of the sub-assembly.


Example: V04 in the circuit diagram 'mixer 1' ≡ V3304
 L01 in the circuit diagram 'oscillator 2' ≡ L2501

When ordering spare parts, these four-(five)- digit numbers are to be indicated.

- Marking of subassemblies in printed circuits:

Code No.	Subassembly/printed circuit	Drwg.-No.
00	Casing	1340.042-01001
	DC filter	1340.042-01022
10	<u>Plug-in</u>	1340.041-00001
20	<u>Frequency processing</u> *)	1340.041-01211
21	Oscillator 1	1340.037-01251
22	Frequency divider 1	1340.037-01252
23	Oscillator 3	1340.039-01253
205	<u>Frequency processing</u> *)	1340.041-01221
24	Reference frequency	1340.037-01254
25	Oscillator 2	1340.037-01255
26	Frequency divider 2	1340.037-01256
28	F1 demodulator	1340.041-01258
30	<u>Signal path 1</u> *)	1340.041-01311 (EKD 511) 1340.041-01312 (EKD 512)
31	Preselector 1	1340.037-01351
32	Preselector 2	1340.041-01352
33	Mixer 1	1340.041-01353
34	Mixer 2	1340.041-01354
305	<u>Signal path 2</u> *)	1340.041-01321 (EKD 511) 1340.041-01322 (EKD 512)
35	Carrier oscillator	1340.037-01355
36	IF2/B	1340.041-01356 (EKD 511) 1340.041-01366 (EKD 512)
37	IF2/A	1340.041-01357 (EKD 511) 1340.041-01367 (EKD 512)
38	Demodulator and AF section	1340.039-01358
40	<u>Control unit</u> *)	1340.041-01401
41	Diode board	1340.041-01451
42	Transistor board	1340.041-01452
43	Input-output logic	1340.041-01453
44	Control computer	1340.041-01454
45	Register and interface	1340.041-01455
46	Display	1340.041-01456
47	Keyboard, complete	1340.041-01402
50	<u>Power supply section</u> *)	1340.039-01500
51	Transverter	1340.039-01551

*) Spare subassemblies according to spare part list E7.



86-029a

Figure 1
Plug-in with the front plate swung down

Restoration of the faulty subassembly and reestablishment of the functionability of the receiver by subassembly exchange

To make service work easier and to reduce the outage times of the receiver, we recommend to replace entire subassemblies. For this purpose, the manufacturer of the equipment offers spare subassemblies according to the spare part list E7.

Variant	EKD 511	EKD 512
Spare subassembly	1340.042-01871 E7	1340.042-01872 E7
Frequency processing 1	1340.041-01211	1340.041-01211
Frequency processing 2	1340.041-01221	1340.041-01221
Signal path 1	1340.041-01311	1340.041-01312
Signal path 2	1340.041-01321	1340.041-01322
Control unit	1340.041-01401	1340.041-01401
Power supply section	1340.039-01500	1340.039-01500

Attention!

The cassettes of receiver EKD 500 and of EKD 300 are not interchangeable.

The Power supply sections of receiver EKD 500 and EKD 300 can be exchanged with each other.

Subassembly exchange requires no readjustment for the functionability of the receiver.

Sections 6.1. to 6.5. contain hints on readjustment in order to minimize tolerances.

In case that the fault symptoms detected during functional check (carried out in accordance with Section III/5) did not result in localization of the faulty subassembly, checks on the receiver plug-in outside the casing are necessary.

. Attention! Pull mains plug before taking the plug-in out of the casing.

. Establish electric connections between casing and plug-in via the 30-core adapter cable (contained in the accessories). For checks via interfaces EXT and EXP, connect additionally the 8-core adapter cable.

. Dismounting and mounting according to Section 3.

. For all checks mentioned in Section 5 opening the cassette lids is not necessary.




Figure 3

Troubleshooting and reestablishment
of unit function

The undermentioned remarks serve to detect the faulty subassembly with only a few test means.

1. Check 'power supply section'

5.1.1. Measuring of the output voltages with digital voltmeter (P9)

	Test point	Correction with
+18 V $\pm$ 0.2 V	X1001/A7, B7	R 5213
+ 5 V $\pm$ 0.1 V	X1003/A1, B1	R 5217
+22 V $\pm$ 2 V	X1003/A7, B7	-
-12 V $\pm$ 0.1 V	X1003/A5, B5	R 5114

5.1.2. In case of voltage breakdowns

+18 V, +5 V, +22V, -12 V: P 1001 and P 1002

+18 V, +5 V, +22V: F 5101

For battery operation: battery cable
fuse

} to be
checked

For localizing short-circuits in the subassemblies, the cassettes are to be withdrawn one after the other.

5.1.3. In case of faulty power supply section

- replacement by spare part subassembly
(Pay attention to the correct voltage adjustment
(X 5002) or
- repair according to Section 6.1.

5.2. Check 'control unit'

5.2.1. When the functional check of the receiver (equipment documentation Section III/5) proved the control unit being faulty

- fault recognition by control test A1 to A5
- no correspondence between operation and display

the following has to be carried out:

- replacement by spare subassembly
(required readjustment: tolerance minimization for receiving level display;
balance R 45145, R 45146, R 45148, R 45147 according to Section 6.2.) or
- repair in accordance with Section 6.2.


5.2.2. Functional breakdown of the receiver although operation and display correspond with each other

- Possible fault reasons:

- Register and interface - output faulty
- Frequency processing faulty
- Signal path faulty

- Fault delimitation by substitution of the control unit by test plug pair P 13

— (Drwg.-No. 1340.042-01602)



- The test result supplies other hints on possible fault sources: 'control unit'

'frequency processing1' and '2'

'signal path 1' and '2'

unscrew front plate fastening and swing front plate down by 90°.

Separate terminal sockets X 1022 and X 1023 from the control unit and connect them with test plug pair P 13.

Changeover switch at P 13 to position 

according to EKD adjustment

13 E 0.00

GC 1, SEL 0

i.e.: PLL2: $f_2/100 = 400 \text{ kHz}$

PLL3: $f_3 = 69.6 \text{ MHz}$

$\pm f_{70}$

If: A1 tone audible in the loudspeaker, at the IF output (X 0003): 200.000 kHz (measure with P1),

Then: frequency processing 1:

frequency processing 2:

signal path 1(from mixer 1):

signal path 2:

} troublefree

register and interface output:

} faulty

(incl. connection cables)

— Replace control unit by spare subassembly
(required readjustment: tolerance minimization for receive level display according to Section 6.2.)

— or repair in accordance with Section 6.2.

Changeover switch at P 13 to position 

according to EKD adjustment

13 E 9999.99

GC 1, SEL 0

i.e. PLL2: $f_2/100 = 300.01 \text{ kHz}$

PLL3: $f_3 = 69.69999 \text{ MHz}$

$\pm \Delta f_{70}$

Connect X 2051 ($f_N = 10 \text{ MHz}$) with receiver input (X 0001) by means of RF cable 1340.037-01124 (in the accessories).

If: A1 tone audible in the loudspeaker, at the IF output

(X 0003): 199.99 kHz

(measure with P1),

Then: frequency processing 1:

frequency processing 2:

signal path 1:

signal path 2:

} troublefree

register and interface output: faulty
(incl. connection cables)

- Replace control unit by spare subassembly
(required readjustment: receive level display
according to Section 6.2.)
- or repair in accordance with Section 6.2.

5.3. Check 'frequency processing'

5.3.1. Cassette 'frequency processing 2'

- f2/100 to X 1004/A 8 (frequency divider 2)

. Check of frequency (with P1) and voltage
(with P6)

f_E input (kHz)	f2/100 (kHz)	$u_{f2/100}$ (V_{SS})
0.00	400.00	$\square \geq 1.5$
99.99	300.01	

. Potential conversion of all logic conditions for
'frequency divider 2' drive.

f_D input (kHz)	f2/100 (kHz)
77.77	322.23
88.88	311.12

- 200 kHz at X 1002/B 11 (reference frequency)
check of frequency: 200.000 kHz (with P1)
and voltage: 150 mV to 300 mV (with P2)

- 50 kHz at X 1002/B 1 (reference frequency)
check of frequency: 50.000 kHz (with P1)

and voltage: $\square \geq 2.4 V_{SS}$ (with P6)

- In case of faulty 'frequency processing 2':

- replacement by spare subassembly
- or repair in accordance with Section 6.3.

5.3.2. Cassette 'frequency processing 1'

- f1 to X 2002 (rear of the plug-in)

. Check of frequency (with P1) and voltage (with P2)
for the subranges of oscillator 1

Range of osc. 1	f_D input (kHz)	f1 (kHz)	admissible fault Δf (Hz)	u_{f1} across 50 ohm (mV)
1a	0.00 1999.00	70200.00 72199.00	$\approx \pm 150 *$	80 ... 100
1b	2000.00 9999.00	72200.00 80199.00		
2	10000.00 29999.00	80200.00 100199.00		

Check of f1 with potential conversion of all logic conditions for the drive of 'frequency divider 1'

f_E input (kHz)	f1 (kHz)	admissible fault $\Delta f1$ (Hz)
17700.00	87900.00	} $\approx \pm 150$ *)
28800.00	99000.00	

* $\Delta f1 = \Delta f70 \approx 150$ Hz

$\Delta f70$ is eliminated with the 2nd frequency conversion (mixer 2)

- f 70 to X 2001 (rear of the plug-in)

Check of frequency (with P1) and voltage (with P2)

f70	70 MHz $\pm \approx 150$ Hz
u_{f70}	80 mV to 100 mV

- In case of faulty 'frequency processing 1':


→ replacement by spare subassembly

→ or repair in accordance with Section 6.3.

Precondition: 'power supply section'
 'control unit'
 'frequency processing'

troublefree

5.4.1. Check 'signal path 2' with 200 kHz from 'frequency processing 2'



- 'signal path 2' in order: E_T display: LED row: 80 to 100 dB (μV)
 . digital: 42 ... 52
 A1 tone available


- 'signal path 2' faulty:

→ replace it by spare subassembly

(readjustment: tolerance minimization for E_T display according to Section 6.2.)

→ or repair in accordance with Section 6.4.

5.4.2. Check 'signal path 1' and '2' with 200 kHz from 'frequency processing 2'



- 'signal path 1' and '2' in order:


E_T display: LED row: approx. 60 dB (μV)
 . digital: 28 ... 35

A1 tone available

- 'signal path 1' faulty:
- replacement by spare subassembly
(readjustment: tolerance minimization for
E_y display according to Section 6.2.)
- or repair in accordance with Section 6.4.

5.4.3. Check 'signal path 1 - subsections'


5.4.3.1. Mixer 2 → X 3002 → signal path 2



- Signal path 1 - subsections in order:
- E_y display . LBD row: 80 ... 90 dB (μV)
- . digital: 38 ... 45
- A1 tone available

- Signal path 1 - subsections F70 ampl. → mixer 2 →
- X 3002: faulty
- replace signal path 1 by spare subassembly
(readjustment: tolerance minimization
for E_y display according to 6.2.)
- or repair in accordance with Section 6.4.

5.4.3.2. Mixer → IF-1 ampl. → Mixer 2 → X 3002 → signal path 2



- Signal path 1 - subsection in order:

E γ display . LED row: approx. 90 dB (μ V)

. digital: 42 ... 48

A1 tone available

- Signal path 1 - subsection: f1 ampl. $\rightarrow$ mixer 1 $\rightarrow$

OF1 ampl $\rightarrow$ 70.2 MHz crystal filter: faulty

$\rightarrow$ replace signal path 1 by spare subassembly


(readjustment: tolerance minimization for

E γ display according to Section 6.2.)

$\rightarrow$ or repair in accordance with Section 6.4.

5.4.3.3. Presselector 1 and 2 $\rightarrow$ control element 1 $\rightarrow$ mixer 1 $\rightarrow$

IF1 ampl. $\rightarrow$ mixer 2 $\rightarrow$ X 3002 $\rightarrow$ signal path 2



- Signal path 1 in order:

E γ display . LED row: approx. 100 dB (μ V)

. digital: 47 ... 53

A1 tone available

- Signal path 1 - subsection:

X 3004 $\rightarrow$ presselector 1 and 2 $\rightarrow$ control element $\rightarrow$

$\rightarrow$ TP = 30 MHz: faulty

$\rightarrow$ Replace signal path 1 by spare subassembly

(readjustment: tolerance minimization

for E γ display according to 6.2.)

$\rightarrow$ or repair in accordance with Section 6.4.

6. Repair of the faulty subassembly




Figure 4

Service work on the cassettes of the signal path (SW1 and SW2) or on the cassettes of the frequency processing (FA1 and FA2)




Figure 5

Unit arrangement for service work on the power supply section

6.1. Power supply section 1340.039-01500

6.1.1. Input and output values

EKD: $f_E = 2.00 \text{ kHz}$

B_{RB} , channel A

medium volume, $I_{\square} = 40 \text{ mA}$

Power consumption of the entire unit

Current measurements with P8 at U_{rated} in the mains- or battery lead.

All indicated current values are approximate ones.

Mains operation: $\sim 127 \text{ V ac}$: approx. 400 mA
 $\sim 220 \text{ V ac}$: approx. 230 mA

Battery operation: $\sim 24 \text{ V dc}$: approx. 1.5 A
 $\sim 12 \text{ V dc}$: approx. 3.0 A

Output voltages

For measuring or correction:

Operate the plug-in outside the casing via the 30-core adapter cable (accessories).

Measurement with P6 at the measuring points according to Figure 1

+18 V : at X1001/A7, B7

+22 V : at X1003/A7, B7

-12 V : at X1003/A5, B5

+5 V : at X1004/A1, A2

Line corrections only after an operating time of the receiver of = 30 min.

+18 V	$\pm$	100 mV	correction with R 5213	(I = approx. 650 mA)
+5 V	$\pm$	20 mV	correction with R 5217	(I = approx. 1.2 A)
-12 V	$\pm$	50 mV	correction with R 5114	(I = approx. 250 mA)
+22 V	-	2 V	-	(I = approx. 70 mA)

Check current load before every correction.

Hum voltages of the output voltages

The ripple is to be measured with load and 220 V ac input voltage by means of P6 (peak-to-peak value).

+18 V path : ≈ 30 mV (20 kHz)
+5 V path : ≈ 50 mV (20 kHz)
-12 V path : ≈ 20 mV (100 Hz or noise)
-22 V path : ≈ 50 mV (20 kHz + 100 Hz)

Control behaviour

With change of the input voltage by ± 10 %, the variations of the individual output voltages - measured with P9, amount to:

+18 V path : $\Delta U = 60$ mV
+5 V path : $\Delta U = 20$ mV
-12 V path : $\Delta U = 10$ mV

The input voltage variation is to be simulated with the adjustable transformer (P 12).

6.1.2. Measuring values within the power supply divider

measured with mains operation 220 V and load

Rectifier voltages

+18/+5 V path

measured at C 5003) : approx. 30 V

-12 V path

measured at C 5105) : approx. 20 V

Ground voltage for 22 V path

measured at C 5108) : approx. 4 V

Overcurrent limitation

The +18 V-, +5 V-, and -12 V path are provided each with a permanently adjusted current limitation.

This current limitation is to be checked by an additional load (slide resistor (R1) 100 $\rightarrow$ 0 ohm).

+18 V path
+5 V path
-12 V path

Sweep current	a-o current
approx. 2 A	≈ 2.5 A
approx. 3 A	≈ 4 A
approx. 0.4 A	≈ 0.25 A

Shorting the +18 V- and +5 V paths causes switching controller noises in the audible range.

Curve shape

At the test points P01 to P06 indicated in the circuit diagram the prescribed curve shapes shall be detected with P6.

Working frequency


The transverter operates at rated voltage with a frequency of roughly 80 Hz.

It greatly depends on the input voltage.

The switching controller is to be adjusted to 20 kHz $\pm$ 3 kHz by means of R 5227.

Closing behaviour

The unit-specific time sequence of the partial voltages in case of ON and OFF switching is the precondition for the functionality of the control unit.



t_{v1}, t_{v2} = delay time of ON and OFF switching

When t_{v1}, t_{v2} is not kept, the power supply needs repair.

6.1.3. Troubleshooting table

Fault	Possible fault reason	Fault elimination
a) Transverter does not start to oscillate	- False voltage protection responds - V5101, V5102 faulty - Contact troubles at K5001/5002 - Contact troubles at circuit closer on front plate - Overload at secondary end	- viz. b) - Replace V5101, V5102 - Replace K5001, K5002 - viz. c) - causes increased power consumption with mains operation
b) False voltage protection responds	- Battery voltage does not comply with the voltage adjusted on the terminal board X 5002. - Component in the protective circuit faulty	e.g. V 5107, V 5106, V 5103, K 5101
c) Starting aid for oscillation not excited (C 5101 not charged or not discharged with connection or disconnection)	- Interruption in the oscillation-start circuit - X 5001/b3(+)- - k 02/7/5/11/13- - R 5111-V 5110- - circuit closer (on front plate)	

Fault	Possible fault reason	Fault elimination
d) F 5101 responds	- Overvoltage in the +5 V- or +18 V path	- Disconnect load in the unit (e.g. TTL-circuits) - dissolder connections 6 and 7 on pc board 51 - check if an exceeding voltage presents at the output of one of the two paths. In this case e.g. transistor V 5101 or V 5102 or the control (MAA 723) is faulty.
	- Short in the circuit	- Separate load and check if the fuses keep responding. In this case e.g. V 5212, V 5214 or transistor insulation faulty.
	- Overvoltage protection circuit faulty	- e.g. V 5107, V 5108 or V 5109 (thyristor)
e) Noise caused by switching controller	- Sawtooth generator (V 5210, V 5207) faulty	- Check curve shapes at P 01, P 02. Trace signal up to circuit connection 3

Fault	Possible fault reason	Fault elimination
d) Output voltage of the -12 V-path too high	- V 5001 faulty - N 5101 faulty	
e) Frequency of rectifier hum voltage amounts, with mains oper., to 50 Hz instead of 100 Hz	- One rectifier branch of the respective rectifier faulty	- Measurement at C 5105: -12-V path C 5108: Additional voltage for 22-V path C 5003: +5-V path +18-V path




Figure 6
Power supply section 1340.039-01500

Stromversorgungsteil (Seitenansicht)
1340.039-01500

(50)




Figure 7

Power supply section 1340.039-01500

6.2. Control unit

6.2.1. Function principle


After switching on the unit as well as after mains fail the microcomputer is brought in the initial position and the receiver is adjusted to its condition before the disconnection or mains failure.

Subsequently, a program for multiplexer control of the display is initiated.

All operating measurements carried out via keyboard or 24-V interface cause via port A an interruption of the PIO circuit.

Mains failure and test routines are controlled via the non-maskable interrupt input of CPU. The RAM circuits of the control computer are backed by an internal battery.

In case of a total breakdown, it is recommended to start troubleshooting in the computer core because fault detecting is supported by the software. The following sequence is to be adhered to: Control computer - input-output logic - keyboard - display - register and interface.







Figure 8 Control unit Front view



86-036 a

Figure 9
Control unit - view from above

6.2.2. Test and check arrangements

- Control unit inserted

The following components of the plug-in are accessible from above:

- R45145 ... R45147 to balance the control voltage linearization (cf. Section 6.2.9.)
- X4701, X4702 to check and repair the keyboard (cf. Section 6.2.7.)
- Strip 01-02 (RESET) on input-output logic.

Open the receiver front plate, remove screening. The control unit is accessible from the soldering side of the register and interface.

On the soldering side of the control computer U_{RAM} can be checked at C4408.

- Control unit removed

By means of connection adapter P15 the control unit can be operated from an external mains unit; +5 V, +18 V, -12 V, 1

- Check of display and keyboard

Open the front plate of the plug-in, slacken the plug-and-socket connections X4501-X1023 and X4505-X1022, take off the control unit and place it upright such that the plug-and-socket connections can be reestablished again. The complementation side of the display is accessible. If necessary, unscrew the cover.

- Check of control computer and input-output logic

Take off the control computer; establish connection plug-in X1023 - input-output logic X4303/04/05 by means of adapter cable P14. The complementation side of the control computer and the input-output logic is accessible.

Connect P14 with P15 when power supply is to be performed from an external mains unit.

6.2.3. Repair sequence 'local operation'




Figure 10

6.2.4. Repair sequence Operation 'external'





Figure 11

1) The unit is to be programmed in advance as 'slave'.

6.2.5. Control computer

- Operating voltages

+5 V at D04/11, U_{RAM} at C08 (cf. Section 6.2.6. U_{RAM} changeover)

- Input signals of CPU

$\overline{BUSERQ}$, $\overline{WAIT}$, $\overline{RESET}$, $\overline{NMI}$, $\overline{INT} = 1$ (≈ 3.5 V)

Clock at D04/6 $\square\square$ 1.2 MHz $U_{high} \approx 4.8$ V, $U_{low} \approx 0.5$ V

- CPU bus and store selection signals

Open wire strap 03-04, establish connection 04-13.

Cyclic program call is performed. The data bus, the address bus and the control bus of the CPU can be oscillographically checked concerning correct low-high signal change. With this, also the connections of the bus lines to the circuits as well as shorts can be checked.

Signal	U_{low}	U_{high}
D0 ... D7	} < 0.7 V	3.5 V
A0 ... A3		> 3.5 V
A4 ... A15		> 2.5 V
M1, RD, WR, MREQ, RFSH		> 2.5 V
CS0 test point 03		> 2.5 V
CS1 R07		> 3.5 V
CS2 test point 05		> 2.5 V
CS3 test point 07		> 2.5 V
CS4 test point 09		> 2.5 V
CS5 test point 11		> 2.5 V

- Software-aided checks

(cf. equipment documentation Section III/5.2.)

a . Test

(key

EXT

and

EXT
FCT

)

This test, an NMI access to the CPU, checks the function of the input gate PIO port A, i.e. it is tested if the data are read. Furthermore, the function of the EPROMs are checked, i.e. if data are put out.

Troublefree function:

All keys are open (PA 6...PA 0 = 78 H), serial input in STOP condition (PA 7 = 1). All EPROMs supply data.

Display: AA-A0 last receive condition. In condition AA a program loop is running cyclically. It is possible to check oscillographically the CPU signals $\overline{IOW}$, $\overline{NERQ}$, $\overline{M1}$, $\overline{RD}$, $\overline{WR}$, and the decoder signals CS 0 ... CS 5.

Malfunctioning:

The key code of a faulty key is indicated or PA 7 is not in STOP condition or port A of the PIO does not work.

Display 01 indicates: EPROMs by switching further with key ☐ (01, 02 ...); the faulty EPROM does not appear on the display but any display as e.g. FF. Consider the departure from the correct sequence.

b . Test A4 RAM test

Results: FF, F1, F2

FF = troublefree, F1 = RAM 1 (D 4405) faulty,

F2 = RAM 2 (D 4406) faulty.

a . Test A5 ROM test

Results: FF, F1, F2, F3, F4

FF = troublefree, F1 ... F4 = faulty EPROM D 4408 ... D 4411.

Attention

Individual EPROMs must not be exchanged.

When a component - circuits D 4408, D 4409, D 4410, D 4411, (D 4412) - has proved itself to be faulty, the entire pc board control computer 1340.041-01454 is to be replaced.


6.2.6. Input-output logic

Test sequence:

- RESET and NMI generation
- RAM changeover
- Input-output gate addresses and assigned output signals
- RESET and NMI generation


unit switch ON/OFF, check voltage curve with double-beam oscillograph P5

+5 V and +18 V



When these conditions are not met — repair power supply in accordance with Section 6.1.


NMI and RESET



RESET pulse

Key

CALL
99




NMI pulse

Keys

EXT







EXT
FCT



- U_{RAM} changeover

Unit switch	U _{RAM} to C 4408
ON	+5 V from power supply
OFF	+ (3.6 ... 4.1)V from support battery

- Input-output gate addresses and assigned output signals

Input	Output	Pulses to be checked	Output signals
Test	AA	30H at D 4302/12 	
Test A1	8 ... 8	10H at D 4302/14 20H at D 4302/13 	a1 ... g1 a2 ... g2 p1, p2 St0 ... St4 X 4301 2.)
Test A2	00	30H at D 4303/12 Oscillogram without synchronization U 2.5 V	 X 4305/3 X 4305/5 1.)
Test-A3	A3 00	10H at D 4302/14 20H at D 4302/13  ~3ms ~4V 50H at D 4302/10  ~6ms ~4V	a1 ... g1 a2 ... g2 St0 X 4301 (3.4 ... 4.3)V  3ms
Test A6	A6	40H at D 4302/11  80μs ~4V	D0 ... D7 to X 4303/1...8 A0 ... A2 at X 4304/6,7,8  80μs ~4V

1) of. Section 6.2.9. V24 interface/example 2

2) of. Sections 6.2.8. and 6.2.9.

6.2.7. Keyboard

Figure 12.

Output signals.

Taste	Hexa- code	XA7017								XA7027		L ₁
		1	2	3	4	5	6	7	8	9	10	
		PA6	PA5	PA4	PA3	PA2	PA1	PA0	IR	TH		
EXT	00	U	U	U	U	0	0	0	1	1		
END	6D	1	1	U	1	1	0	1	1	1		
0	62	1	1	U	U	0	1	0	1	1		
1	67	1	1	U	U	1	1	1	1	1		
DEL	76	1	1	1	U	1	1	0	1	1		
EXT FCT	20	0	1	0	0	0	0	0	0	1		
SCAN FCT	61	1	1	U	U	0	1	1	1	1		
SCAN	6C	1	1	U	1	1	0	0	1	1		
	64	1	1	U	U	1	0	0	1	1		
	66	1	1	U	U	1	1	0	1	1		
CALL 99	21	U	1	U	U	0	0	1	0	1		
CALL 90	22	U	1	U	U	0	1	0	1	1		
CALL	63	1	1	U	U	0	1	1	1	1		
END	73	1	1	1	U	0	1	1	1	1		3 ms
	65	1	1	U	U	1	0	1	1	1		
	30	U	1	1	U	0	0	0	1	1		
	31	U	1	1	U	0	0	1	1	1		
	32	U	1	1	U	0	1	0	1	1		
	33	U	1	1	U	0	1	1	0	1		
	34	U	1	1	U	1	0	0	1	1		
	35	U	1	1	U	1	0	1	1	1		
	36	U	1	1	U	1	1	0	1	1		
	37	U	1	1	U	1	1	1	1	1		
	38	U	1	1	1	0	0	0	1	1		
	39	U	1	1	1	0	0	1	1	1		
	2E	U	1	U	1	1	1	0	1	1		
	35	U	1	1	1	0	1	1	1	1		
EXT EXT FCT	00	0	0	0	0	0	0	0	0	0		
	20	U	1	U	1	0	1	1	1	1		
	24	U	1	U	1	1	0	1	1	1		0,5 ms
keine Taste	70	1	1	1	1	0	0	0	1	1		

Für jede Taste kann der Code statisch erzeugt werden, wenn gleichzeitig die Taste EXT FCT gedrückt wird.


Code can be generated for each key if EXT FCT is pressed simultaneously

- Low/high levels


Static L/H levels are to be provided at the outputs by depressing the respective key. Checks should be performed according to the scheme below.

Outputs		Low		High	
		Key	Level	Key	Level
X 4701/8	TR	"CALL 99"			
7	PA 0	"EXT" and "EXT FCT"	<0.5 V	"7"	>4.0 V
6	1				
5	2				
4	3				
3	4				
2	5				
1	6				
X 4702/6	TN				

- Pulse generation




Key pulse



L/H level

Test point		L (V)	H (V)
X 4701/1	PA 6	< 0.5	> 4.5
7	PA 0	< 0.5	> 4.5
8	TR	< 0.5	> 3
X 4701/6	TN	< 2.6	> 3




- Pulse diagram for rotary pulse generator



6.2.8.

- Digital display

Voltage curve in test A1

Segment	Test point at X 4601	$\hat{U}$	
a1 ... g1	A4, B3, B13; B12 A13, A3, B4	~3.4 V	
a2 ... g2	A1, A2, A11, A12 B11, B2, B1		
p1, p2 St0...St4	A5, B10 A8, B9, B7, A10 B8	~4.3 V	
LED EXT	A9	~4.3 V ~4.7 V	

- LED row

Voltage values

Position S 4001	U at input	Point	U at point 15	Lighting LED
$\Delta F \times 1$	0 V	04	2.7 V ₌	V 17
$\Delta F \times 2$				V 17
E γ	4.8 V ₌	19		V 17
U _{AF}	1.4 V~ (1 kHz)	03	4.7 V ₌ 1)	V 22

1) correction with R 4631

Check entire row with test A3 according to the Equipment documentation Section III/5,

S 4001 to E γ

0.2.3. Register and interface

- Register and interface matrix

The receiver setting is stored in the 12 register circuits D 4504 to D 4515 that form the register and interface being arranged as matrix (7 rows/8 columns). The rows are the addresses, the columns the data.

Assignment of the circuit function

A \ D	7	6	5	4	3	2	1	0
1	D 4505 100Hz				D 4504 10Hz			
2	D 4707 10 kHz				D 4506 1 kHz			
3	D 4509 1 MHz				D 4508 100 kHz			
4					D 4510 10 MHz			
5	D 4512 MOD				D 4511 B			
6	D 4514 SEL				D 4513 SEL			
7					D 4515 GC			

Example

Short-time reaction at $\Delta F \approx 1 \text{ kHz}$

Setting

73 E 12345.67

SEL 1

GC 4

A \ D	7	6	5	4	3	2	1	0
1	Q	1	1	0	0	1	1	1
2	Q	1	0	0	0	1	0	1
3	0	1	0	0	0	1	0	1
4	0	0	1	0	0	0	1	1
5	0	1	1	1	1	1	0	0
6	0	1	1	0			0	1
7						1	0	0

Note:

Data for B stored in inverted form. The letterings on the lines at the outputs of the register circuits correspond with this matrix.

Example: 3/5 means address 3/data bit 5, i.e. bit 2¹ of the 1-Hz digit of the frequency.

- The frequency data correspond with the decimal places in the 8-4-2-1 code. Output is performed via drivers D 4516 to D 4520. The output lines are marked in accordance with the decimal points. The levels are CMOS levels.

Example: Setting to 1.23 kHz

Frequency		x 1 kHz			x 100 Hz				x 10 Hz			
Line	d3	c3	b3	a3	d2	c2	b2	a2	d1	c1	b1	a1
Logic condition	0	0	0	1	0	0	1	0	0	0	1	1
X 4501	B20	B19	B18	B17	B24	B23	B22	B21	B28	B27	B26	B25

- The selector data are derived automatically from the frequency i.e. the interconnection is contained in the ROM test. The output lines go directly out from the store circuits; the voltages are CMOS levels. For MOD, B and GC the store data are decoded and logically connected. The output signals are generated via driver stages.

- Check of the register and interface outputs

Precondition: Input and display in order. Input signals A0...A2 at X 4503 and D0...D6 at X 4504 available, if not, check 40 H at input-output logic (cf. Section 6.2.6.).

Correct display does not indicate proper output of the register and interface.

Checking the outputs is performed with test A6

Setting

A6

(test 6)

With key  switch digits 00 to 99 further one after the other; Check with this the logic conditions at the soldering side according to the table for register and interface test. (cf. Fig. 13) Observe the following:

X 4501/a 16 This point lies next to +18 V
Be cautious with test prod.

X 4505/B7 }
/B9 } Check of the logic conditions with pull-up resistance 3.3 kohm to 10 kohm

X4505
B7, B9

X 4501/A 16 }
X 4505/B5 }
/B9 }

At these points, carry out an additional check of the short-time reaction at $\Delta F \approx 1$ kHz.

Table Display in testing procedure




	Measur. point	Register and interface test										Level 0/1
		00	11	22	33	44	55	66	77	88	99	
F	X4501/B3	0	0	1	1	0	0	1	1	0	0	$\approx 0,8V/\approx 2,4V$
	B4	0	1	0	1	0	1	0	1	0	1	
	Code 8421 corresponds to d o b a											
x 10 Hz	B25	0	1	0	1	0	1	0	1	0	1	
	B26	0	0	1	1	0	0	1	1	0	0	
	B27	0	0	0	0	1	1	1	1	0	0	
	B28	0	0	0	0	0	0	0	0	1	1	
SEL	X4501/A26	0	1	0	1	0	1	0	1	0	1	$\approx 0,5V/\approx 4,5V$
	A27	0	0	1	1	0	0	1	1	0	0	
	A28	0	1	0	1	0	1	0	1	0	1	
	A29	0	0	1	1	0	0	1	1	0	0	
	B29	0	0	0	0	1	1	1	1	0	0	
MOD	X4501/A25	0	1	0	0	0	0	0	0	0	0	$\approx 0,2V/\approx 17,5V$
	A24	0	0	1	0	0	0	0	0	0	0	
	A23	0	0	0	1	0	1	0	0	0	0	
	A22	0	0	0	1	0	1	0	0	0	0	
	A21	0	0	0	0	1	0	1	0	0	0	
	A20	0	0	0	0	0	1	1	0	0	0	
	A19	0	0	0	0	0	0	0	1	1	0	
	A18	0	0	0	0	0	0	0	0	0	1	
	A17	0	0	0	0	0	0	0	1	1	1	
A16	0	0	0	0	0	0	0	0	1	1	$\approx 0,2V/\approx 12V$	
B	X4505/B1	0	1	0	1	0	1	0	1	0	1	$\approx 1V/\approx 6V$
	B2	0	0	1	1	0	0	1	1	0	0	
	B3	0	0	0	0	1	1	1	1	0	0	
	B4	0	0	0	0	0	0	0	0	0	1	
	B5	0	0	0	0	0	0	0	0	0	1	
GC	X4505/B7	0	1	0	1	0	1	1	1	1	1	$\approx 0,2V/\approx 3V$
	B8	1	0	0	1	1	1	1	1	1	0	
	B9	1	1	1	1	1	0	1	1	1	0	

Figure 13

- Short-time reactions

In case of frequency changes of ≈ 1 kHz the control computer supplies the output GC = 8 that initiates through the monostable flipflop (D 4523) a dynamic behaviour of lines FS 1/0, $\downarrow$ and U_{block} . A short lighting up of V 4623 (right LED) presents in the LED row.

Setting 73 E 0.00 $dF \approx 1$ kHz

Test point	Line	Pulse	Condition
X 4501/A 16	FS 1/0		MOD 8 or 9
X 4505/B9	$\downarrow$		GC $\neq$ 5
X 4505/B5	U_{block}		

$T = 125 \dots 155$ ms

- Receive blocking (cf. Equipment documentation, Section II/2.7.)

The blocking signal of $+ (3 \dots 15)$ V at X 0013/X 0014 and bandwidth B = 9 have the same effects:

Test point	Line	Logic condition	Level
X 4505/B4	5/3	1	≈ 1 V / ≈ 6 V
X 4505/B5	U_{block}	1	≈ 1 V / ≈ 6 V
X 4501/A16	FS 1/0	0	≈ 0.2 V / ≈ 12 V

- SCAN STOP

The control signal at X 0015/X 0016 acts via N 4501/8 and D 4501/4 on PB Ø.

Function	U_{c} at X 0015/X 0016	PB Ø at X 4502/6	Level 0/1
SCAN	-15 V ... +0.8 V 1)	1	≈ 4.5 V
SCAN STOP	+3 V .. +15 V	0	≈ 0.5 V

1) Control signal -15 V ... +8 V is equivalent to 'sockets open'.

Precondition: Function of the signal path in order.

Setting 1 16 E 0.00 GC 1

Set f_{AF} to 1 kHz with A1 $\approx$

Set U_{AF} to 0 dB_m (0.77 V) at X 1020/A - B with $\approx$

Frequency F = 1.50 kHz

Check if $U_{AF} \approx -12$ dBm

Setting 2 48 E 1.00 GC 1

U_{AF} to 0 dBm as above

Frequency F = 2.50 kHz

Check if $U_{AF} \approx -3$ dBm

If U_{AF} is not adjustable or in case of distortions, check level with setting 1:

Incoming AF voltage at X 4505/A 13 $\sim$ 0 dBm (0.77 V)

outgoing AF voltage at X 4505/B 13 $\sim$ -12 dBm (0.2 V)

Checking and balancing the control voltage linearization

Precondition: Function of the signal path in order.

Do not unscrew front panel of the plug-in; balancing elements are accessible from above (cf. Figure 9). Balancing requires feeding of a defined aerial signal with calibration level. Use aerial socket X 0001 at the casing rear; $Z = 75$ ohm. The voltages to be supplied are emf ratings.

Setting 47 E 4500.00 GC 1, SEL 0

Frequency setting on test oscillator 4501.00 kHz

Make use of A3, perform balancing according to the table below:

Aerial emf	Number	Balancing element	Remarks
30 dB (μ V) $\approx$ 32 μ V	15	R 45 145	} alternating until residual error = 0
90 dB (μ V) $\approx$ 32 mV	45	R 45 146	
10 dB (μ V) $\approx$ 3.2 μ V	05	R 45 148	
120 dB (μ V) $\approx$ 1 V	60	R 45 147	

Check by repetition

In balanced condition, the display fault amounts in digits to ± 2 , i.e. to ± 4 dB (μ V).

- V-24 interface

Lines

101 Protective earth

102 System earth


103 Transmitting data to data transmission equipment (DUE)

104 Receiving data from DUE

105 Request to transmit to DUE

106 Ready for transmission from DUE

. Schematic circuit diagram



Setting test A2

Double-beam oscillograph

B channel at line 1/103, X 0005/E - A, B (⊥)

A channel at line 1/105, X 0005/C - A, B (⊥)

A channel
synchronizes
B channel


Oscillograph pulse curve

Example 1

Key

1

31 H



If no double-beam oscillograph available, select

key EXT


, 00 H. Oscillograph lines 1/103 and 1/105 separately.

Example 2

Key

EXT

00 H



If no pulses can be detected, trace the signal back up to X 4501

Line 1/103

X 4501/A2, line 1/105

X 4501/A 4

6.3. Frequency processing

6.3.1. Troubleshooting sequence

The test programs for troubleshooting are given in the following in accordance with the principle of frequency processing. Each program starts with indication of the fault, e.g.

f2/100 wrong
1 kHz correct

that means that frequency f2/100 is wrong, the 1-kHz signal correct.

After that, different test measurements are carried out which are indicated as abridged questions, e.g.

Uf2/100

n

that means that the voltage or the voltage curve Uf2/ are available as represented in the General diagram.

The measurements indicate which component is to be checked. The required test program or test instructions are given, e.g. PLL2

Switch on
range 1

For each test program the measuring points are given in the opposite diagrams.

The test program is terminated with the information that the component to be tested is troublefree, e.g.


PLL 1 in order

6.3.2. Frequency processing - outline.


2) Vereinfachter Übersichtsschaltplan - Frequenzen und Pegel

Frequenzumsetzung

Frequenzumsetzung



1) Programm für die Fehlersuche



1) Fehler - Frequenz hoch
2) Fehler - Frequenz niedrig
3) Fehler - Frequenz hoch
4) Fehler - Frequenz niedrig

Frequenzumsetzung - Übersicht





Figure 14
Frequency processing 1 1340.041-01211

6.3.3. Phase-lock loop 1 (PLL1)

1 Prüfprogramm PLL1




$f1 = 700 \cdot 2 \cdot f_c \cdot \Delta f$
 $f3 = 1000000 - 65536 \cdot \Delta f$
 $\Delta f = 100 \dots 239$
 $f1 = 61 \cdot 10 \dots 239$


Bereich	f1 in kHz	f3 in kHz
10	0.0	1.0
11	2.0	1.0
2	10.0	1.0

2. Bereich 1

2 Blockschaltbild PLL1



2 Synchronisierter Zustand



2. Phasenregelkreis 1 (PLL1)

(1) synchronisierter Zustand





Figure 15
Positions of test points PLL1


6.3.4. Oscillator 1

② Arbeitsweise des Flussscheidungsapparates



5 Impulsschema des Frequenzdiskriminators

၁၂



Oscillator 1

Controlled by the Department of the Interior

301, 302, 303, 310, 317, 312

Drucke 091--10 Messen

BUCKE 114-12-4755

11 12 00 43 7 20 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170 175 180 185 190 195 200 205 210 215 220 225 230 235 240 245 250 255 260 265 270 275 280 285 290 295 300 305 310 315 320 325 330 335 340 345 350 355 360 365 370 375 380 385 390 395 400 405 410 415 420 425 430 435 440 445 450 455 460 465 470 475 480 485 490 495 500 505 510 515 520 525 530 535 540 545 550 555 560 565 570 575 580 585 590 595 600 605 610 615 620 625 630 635 640 645 650 655 660 665 670 675 680 685 690 695 700 705 710 715 720 725 730 735 740 745 750 755 760 765 770 775 780 785 790 795 800 805 810 815 820 825 830 835 840 845 850 855 860 865 870 875 880 885 890 895 900 905 910 915 920 925 930 935 940 945 950 955 960 965 970 975 980 985 990 995 1000 1005 1010 1015 1020 1025 1030 1035 1040 1045 1050 1055 1060 1065 1070 1075 1080 1085 1090 1095 1100 1105 1110 1115 1120 1125 1130 1135 1140 1145 1150 1155 1160 1165 1170 1175 1180 1185 1190 1195 1200 1205 1210 1215 1220 1225 1230 1235 1240 1245 1250 1255 1260 1265 1270 1275 1280 1285 1290 1295 1300 1305 1310 1315 1320 1325 1330 1335 1340 1345 1350 1355 1360 1365 1370 1375 1380 1385 1390 1395 1400 1405 1410 1415 1420 1425 1430 1435 1440 1445 1450 1455 1460 1465 1470 1475 1480 1485 1490 1495 1500 1505 1510 1515 1520 1525 1530 1535 1540 1545 1550 1555 1560 1565 1570 1575 1580 1585 1590 1595 1600 1605 1610 1615 1620 1625 1630 1635 1640 1645 1650 1655 1660 1665 1670 1675 1680 1685 1690 1695 1700 1705 1710 1715 1720 1725 1730 1735 1740 1745 1750 1755 1760 1765 1770 1775 1780 1785 1790 1795 1800 1805 1810 1815 1820 1825 1830 1835 1840 1845 1850 1855 1860 1865 1870 1875 1880 1885 1890 1895 1900 1905 1910 1915 1920 1925 1930 1935 1940 1945 1950 1955 1960 1965 1970 1975 1980 1985 1990 1995 2000 2005 2010 2015 2020 2025 2030 2035 2040 2045 2050 2055 2060 2065 2070 2075 2080 2085 2090 2095 2100 2105 2110 2115 2120 2125 2130 2135 2140 2145 2150 2155 2160 2165 2170 2175 2180 2185 2190 2195 2200 2205 2210 2215 2220 2225 2230 2235 2240 2245 2250 2255 2260 2265 2270 2275 2280 2285 2290 2295 2300 2305 2310 2315 2320 2325 2330 2335 2340 2345 2350 2355 2360 2365 2370 2375 2380 2385 2390 2395 2400 2405 2410 2415 2420 2425 2430 2435 2440 2445 2450 2455 2460 2465 2470 2475 2480 2485 2490 2495 2500 2505 2510 2515 2520 2525 2530 2535 2540 2545 2550 2555 2560 2565 2570 2575 2580 2585 2590 2595 2600 2605 2610 2615 2620 2625 2630 2635 2640 2645 2650 2655 2660 2665 2670 2675 2680 2685 2690 2695 2700 2705 2710 2715 2720 2725 2730 2735 2740 2745 2750 2755 2760 2765 2770 2775 2780 2785 2790 2795 2800 2805 2810 2815 2820 2825 2830 2835 2840 2845 2850 2855 2860 2865 2870 2875 2880 2885 2890 2895 2900 2905 2910 2915 2920 2925 2930 2935 2940 2945 2950 2955 2960 2965 2970 2975 2980 2985 2990 2995 3000 3005 3010 3015 3020 3025 3030 3035 3040 3045 3050 3055 3060 3065 3070 3075 3080 3085 3090 3095 3100 3105 3110 3115 3120 3125 3130 3135 3140 3145 3150 3155 3160 3165 3170 3175 3180 3185 3190 3195 3200 3205 3210 3215 3220 3225 3230 3235 3240 3245 3250 3255 3260 3265 3270 3275 3280 3285 3290 3295 3300 3305 3310 3315 3320 3325 3330 3335 3340 3345 3350 3355 3360 3365 3370 3375 3380 3385 3390 3395 3400 3405 3410 3415 3420 3425 3430 3435 3440 3445 3450 3455 3460 3465 3470 3475 3480 3485 3490 3495 3500 3505 3510 3515 3520 3525 3530 3535 3540 3545 3550 3555 3560 3565 3570 3575 3580 3585 3590 3595 3600 3605 3610 3615 3620 3625 3630 3635 3640 3645 3650 3655 3660 3665 3670 3675 3680 3685 3690 3695 3700 3705 3710 3715 3720 3725 3730 3735 3740 3745 3750 3755 3760 3765 3770 3775 3780 3785 3790 3795 3800 3805 3810 3815 3820 3825 3830 3835 3840 3845 3850 3855 3860 3865 3870 3875 3880 3885 3890 3895 3900 3905 3910 3915 3920 3925 3930 3935 3940 3945 3950 3955 3960 3965 3970 3975 3980 3985 3990 3995 4000 4005 4010 4015 4020 4025 4030 4035 4040 4045 4050 4055 4060 4065 4070 4075 4080 4085 4090 4095 4100 4105 4110 4115 4120 4125 4130 4135 4140 4145 4150 4155 4160 4165 4170 4175 4180 4185 4190 4195 4200 4205 4210 4215 4220 4225 4230 4235 4240 4245 4250 4255 4260 4265 4270 4275 4280 4285 4290 4295 430

11/17	11/18	11/19	11/20	11/21
10 000 00	10 000 00	10 000 00	10 000 00	10 000 00
30 000 00	30 000 00	30 000 00	30 000 00	30 000 00
50 000 00	50 000 00	50 000 00	50 000 00	50 000 00

20N 2-2007-11-11

Drucko 09-1-10

Page 11--12

32225 01-3-93

SECRET

一、

11

1

16th June 1944

[illegible]

Leich der O...

024 197-36

eichbedr.

SECRET (U.S. EDITION)

mont-Kinstell-

10 000 000 US

30 000 00

31.000 00

000 000

66 666 99

Ich des Phosphorkristalle

ellen mit R 2125

10 V an Zrt. 15.18 be

80127 DE 22190
L1128 PMN 22177

100

1990

Journal of Management Education 30(6)

Abstract

100

[illegible]

Age Group	Percentage of Respondents
18-29	85%
30-49	80%
50-69	75%
70+	70%

Test sequence

No output voltage f1

1. UC45 or UC47
2. U 1 (15...18)
3. US1 (12)
4. Does oscillator work?

Control circuit does not synchronize (06)

1. Operating voltages
2. 50 kHz (ref) (05)
3. $\Delta F1/2N1$ (07)
4. U f 4 (15...18)
5. US1 (12)
6. Open bridge 11...12, apply approx. +8 V dc to 12,
synchronize with frequency switch '10 MHz' and '1 MHz'
7. Check capture aid and N 02
8. Balance phase discriminator

4

27-11-51 10 11 12


12 Sanctus Joseph Society

1. UC45 b/w. UC47
2. U1 (15-18)
3. U51 (12)
4. ~~active~~ Oscillator?

የግንባታ ሥራ ላይ የሚገኝ (፬)

- | | | |
|----|------------|------|
| 1. | Settlement | (05) |
| 2. | Settlement | (07) |
| 3. | Settlement | (15) |

10-10-68





Check of the frequency discriminator (capture aid)

D01, D02, D03, V10, V11 and V12

Open bridge 09 ... 10

Open bridge 11 ... 12

Apply approx. +8 V dc to 12 (suitable voltage applied to C1E)

f _e	f ₁ /N1	D03		09
		Pin 9	Pin 5	
10 000 00	> 50 kHz			< 1 V
30 000 00	< 50 kHz			> 14 V

Check of the amplifier N 02

Open bridge 09 ... 10

Open bridge 11 ... 12

Adjust with R 2125

$U_{\text{pin 4}} \gg U_{\text{pin 5}} \longrightarrow U(11) < 2 \text{ V}$

$U_{\text{pin 4}} \gg U_{\text{pin 5}} \longrightarrow U(11) > 13 \text{ V}$

Balancing the oscillator frequency

After replacing V 2125, V 2126, V 2128 or V 2129 the oscillators have to be balanced. Balancing is performed in range 1 with C24 and in range 2 with C34 by exchanging the capacitors.

Balancing conditions (had measurement been performed with screening cap?)

Frequency setting	U_S at point 11 P 8, R ₁ 3 Mohm
1. 10 000 00	2.7 ... 2.9 V = U (1.)
2. 30 000 00	< 14 V
3. 31 000 00	synchronized ?
4. 00 000 00	U (1.) - 0.2 V.
5. 09 999 99	9 ... 11 V

Balancing the phase discriminator


Setting with R 2125

$U_P = 7 \dots 10 \text{ V}$ at point 15 ... 18 at $f_E = 20\,000\,00$


Observe oscillogram at C 2108 and R 2111

6.3.5. Frequency divider 1


1 Prüfprogramm Frequenzteiler 1



10 Lage der Meßpunkte




2 Kode für Oszillator 1-Bereiche



7 Prüfung des Einstellbaren Frequenzteilers 1

-Rücksetzteinheit (3:1-Teilung)



Teil an 0/15
R1A an 0/5
R1B an 2

• U_{U11} = 50 mV

• U_{U11} = 50 mV

-Zähler

U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

-Frequenzteiler

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

-Einstellbare Frequenzteiler

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

• U_{U11} = 50 mV

Einstellbarer Frequenzteiler 1

Eingangsfrequenz $\Delta f_1 = 0,5 \dots 255 \text{ kHz}$

Ausgangsfrequenz $\Delta f_2 = 0,5 \dots 255 \text{ kHz}$, im angegebenen Zustand von P1.1


Teilerfaktor $2N1 = 2 \cdot (5 + N1)$

Zählentlang $N1 = 000 \dots 255$ Zifferwahl an 8-4-2-1-Code


Zählende $n1 = 99$

Zählung nächstes an 8-4-2-1-Code

ii) Blockschaltbild



Impulsdiagramme für Zählende



iii) Frequenzteiler 1

3 für die Frequenz kann man am Eingang (Punkt ii) ein Signal mit einem Pegel von 50 mV ~ aus einem externen Generator (P1) messen

Level balancing:

Accomplish the following adjustments:

With L 04 70-MHz voltage at 17 to minimum
 With L 02 70-MHz voltage at 17 to maximum
 With R 37 70-MHz voltage at 26
 With R 28 70-MHz voltage at 17

Frequency balancing


Balance $f = 70$ MHz with L 03, $\Delta f < \pm 150$ Hz.

6.3.6.2. f_3 oscillator

Level balancing f_3 :

Set 03 to ~ 50 mV/50 ohm with R 02 (tapping on the coil decoupling loop of L 01).

Frequency balancing f_3 :



Open bridge 38/39.

Apply positive voltage via opposite voltage divider to 38.

In position A (10 V dc) $f_3 > 69.7$ MHz; in position B (4 V dc)

$f_3 = 69.6$ MHz. If this cannot be reached, change C 04. Increasing C 04 causes decrease of frequency.

6.3.6.3. Phase discriminator

Image wave test:

$f_3 > 70$ MHz $\rightarrow$ point 9/D02 $\rightarrow$ low level $U_{39} < 2$ V dc

Capture test:

$f_2/100 = 350$ kHz at 33

$f_3 < 69.650$ MHz $\rightarrow$ wide negative pulses at point 5/D-02

$\rightarrow U_{39} > 13$ V dc

$f_3 > 69.650$ MHz $\rightarrow$ wide negative pulses at point 5/D-02

$\rightarrow U_{39} < 2$ V dc



(The narrow negative pulses presenting at point 9/D-02 or 5/D-02 - approx. 50 ns - are only visible with appropriate setting of the oscillograph.)

Phase discriminator:

Close bridge 38/39.

PLL synchronized ($U_{39} = 44 \dots 111$ V).

In case of triggering with $f_2/100$ the oscillograph supplies a stationary pattern of P30 and P54.



- 67 -




Figure 16 Frequency processing 2 and F1 -
Demodulator 1340.041-01221

6.3.7. Phase-lock loop 2 (PLL 2)





Figure 17

Position of test points PLL 2
19910-100.0461 (19910-100.0461)

6.3.8. Oscillator 2



Keine Ausgangsspannung 12

1. -12 V C01
2. -9 V C02
3. U72 (10)
4. U52 (12)

Reglerstele synchronisiert (1)

1. Betriebsspannungen
2. 1 kHz (R02) (01)
3. 12/12 (03)
4. U72 (10)
5. U52 (12)

5. Betrieb 11...12 MHz, an 12 MHz
als Frequenzstandard, 10 MHz U. = 1 kHz synchronisiert
7. Frequenz und 100 MHz
8. Abgleich Frequenzdivisor

No output voltage f2

1. -12 V 030
2. -9 V 029
3. U 2 (10)
4. US2 (12)

1

1. Operating voltages

2. 1 kHz (ref) (01)
3. f2/N2 (03)
4. U 2 (10)
5. U_{g2} (12)

6. Open bridge 11...12, apply approx. +8 V dc to 12,
synchronize with frequency switch '10 kHz' and '1 kHz'

7. Check capture aid and N 02

8. Balance phase discriminator

6.4.1.9. Kontrolle "Regelgleichlauf / Kanal A und B"

Automatikregelung"

- EKD: ☐ F 4 500.00 kHz, ☐ MOD 6, ☐ B 6, ☐ SEL 0, ☐ GC 1,
☐ df 2.00 kHz
- auf jeweils 1000 Hz-Ton im Kanal A bzw. B abstimmen.
- P4-EMK = 2 μ V ... 200 mV in 20 dB-Schritten schalten,
Meßwert P3 (A) bzw. (B) = -3,5 dBm ... 3,5 dBm, so
maximale Pegeldifferenz zwischen (A) und (B) $\leq$ 2 dB

6.4.1.10. Einstellen "Regelersatz Regelglied 1" (Mischer 1)


- HF-Generator P4 an Empfängereingang X 3004 (Y),
 $f = 4501$ kHz, EMK = 100 μ V.
- ZF2 - Übergabepegel an X 3001 mit Millivoltmeter P3 messen
(über BNC-T-Stück — Zubehör),
- EKD: ☐ F 4 500.00 kHz, ☐ MOD 4, ☐ B 7, ☐ SEL 0, ☐ GC 5,
 $\approx \gamma$ mit P4 auf ca. 1000 Hz-Ton im Kanal A abstimmen.
- ZF2 - Übergabepegel - Sollwert: 5.5 ± 0.5 mV.
- Auf ☐ GC 1 umschalten.
Mit R 3836 auf - 12 dB unter den bei ☐ GC 5 $\approx \gamma$ von P3
angezeigten Pegelwert einstellen.

6.4.1.11. Einstellen "Trigger - Regelverstärker"



- HF-Generator P4 an Empfängereingang X 3004 (Y)
 f_E 4 500.00 kHz, EMK = 1 μ V
- EKD: ☐ F 4 500.00 kHz, ☐ MOD 4, ☐ B 7, ☐ SEL 0, ☐ GC 2,
Mit P4 auf ca. 1000 Hz-Ton im Kanal A abstimmen
- mit Digital-Voltmeter P9 Kollektorspannung an V 3826 messen
und R 3813 so einstellen, daß $U_C = V$ 3826 auf ca. +18 V
springt und diesen Wert beibehält.
- Zur Kontrolle: P4-EMK von 30 μ V in 10 dB-Schritten schalten.
 $U_C = V$ 3826 muß kurzzeitig < 1,5 V werden und wieder auf
ca. +18 V ansteigen.

6.3.9. Frequency divider 2


1 Prüfprogramm Frequenzteiler 2



7 Prinzip des 5:1-Teilers



13 Variations des 5:1-Teilers und HF-Regel




1 Prüfung des Einstellbaren Frequenzteilers 2

-Rücksetzeinheit

(3:1-Teilung)



- Brücken 16 - 17 verbunden
18 - 19 offen
21 - 22 verbunden
10 - 11 verbunden
- 20 Hz - Schalter auf '1'
- Uf2 = 50 mV~
- Zähler A/B = 40000




- Brücken 16 - 17 verbunden
18 - 19 offen
21 - 22 verbunden
- Uf2 = 50 mV~

-Frequenzeinstellung

- Brücken 16 - 17 verbunden
18 - 19 offen
21 - 22 verbunden
10 - 11 verbunden
- Uf2 = 50 mV~

-Einstellbare Frequenzteilung





- Brücken 16 - 17 verbunden
18 - 19 verbunden
21 - 22 verbunden
- Uf2 = 50 mV~


10 Einstellbarer Frequenzteiler 2

- Eingangsfrequenz f2 = 40000 - (0,000...999) kHz
- Ausgangsfrequenz f2/N2 = 1 kHz, im Synthesekanal Zustand von R2A
- Teilerfaktor N2 = 40000 - f2
- Zählzeit f2 = 9999 Ziffernwert im 8-4-2-1-Code
- Zählzeit f2 = 40000
- 10 kHz, 1 MHz und 100 kHz - Dekade im 8-4-2-1-Code
- 10 kHz - Dekade und 2 Bit - Ziffernwert im 8-4-2-1-Code

11	07	12	-	Dezember	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99
00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99				



Impulsdiagramm



3 Für die Frequenz kann man ein Punkt 11 ein Signal mit einem Pegel von 50 mV~ und einer Frequenz < 30 kHz einstellen (P4).

6.4. Signal path (portable standard C and A frequency)

6.4.1. Check or correction of levelling

Open cassette lid (complementation side) of cassettes

'signal path 1' and 'signal path 2' and fasten outer cassettes in hinged position with cassette support (contained in the accessories).

6.4.1.1. Basic amplification 'signal path 1'

- RF generator (P4) to receiver input X 3004 (Y)

$f_B = 4\ 500\ \text{kHz}$, $\text{emf} = 1\ \text{mV}$

- RF millivoltmeter P2 (150-mV range) via BNC-T-piece (accessories) at X 3002 (IF2 = 200 kHz)

- EKD: 4 500.00 kHz, 4, 5, 0, 5 $\approx \gamma$

- Tune with P4 to zero beat (required forward centre)

Test value P2: 50 to 60 mV

Correction: 'coarse' with R 3434 } when holding the control volume
'fine' with R 3409 } for 'signal path 1': 60 $\begin{smallmatrix} +2 \\ -1 \end{smallmatrix}$ dB

6.4.1.2. Control volume 'signal path 1'

- Actual value from point 6.4.1.1. (test value P2) is the reference value

- $\approx \gamma$

- P4 - $\text{emf} = 1\ \text{V}$

- Test value P2: Actual value from point 6.4.1.1. $\begin{smallmatrix} +1 \\ -2 \end{smallmatrix}$ dB

- Correction: with R 3409

6.4.1.3. Mixer - symmetry

- Receiver input X 3004 (Y) not connected

- P2 (500-mV range) to X 3002 (IF2 = 200 kHz) via BNC-T-piece (accessories)

- EKD: 0.00 kHz, 4, 5, 0, 5 $\approx \gamma$

- Test value P2 $\approx 200\ \text{mV}$

Correction (minimization): with C 3336 (balancing capacity)

Channel A and B, manual control)

- RF generator P4 to X 0001 (casing) and via connection cable to X 3004 (plug-in).

$$f_E = 4\ 500\ \text{kHz}, \text{ emf} = 1\ \mu\text{V}$$

- AF millivoltmeter P3 and load resistance 600 ohm in parallel to line output A (25) and B (26).
- EKD: 4 500.00 kHz, 6, 7, 0, 5 $\approx \gamma$
 2.00 kHz
- Tune with P4 to approx. 1000-Hz tone in channel B, test value P3 (B): +1 dBm, correction with R 3617 *)
- Set 1000-Hz tone with rotary button (2.00-kHz step) in channel A, test value P3 (A): +1 dBm, correction with R 3855 *)
maximum level fault: 0.5 dB.

6.4.1.5. Levelling 'A3E'

- RF generator P4 to receiver input X 3004 (Y)
 $f_E = 4\ 500\ \text{kHz}, \text{ emf} = 5\ \mu\text{V}, m = 0.5\ f_{\text{mod}} = 1\ \text{kHz}$
- AF millivoltmeter P3 in parallel to 600-ohm load resistance at AF line output A (25)
- EKD: 4 500.00 kHz, 2, 6, 0, 1
- Tune with P4 1000-Hz tone in channel A to minimum noise
- Balance test value P3 (A) = -1 dBm by means of R 3847 *)

6.4.1.6. Changing AF line levels (max +6 dBm)

A change of the AF line levels (up to max +6 dBm) is to be carried out with

Channel A: for A3E with R 3847

for A1A, J3E, B8E (+SB) with R 3855 (Demod. and AF)

Channel B: for B8E (-SB) with R 3617 (IF 2/B)

Cf. also Sections 6.4.1.4. and 6.4.1.5.

6.4.1.7. Balancing 'control synchronism/channel A and B, man. con

- RF generator P4, emf = 20 μV
- EKD: 4 500.00 kHz, 6, 6, 0, 5
- Tune to 1000-Hz tone in channel A or B
- Adjust test value P3 (B) = 0 dBm with $\approx$
- Adjust test value P3 (A) = 0 dBm $\pm$ 0.5 dB with R 3734
- Switch P4-- emf = 2 μV in 20-dB steps and set test value P3 (B) = 0 dBm with $\approx$
- Maximum level difference between (A) and (B): $\leq 1.5\ \text{dB}$

*) For increased AF output level (e.g. + 6 dBm) balance to a value being 6 dB higher

4.1.8. Balancing 'automatic control/channel A and B'

RF generator P4, emf = 200 mV

EKD: 4 500.00 kHz, 6, 7, 0, 1, 2.00 kHz. Tune with P4 to approx. 1000-Hz tone in channel B, set measuring value P3 (B) = +2 dBm with R 3616

Set 1000-Hz tone with rotary button $\approx$ (2.00-kHz step) in channel A

Set test value P3 (A) = +2 dBm with R 3801, max. level fault: 0.5 dB

P4-emf = 2 μ V, test values P3 (A) or (B) = -2 dBm ... 0 dBm

4.1.9. Check 'control synchronism/channel A and B, automatic control'

EKD: 4 500.00 kHz, 6, 6, 0, 1, 2.00 kHz

Tune to 1000-Hz tone in channel A or B

Switch P4 - emf = 2 μ V ... 200 mV in 20-dB steps

test values P3 (A) or (B) = -3.5 dBm ... 3.5 dBm,

maximum level difference between (A) and (B): $\leq$ 2 dB

4.1.10. Adjustment 'control start/control element 1' (mixer 1)

RF generator P4 to receiver input X 3004 (Y), f = 4501 kHz, emf = 100 μ V

IF 2 - interposition level on X 3001 to be measured with millivoltmeter P3 (via BNC-T-element -- accessories).

EKD: 4 500.00 kHz, 4, 7, 0, 5,

Tune $\approx$ with P4 to approx. 1000 Hz-tone in channel A

IF 2 - interposition level - rated value : 5.5 ± 0.5 mV

Switch over to 1

Adjust to a value -12 dB below the one read by P3 for 5 $\approx$ with R 3836.

4.1.11. Adjustment 'trigger - control amplifier'

RF generator P4 at receiver input X 3004 (Y)

f = 4 500.00 kHz, emf = 1 μ V

EKD: 4 500.00 kHz, 4, 7, 0, 2

Tune with P4 to approx. 1000-Hz tone in channel A

Measure with digital voltmeter P9 collector voltage at V 3826 and adjust R 3813 such that U_C = V 3826 jumps to approx. +18 V and maintains this value.

For checking: Switch P4 - emf from 30 μ V to 1 μ V in 10-dB steps. U_C shall decrease for a short time to < 1.5 V and increase then again to approx. +18 V.

- RF generator P4 to receiver input X 3004 (Y)

$f_E = 4\ 500\ \text{kHz}$, $\text{emf} = 30\ \mu\text{V}$

- EKD: 4 500.00 kHz, 4, 7, 0, 1

- Tune with P4 to approx. 1000-Hz tone in channel A

- Measure with digital voltmeter P9 capacitor voltage C 3808

- Measure with P9 the voltage at slider of R 3829 and adjust with R 3829 to a value that is 0.5 V below $U_C\ 3808$

(guide value: $4.3\ \text{V} - 0.5\ \text{V} = 3.8\ \text{V}$)

6.4.1.13. Balancing 'display E_Y' (LED row and decimal digital display)

- RF generator P4 to receiver input X 3004 (Y)

$f_E = 4\ 500\ \text{kHz}$, $\text{emf} = 1\ \text{mV}$

- EKD: 4 500.00 kHz, 4, 2, 0, 1, TEST 3

Changeover switch 'LED row' (2) → E_Y

- Tune P4 to zero beat (IF forward centre)

- Balance the emf pairs in the sequence $30\ \mu\text{V}$, $30\ \text{mV}$ and $3\ \mu\text{V}$ at 1 V with the assigned preset controllers R 45145 ... R 45148 to the values 'decimal digital display' given in the table below.

	P4 - emf			
	$30\ \mu\text{V}$	$30\ \text{mV}$	$3\ \mu\text{V}$	1 V
LED row	30 dB (μV)	90 dB (μV)	10 dB (μV)	120 dB (μV)
Decimal digital display	15 ± 1	45 ± 1	5 ± 1	60 ± 1
Preset controller	R 45145	R 45146	R 45148	R 45147

(Position of preset controller cf. Figure 1)

Note: dB (μV) = dB exceeding $1\ \mu\text{V}$ i.e., 0 dB (μV)

If rated balancing cannot be achieved: change shift register R 45122 (150 kohm ... 220 kohm)

dB (μV) = dB over $1\ \mu\text{V}$, i.e. 0 dB (μV) = $1\ \mu\text{V}$

The following section provides hints on troubleshooting in the cassette 'signal path 1'.
 For this purpose, the plug-in is to be connected outside the casing via adapter cable (30- and 8-core cable, contained in the accessories).
 For fault localization: : dismount cassette lid (complementation side)
 . perform level check according to the figure

Vorselektor 1 (31)

Vorselektor 2 (32)

X3004

TEST EMK = 1mV/R_i = 75 Ω
 4,5 MHz, SEL 0
 GC5, ✓

Mischer 1 (33)

X3003

70,2...100,2 MHz
 70...110 mV/50 Ω

Mischer 2 (34)

X3001

70 MHz
 70...110 mV/50 Ω

X3002

TEST 200 kHz
 50...60 mV

TEST

Abgleich: R3434
 Verstärkung: 55 ± 5

Abgleich: R3409
 Regelungsfang 60 dB ± 2
 GC 5, ✓ TEST

Abgleich III₂

Abgleich IV₂

Abgleich V₂

Abgleich VI₂

Abgleich - Bandbreite
 (Kopplungsbügel)

Abgleich VII
 (HP = 24 MHz)

Abgleich
 (TP = 30 MHz)

Abgleich II
 (HP = 1,5 MHz)

Abgleich I
 (TP = 1,5 MHz)

Abgleich
 (TP = 30 MHz)

Abgleich
 70,2 MHz, optm.

Abgleich
 70,2 MHz, optm.

Interface
 Vorselektor 1 u. 2


Abgleich
 70 MHz, max.

Abgleich
 200 kHz max.

86-033a

Figure 18
 Signal path 1 1340.041-01311

6.4.2.1.1. - Selectivity characteristics 'presselector 1'
(Switchable suboctave filter 1.5 MHz to 24 MHz in 12 subranges)



	Pass range (≤ 2 dB) $f_A \dots f_E$ (MHz)	Blocking range (mean value ≤ 20 dB)		Balancing frequency	Balancing elements
		$\leq 0.5 \cdot f_E$ (MHz)	$\geq 2 \cdot f_A$ (MHz)		
III 1	1.5 ... 2	≤ 1	≥ 3	-	-
III 2	2 ... 2.5	≤ 1.25	≥ 4	2.25 MHz	L3101, L3102
III 3	2.5 ... 3	≤ 1.5	≥ 5	-	-
IV 1	3 ... 4	≤ 2	≥ 6	-	-
IV 2	4 ... 5	≤ 2.5	≥ 8	4.5 MHz	L3103, L3104
IV 3	5 ... 6	≤ 3	≥ 10	-	-
V 1	6 ... 8	≤ 4	≥ 12	-	-
V 2	8 ... 10	≤ 5	≥ 16	9 MHz	L3105, L3106
V 3	10 ... 12	≤ 6	≥ 20	-	-
VI 1	12 ... 16	≤ 8	≥ 24	-	-
VI 2	16 ... 20	≤ 10	≥ 32	18 MHz	L3107, L3108
VI 3	20 ... 24	≤ 12	≥ 40	-	-

Each subrange ends at $f_E - 10$ Hz

- For all measurements $Z_E = Z_A = 75$ ohm
- Balancing with broad-band wobble measuring set-up (P7)*) between cassette input X 3004 and presselector 2 output P 3205.

*) When balancing with RF generator (P4), attenuate the coil that is not to be balanced with a 300-ohm resistance.

- For balancing: Remove connection to mixer 1 (P 3205 $\rightarrow$ P 3301) at P 3205: 75-ohm resistance $\rightarrow$ 1

For switching on the subrange to be balanced:

EKD: for range III 2: ☐ F 2250.00, ☐ SEL 1
range IV 2: " 4500.00, " 1
range V 2: " 9000.00, " 1
range VI 2: " 18000.00, " 1

- Coil balancing according to set-point value-selectivity characteristics

Adjust with strap to insertion loss of ≈ 2.5 dB at the pass-range limits f_A and f_E with adherence to the selection ratings at $0.5 \cdot f_E$ and $2 \cdot f_A$.

- In the other subranges (III 1 ... VI 1 and III 3 ... VI 3):
Check insertion loss ≤ 3 dB and selection ratings according to 6.4.2.1.1.


Range I LP ≈ 1.5 MHz

Balancing elements

L 3214

L 3215

L 3216



Range II HP ≈ 1.5 MHz

LP ≈ 30 MHz

Balancing elements

L 3217

L 3218


L 3219

Balancing elements

L 3211

L 3212

L 3213



Range VII HP ≈ 24 MHz

LP ≈ 30 MHz

Balancing elements

L 3220


L 3221

Balancing elements

L 3211

L 3212

L 3213



For all measurements $Z_R = Z_A = 75$ ohm

- Balancing with broad-band wobble measuring set-up (P7) between cassette input X 3004 and preselector 2 - output P 3205
- When balancing: Remove connection to mixer 1 (P 3205 → P 3301) at P 3205: 75-ohm resistance → 1
- For balancing the respective preselection range the following operation of the receiver is required:

For request 1 : BKD: F 250.00 kHz, SBL 1

" II : EKDI " 4500.00 kHz, " 0

" VII : EKD; " 26000,00 kHz; " 1

6.4.3. Signal path 2 1340.041-01321

The following section supplies hints on troubleshooting in the cassette 'signal path 2'.

For this purpose, the plug-in is to be connected outside the casing via adapter cable (30-and 8-core cable, contained in the accessories).

For fault localization:

- Dismount cassette lid (complementation side)
- Apply input signal from RF generator (P4) to X 3051 (input socket for signal path 2)
- Load line output A (25) and line output B (26) at one end — 1 and with R = 600 ohm to avoid interferences
- Perform level check acc. to figure 19 or 20.




Figure 19

Signal path 2

1340.041-01321

Pegelkontrolle bzw. Pegelkorrektur

	HP-Generator (74)		Sendeleist.	Bandbreite	Verst. Regelung	Prüfung	Prüfpunkt	Messwerte	
	f	U _e						U _{best.}	U _{max.}
OC 5 U _{ZF2} -Verst.	199 kHz	55 µV	MOD 1	B 6	OC 5	Kontrolle U _{best.} U _{max.}	X 3001 /B11	199 kHz	U _{best.} U _{max.}
U _{f_{HF}} -Verst.	200 kHz	10 µV	MOD 3	"	OC 5	L 3701 Max.	ZF2 - Ausgang (27)	200 kHz	U _{best.} U _{max.}
U _{f_{HF}} -Korr.	200 kHz	50 µV	"	"	"	T 3701 Max.	ZF2/B P 3605	200 kHz	U _{best.} U _{max.}
Zusammen- fassend (U _{f_{HF}} , f _{HF})	-	-	MOD 1	beliebig	OC 5	Kontrolle	X 3001 /B2	199,8 kHz ± 199,5 kHz	110...160 mV
	200 kHz	-	MOD 3	"	"	Kontrolle f und U _{max.}	"	200,00 kHz	120...170 mV
	-	-	MOD 4	außer	"	"	"	200,00 kHz	"
Pegelung/322 U _{HF(A)}	201 kHz	55 µV	MOD 5	B 16	OC 5	R 3095 einstellen	NP-Lage-Ausg.	1 kHz	0 dB
Regelstell- wert (Autosmetik)	201 kHz	110 µV	"	"	OC 1	B 3001 einstellen Kontrolle f, U _{max.}	"	1 kHz	-1 dB
Regelstwert U _{HF1}	201 kHz	25 mV	"	"	"	B 3036 einstellen	"	1 kHz	± 1,2 dB
Pegelung/433 U _{HF (A)}	200 kHz ± 0,5/1 kHz	1,5 mV	"	"	"	B 3047 einstellen	X 3001 /B10	1 kHz	12,5 V
Abbrück- stärker	201 kHz	1 mV	MOD 2	"	"	"	NP-Lage-Ausg. A	1 kHz	-1 dB
Pegelung/668 U _{HF (B)}	201 kHz	1,5 mV	MOD 4	"	OC 5	Kontrolle □ est.	"	1 kHz	± 2 V _{max} B 0m
	201 kHz	55 µV	MOD 6	B 7	OC 5	L 3601 Max. B 3617 einstellen	NP-Lage-Ausg. B	1 kHz	0 dB

Figure 20

Parameters, criteria, are values and frequency response of the output voltage U , as well as the function of the LED V 4602 

Test and troubleshooting are accomplished in the sequence "Value of the output voltage" - "Frequency of the output voltage".

The tables (figure 21, 22) show, in dependence on the class of emission (MOD) selected, the voltage U of the functional groups or the voltages and frequencies at the inputs U_E , f_E and at the output U_A , f_A ($\approx f_{U3}$) as well as the function of the LED V 4602 

6.4.3.1.1. Output voltage and control voltage generator

The maximum balancing L 3503 is performed at A1A (very flat maximum) or at F  alternating with F  to the equal value of U_A . The crystal oscillator is amplitude-controlled via T 3514.

6.4.3.1.2. Crystal oscillator

The crystal-stabilized oscillator is tuned at its frequency by means of the parallel circuit L 3501-C 3521, C 3530 and the capacity diode V 3529.

The frequency range is balanced at A1A with C 3530 (coarse) and L 3501 (fine) to $f_A = 198.8$ kHz with 0 V at X 3501/B7 and $f_A = 199.5$ kHz with 9.5 V at X 3501/B7.

Access to the balancing core of L 3501 is provided after dissoldering of the metal tip in the cap centre. After accomplishing balancing work the coil is to be covered again with the metal tip.

6.4.3.1.3. Store and switch

The switch is actuated by the trigger.

Class of emission R3E, $U_E = 200$ mV, $f_E = 200$ kHz $\pm \Delta f_E$.

The switch is closed as V 3523 and V 3526 are blocking and V 3508 or V 3509 cause opening - depending on the potential difference - between emitter and collector thus closing the phase control loop

$$\Delta f_A = \Delta f_E.$$

Class of emission R3E, $U_E = 50 \text{ mV}$, $f_E = 200 \text{ kHz} \pm \Delta f_E$.

The switch is open because V 3508 and V 3509 are blocking via V 352

The phase control loop is open, Δf_A is independent of Δf_E , f_A is nearly constant and changes with -3 Hz/min (discharge of store capacitor C 3518).

In case f_A is dependant on f_E : check V 3523, V 3526, V 3508, and V 3509.

When change of f_A too large: replace T 3508, T 3509, T 3510, T 3525, C 3518 in this sequence.

Attention! V 3510 is a MOS transistor. When changing V 3510 or any components which are fed to its transistor terminals these are to be shortened.

In the class of emission J3E, $U_E = 200 \text{ mV}$, $f_E = 200.000 \text{ kHz}$ the operating condition R3E is equal to $U_E = 200 \text{ mV}$, $f_E = 200.000 \text{ kHz}$. The inverse voltages for V 3523 and V 3526 are firmly switched on via V 3540.

6.4.3.1.4. Phase detector

Direct voltage to N 3501/8 at $U_E = 0$: approx. 6 V.

With the control loop closed the voltage at N 3501/8 varies irregularly by approx. $\pm 10 \%$ (phase jumps of f_A).

6.4.3.1.5. Voltage path 200.000 kHz

Characteristic of the voltage path: V3501/B3-R3506-V3516-R3503-N3501/14

6.4.3.1.6. Voltage path 200 kHz + Δf_E

Characteristic of the voltage path: V3501-R3508-V3518-C3505-R3503-N3501/14

6.4.3.1.7. Amplifier and trigger

Gate D 3504/9, 10, 11, 8 is included in the amplifier. E 3520 causes slow recharging of C 3517 after having applied the input voltage and with this the delayed response of the trigger (0.5 s). $U_E \approx 200 \text{ V}$ 3504C 15.5 V $\rightarrow$ 5 V; V 3503E 3.5 V $\rightarrow$ 13.5 V.

V 3521 provokes quick recharging of C 3517 after disconnection of the input voltage and thus immediate response of the trigger.

6.4.3.1.8. Divider 200 kHz/1.905 kHz

Divider ratio 1:105.

At the classes of emission F the divider is put into operation via K input D 3503/10 by applying 2.7 V. The divider consists of the counter components D 3501 and D 3502 as well as of the decoding circuit D 3504 (2 gates) and D 3503 for releasing a reset pulse. Every 103rd pulse at D 3501/14 causes that H potential is applied to the J inputs of D 3503. Thus, the 104th pulse can release a reset pulse at the Q output. This pulse is terminated with the trailing edge of the 105th pulse.

6.4.3.1.9. Mixer 200 kHz $\pm$ 1.905 kHz

The summation and difference frequencies are available opposite in phase at the outputs N 3502/12 and N 3502/13.

Input voltages: N 3502/6.14 approx. 2 V; N 3502/7.9 approx. 3.6 V.

A summation voltage of approx. 400 mV is applied to N 3502/12, 13 (both input- and mixed frequencies).

6.4.3.1.10. Crystal filter 201.905 kHz and 198.095 kHz

Both crystal filters are bridge filters whose branches are activated opposite in phase by N 3502/12 or N 3502/13. After crystal exchange a maximum balance von U_A by minimum tuning of the crystal frequency with C 3535 or C 3536 may be required.

C 3537 and C 3538 provide minimum balancing of the distortion products of U_A (suppression of the undesired frequencies).

DC voltages of the function groups in dependence of the class of emission selected (MOD)

Test value	Function Group	Test point	A1A	A3E	R3E, B _R BE	J3E, B3E	F0, F _{JL}	F _{LT}
DC voltages of the function groups U (V)	Output amplifier and control voltage generator	X3501/B1	18	18	18	18	18	18
	Crystal oscillator	V3548/K	16.5	0	16.0	16.0	0	0
		X3501/B7	0...9.5	0	0	0	0	0
	Store and switch	V3542/K	0	0	16.5	16.5	0	0
	Phase detector	V3519/K	0	0	16.5	16.0	0	0
	Voltage path	V3516/K	0	0	0	0.7	0.7	0.7
		200 kHz + Δf	0	0	0.7	0	0	0
	Amplifier and trigger	V3546/K	0	0	16.0	(5)	16	16
	Divider 200/11.905 kHz	X3504/A1 D3503/10	5 0	5 0	5 0	5 0	5 2.7	5 2.7
	Mixer 200 kHz ± 1.905 kHz	V3534/K	0	0	0	0	16.5	16.5
Crystal filter	201.905 kHz	X3501/A9	0	0	0	0	17.5	0
	498.095 kHz	X3501/A11	0	0	0	0	0	17.5

Table

Voltages and frequencies at the inputs and at the output as well as the function of the carrier display  in dependence on the class of emission selected (MOD)

Test value	Function group		Connection points	A1A	A3E	R3E, R _H EE	J3E, 2EE	F0, 3Π	FU
Input voltages and frequencies (test)	$\frac{U_E}{f_E}$	Voltage path 200.000 kHz	X3501/B3 — X3501/A3 ⊥	—	—	—	200 mV 200.00 kHz	200 mV 200.00 kHz	200 mV 200.00 kHz
	$\frac{U_E}{f_E}$	Voltage path 200 kHz + Δf_E	P3501 — P3502 ⊥	—	—	50mV/200mV 200kHz + Δf_E $\Delta f_E \approx 50\text{Hz}$	—	—	—
Output voltages and frequencies $R_A = 680 \text{ ohm}$	$\frac{U_A}{f_A}$	Output amplifier	X3501/B13 — X3501/A13	110 mV to 160 mV < 198.8 to > 199.5 kHz (A1-pitch control)	0	120 to 170 mV 200kHz + Δf_A $U_E = 200\text{mV}$ $\Delta f_A = \Delta f_E$ $U_E = 50\text{mV}$ $\Delta f_A \text{ const.}$ (~3Hz/min)	120 to 170 mV 200.000 kHz $f_A = f_E$	80 to 130 mV $W < 5\%$ 201.905 kHz	80 to 130 mV $W < 5\%$ 198.095 kHz
Function Carrier display 	f_{U3}	Trigger	X3501/B11	dark	dark	$U_E = 200\text{mV}$ lit $U_E = 50\text{mV}$ dark	dark	dark	dark

Figure 22

6.4.3.2.1. Amplification in signal path 2 (X3051 — P3705)

$U_e = 55 \mu V$ at X3051 (RF generator P4), GC 5 and $\approx \rightarrow$

$U_a = 100 \text{ mV}$ to 200 mV at P3705 — $\perp$ (millivoltmeter P3)

$U_{R2} = 0.75 \text{ V}$

Amplification difference with bandwidths B 2... B 4 : $\approx 4 \text{ dB}$
with B 1 : $\approx 6 \text{ dB}$

Attention Exchange IF2 amplifier circuits N3603 (IF2/B) and N3702 (IF2/A) only in pairs (spare part in B1)


6.4.3.2.2. Carrier amplifier (for R3E and B_{R8E})

$200 \text{ kHz}/U_e = 10 \mu V$ at X3051 (RF generator P4)

$U_a = 30 \text{ mV}$ to 100 mV at P3605 — $\perp$ (millivoltmeter P3)

3 dB bandwidth : $\approx \pm 50 \text{ Hz}$

6.4.3.2.3. Bandwidth and selection of mechanic filters

B	Rated bandwidth	3 dB bandwidth	60 dB bandwidth
1	0.15 kHz	$\approx \pm 50 \text{ Hz}$	$\approx \pm 250 \text{ Hz}$
2	0.4 kHz	$\approx \pm 150 \text{ Hz}$	$\approx \pm 500 \text{ Hz}$
3	0.75 kHz	$\approx \pm 300 \text{ Hz}$	$\approx \pm 850 \text{ Hz}$
4	1.75 kHz	$\approx \pm 750 \text{ Hz}$	$\approx \pm 1250 \text{ Hz}$
5	3.1 kHz	$\approx \pm 1.5 \text{ kHz}$	$\approx \pm 2.15 \text{ kHz}$
6	6.0 kHz	$\approx \pm 3.0 \text{ kHz}$	$\approx \pm 4.0 \text{ kHz}$
7*)	+3.0 kHz	$\approx +(0.25...3.0) \text{ kHz}$	$\approx -0.25 \text{ kHz}; \approx +3.5 \text{ kHz}$
**)	+6.0 kHz	$\approx +(0.3...5.9) \text{ kHz}$	$\approx -0.3 \text{ kHz}; \approx +6.8 \text{ kHz}$
8*)	-3.0 kHz	$\approx -(0.25...3.0) \text{ kHz}$	$\approx +0.25 \text{ kHz}; \approx -3.5 \text{ kHz}$
**)	-6.0 kHz	$\approx -(0.3...5.9) \text{ kHz}$	$\approx +0.3 \text{ kHz}; \approx -6.8 \text{ kHz}$
9		signal path blocked	

*) EKD 511

**) EKD 512

Attention The signs of the built-in sideband channel filters are opposite to that of the input signal (sideband commutation in mixer 1).

6.4.3.3. Demodulator and AF section 1340.039-01358

6.4.3.3.1. Demodulator/A1A; J3E; F1B; F3C

Level outline with input signal applied

At P 3801 → 1: IF2 signal = 201 kHz or 200 kHz/100 mV, GC 5

At N 3801/14 : $U_{\text{carrier (lim.)}}$ = 200 mV to 350 mV_{ss}

At N 3801/9 : U_{IF2} = 7 ... 15 mV_{ss}

At N 3801/8 : U_{AF} = 50 ... 55 mV_{ss}

adjust with R 3855

6.4.3.3.2. Demodulator/A3E

Level outline with input signal applied

At P01 → 1: IF2 signal = 200 kHz/m = 0.5; 1 kHz, 100 mV, GC 5

At X01/14 : IF2 signal = 3 ... 5 mV_{ss}

At X01/8 : U_{AF} = 50 ... 55 mV_{ss} ; adjust with R 3847

Attention At input P 3801 → 1 : approx. 1.1 V dc voltage

6.4.3.3.3. AF line amplifier 'channel A'

Level outline with input signal applied

At N 3802/3 : U_{AF} = 50 ... 55 mV_{ss}

At N 3802/6 : U_{AF} = 0.775 V_{ss} (with 52 mV at N 3801/8)

At X 3801/B4 : U_{AF} = 0.775 V_{ss}

Line output 'A' : at X 3802/5 : 8.8 ... 9.2 V_{ss}

at X3802/10 : 8.8 ... 9.2 V_{ss}

6.4.3.3.4. Monitoring amplifier

U_B at X X.3801: 100 mV (for 0.5 W across 8 ohm X 1021  external)

(Correcting of amplification possible with R 71.)



Attention Do not generate AF power with the heat radiator disconnected (thermal overload) !

6.4.3.3.5. Control amplifier

- Manual control: GC 5

Generation of U manual control by voltage divider

R 3845, R 1002 ($\approx$) and R 1007

R 1002	→ Mixer 1	→ IF amplification A/B
	$U_{R1} \approx 14.5 \text{ V} \approx$	$U_{R2} \approx 0.75 \text{ V} \approx$
	$U_{R1} \approx 9.5 \text{ V} \approx$	$U_{R2} \approx 0.3 \text{ V} \approx$

- Automatic control: GC 1, GC 2

At P 3801 → $\perp$: $U \approx 100 \text{ mV}/200 \text{ kHz}$

At IF output (27): $\approx 100 \text{ mV}$ (without load)

U at V 3821_B = approx. 45 mV $\approx$ (adjustable with R 3801)

Control detector/A : U at V 3824_B > +4 V

	Trigger (not driven)	Trigger (driven)
Trigger V 3826 _C	$\approx 0.55 \text{ V} \approx$	>17 V $\approx$
Holding circuit V 3827 _C	approx. 1,25 V $\approx$	approx. 0.25 V $\approx$
Long-time detector V 3828 _B	approx. 0.66 V $\approx$	0

$U_{C 3808} = 3 \dots 4 \text{ V}$

Short-time detector $U_{R3829/R3830} = 3 \dots 4 \text{ V} \approx$

Amplifier V 3829_B , $= 13 \dots 14 \text{ V} \approx$

Amplifier V 3830_C $= 12 \dots 13 \text{ V} \approx$

Voltage of slider R 29 = $U_{C 3808} - 0.6 \text{ V}$

6.5. PLL demodulator 1340.041-01258

6.5.1. Check 'input signal' (X 2801/A, B1 or X 0002)

Receiver setting: ☐ F 0.00 kHz

☐ B 6

☐ MOD 7, 8 or 9

☐ GC 5

Adjust input voltage with control " $\nabla \approx$ " to 0.8 V.

Measure input frequency at MOD 7, 8 and 9

Setpoint value: 1905 Hz $\pm$ 1 Hz

6.5.2. Check 'input band-pass' (N 2801)

(P 12 serves as earth reference for all measurements on this pc board.)

Measure 3-dB decrease at P 01 with $\Delta F = 0.10$ kHz

Pass range approx. 1.1 kHz to 2.7 kHz

Slope steepness approx. 12 dB/oct.

Operating residual attenuation 1.5 dB to 2 dB

6.5.3. Check 'limiter amplifier' (N 2802, V 2804, V 2805)

U_{P02} : approx. V_{rms} at $U_e = 500$ mV to 2.5 V

(adjust with control " $\nabla \approx$ ")

U_{P03} : approx. 0.8 V_{pp}

6.5.4. Check 'PLL' (N 2803, N 2804, D 2801, V 2806 ... V 2816)

Measure PLL zero position and VCO frequency with the signal path blocked (☐ B 9).

Rebalancing: PLL zero position with R 2826 (0 V $\pm$ 5 mV at P04)

VCO frequency with R 2842 (1905 Hz $\pm$ 2 Hz at P05)

(Forced changeover with IF bandwidth ☐ B)

100-Bd low pass: at ☐ B 1, 2, 3 (f_g approx. 150 Hz)

600-Bd low pass: at ☐ B 4, 5, 6 (f_g approx. 900 Hz)

Offset correction : for 100-Bd low pass with R2867 at P 09
for 600-Bd low pass with R2876 and R2883
at P 08 and P 09

6.5.6. Check 'amplifier' (N 2810)

Measure V = approx. 40 with low Δf (e.g. 80 Hz)

Offset correction with R 2891.

6.5.7. Check 'evaluator circuit' (N 2811)

At centre frequency (1905 Hz)

: $U_{P11} = 0 \text{ V} \pm 15 \text{ mV}$

At centre frequency $+\Delta f = 500 \text{ Hz}$

: $U_{P11} = +1 \text{ V} \pm 50 \text{ mV}$

At centre frequency $-\Delta f = 500 \text{ Hz}$

: $U_{P11} = -1 \text{ V} \pm 50 \text{ mV}$

In case of exceeding U_{P11} values

: balance with R 2892

In case of too low U_{P11} values

: balance with R 2897

6.5.8. Check 'Line current for teleprinter'

Connect ammeter with 200 ohm (load resistance) in series
to teleprinter terminal (X 0008, 3 and 4).

At ☐ MOD 1 ... 7 : 40 mA $\pm$ 5 mA (correction with R 28106)

6.5.9. Check 'holding and capture range of PLL'

Receiver setting:

☐ F 0.00 kHz

☐ dF 0.01 kHz

☐ MOD 8 and 9

☐ B 6

☐ GC 1

Changeover switch 'LED row' (2) $\rightarrow$ ' $\Delta f \times 2$ '

Holding range: Setpoint value: $\Delta f \approx \pm 900$ Hz referred to centre frequency

Increase frequency with rotary button " $\approx$ " until luminous point of the LED row jumps from row end to row centre.

Capture range: Setpoint value: $\Delta f \approx \pm 800$ Hz referred to centre frequency

Detune frequency of Δf values 2.00 kHz towards 0.00 kHz by means of rotary button " $\approx$ ".

accomplish this function check at MOD 8 and MOD 9.

check simultaneously the synchronization process through monitoring tone.

SERVICE-UNTERLAGE

EMPFÄNGER - TYPREIHE

EKD 500

EKD 511	TYP 1340.42 A1
EKD 512	TYP 1340.42 A2
EKD 514	TYP 1340.42 A4
EKD 515	TYP 1340.42 A5

BAND 2

Hierzu gehört:

SERVICE-UNTERLAGE 1340.042-91700 SU Band 1

Änderungen in Konstruktion und Ausführung, die der technischen Verbesserung und Weiterentwicklung unserer Erzeugnisse dienen, behalten wir uns vor.

Bestellnummer : 1340.042-91700 SU Band 2
Ausgabe 2/1987

665 BkG 011/00762/88



VEB FUNKWERK KÖPENICK

BETRIEB DES VEB KOMBINAT NACHRICHTENELEKTRONIK

DDR · 1170 Berlin, Wendenschloßstr. 142-174

INHALTSVERZEICHNIS

		Seite
EMPFANGER EKD 500	1340.042-00001 Fp	5
EINSCHUB	1340.041-10004 Sp Bl.1	6
	1340.041-10004 Sp Bl.2	7
BAUGRUPPENÜBERSICHT	1340.042-00001 ü	8
GEHÄUSE , VOLLSTÄNDIG	1340.042-01001 Sp	9
GLEICHSTROMWEICHE	1340.042-01022	
STROMVERSORGUNGSTEIL	1340.039.01500 Sp	10
SCHALTREGLER , VOLLSTÄNDIG	1340.039-01552	12
TRANSVERTER	1340.039-01551	
BEDIENEINHEIT	1340.041-01401 Sp	13
STEUERRECHNER	1340.041-01454 Sp	14
	1340.041-01454	15
EIN - AUSGABELOGIK	1340.041-01453 Sp	16
	1340.041-01453	17
TASTATUR , VOLLSTÄNDIG	1340.041-01402 Sp	18
DREHIMPULSGEBER	1340.041-01431 Sp	
TASTATUR , VOLLSTÄNDIG	1340.041-01402	19
ANZEIGE	1340.041-01456 Sp	20
	1340.041-01456	21
STELLSPEICHER	1340.041-01455 Sp Bl.1	22
	1340.041-01455 Sp Bl.2	23
	1340.041-01455	24
	1340.041-01455	25
FREQUENZAUFBEREITUNG 1	1340.041-01211 Sp	27
OSZILLATOR 1	1340.037-01251 Sp	28
	1340.037-01251	29
FREQUENZTEILER 1	1340.037-01252 Sp	30
	1340.037-01252	31
OSZILLATOR 3	1340.039-01253 Sp	32
	1340.039-01253	33

FREQUENZAUFBEREITUNG 2 und F1-DEMULATOR	1340.041-01221 Sp	35
OSZILLATOR 2	1340.037-01255 Sp 1340.037-01255	36 37
FREQUENZTEILER 2	1340.037-01256 Sp 1340.037-01256	38 39
REFERENZFREQUENZ	1340.037-01254 Sp 1340.037-01254	40 41
SIGNALWEG 1	1340.041-01311 Sp	43
VORSELEKTOR 1	1340.037-01351 Sp 1340.037-01351	44 45
VORSELEKTOR 2	1340.041-01352 Sp 1340.041-01352	46 47
MISCHER 1	1340.041-01353 Sp 1340.041-01353	48 49
MISCHER 2	1340.041-01354 Sp 1340.041-01354	50 51
SIGNALWEG 2	1340.041-01321 Sp 1340.041-01322 Sp	52 53
TRAGERSZILLATOR	1340.037-01355 Sp 1340.037-01355	54 55
ZF 2 / B	1340.041-01356 Sp 1340.041-01356 / 01366	56 57
ZF 2 / A	1340.041-01357 Sp 1340.041-01357 / 01367	58 59
ZF 2 / B	1340.041-01366 Sp	60
ZF 2 / A	1340.041-01367 Sp	61
DEMULATOR und NF-TEIL	1340.039-01358 Sp 1340.039-01358	62 63
F1-DEMULATOR	1340.041-01258 Sp 1340.041-01258	64 65
200 kHz / 1.7 kHz - UMSETZER	1340.041-01257 Sp 1340.041-01257	66 67







Gehäuse, vollst.
1340.042-01001

Frequenzteiler 2

Oszillator 2

Referenzfrequenz

F1 - Demodulator




X18

Stromversorgung 1340.039-01500

- E - Teile enthalten in Aufbau
- Osteil, mont.
- Montageplatte, vorm. - 01024 ST
- Kassetteneinbaueinheit - 01011 ST
- Frontplatte, vollst. - 01031 ST

EINSCHUB
1340.041-10004 Sp B1.1

nur im EKD 514 / 515 enthalten



- ① HF-Kabel 1340.041 - 01120 (4)
- ② HF-Kabel 1340.041 - 01121 (4)
- ③ HF-Kabel 1340.041 - 01122 (4)

EINSCHUB
1340.041-10004 Sp Bl.2

Gleichstrommelche
1340.042-01022

00

Gehäuse, vollst. 1340.042-01001

Frequenzaufbereitung 2

schwarz

1340.041-01221 20

Frequenzaufbereitung 1

rot

1340.041-01211 1) 2) 3) 4) 5) 20

Signalweg 1

gelb


1340.041-01311 1) 4) 2) 5) 30

Signalweg 2

grün

1340.041-01321 1) 4) 2) 5) 30

BAUGRUPPENÜBERSICHT 1340.042-00001 ü





1) EXD 511 : 1340.042-10001

2) EXD 512 : 1340.042-10002


4) EXD 514 : 1340.042-10004

5) EXD 515 : 1340.042-10005







STROMVERSORUNGSTEIL
1340.039.01500 Sp




SCHALTREGLER , VOLLSTÄNDIG
1340.039-01552





TRANSVERTER
1340.039-01551







STEUERRECHNER
1340.041-01454 Sp




Ein - Ausgabelogik




EIN - AUSGABELOGIK 1340.041-01453 Sp



1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100
 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134 135 136 137 138 139 140 141 142 143 144 145 146 147 148 149 150 151 152 153 154 155 156 157 158 159 160 161 162 163 164 165 166 167 168 169 170 171 172 173 174 175 176 177 178 179 180 181 182 183 184 185 186 187 188 189 190 191 192 193 194 195 196 197 198 199 200
 201 202 203 204 205 206 207 208 209 210 211 212 213 214 215 216 217 218 219 220 221 222 223 224 225 226 227 228 229 230 231 232 233 234 235 236 237 238 239 240 241 242 243 244 245 246 247 248 249 250 251 252 253 254 255 256 257 258 259 260 261 262 263 264 265 266 267 268 269 270 271 272 273 274 275 276 277 278 279 280 281 282 283 284 285 286 287 288 289 290 291 292 293 294 295 296 297 298 299 300
 301 302 303 304 305 306 307 308 309 310 311 312 313 314 315 316 317 318 319 320 321 322 323 324 325 326 327 328 329 330 331 332 333 334 335 336 337 338 339 340 341 342 343 344 345 346 347 348 349 350 351 352 353 354 355 356 357 358 359 360 361 362 363 364 365 366 367 368 369 370 371 372 373 374 375 376 377 378 379 380 381 382 383 384 385 386 387 388 389 390 391 392 393 394 395 396 397 398 399 400
 401 402 403 404 405 406 407 408 409 410 411 412 413 414 415 416 417 418 419 420 421 422 423 424 425 426 427 428 429 430 431 432 433 434 435 436 437 438 439 440 441 442 443 444 445 446 447 448 449 450 451 452 453 454 455 456 457 458 459 460 461 462 463 464 465 466 467 468 469 470 471 472 473 474 475 476 477 478 479 480 481 482 483 484 485 486 487 488 489 490 491 492 493 494 495 496 497 498 499 500
 501 502 503 504 505 506 507 508 509 510 511 512 513 514 515 516 517 518 519 520 521 522 523 524 525 526 527 528 529 530 531 532 533 534 535 536 537 538 539 540 541 542 543 544 545 546 547 548 549 550 551 552 553 554 555 556 557 558 559 560 561 562 563 564 565 566 567 568 569 570 571 572 573 574 575 576 577 578 579 580 581 582 583 584 585 586 587 588 589 590 591 592 593 594 595 596 597 598 599 600
 601 602 603 604 605 606 607 608 609 610 611 612 613 614 615 616 617 618 619 620 621 622 623 624 625 626 627 628 629 630 631 632 633 634 635 636 637 638 639 640 641 642 643 644 645 646 647 648 649 650 651 652 653 654 655 656 657 658 659 660 661 662 663 664 665 666 667 668 669 670 671 672 673 674 675 676 677 678 679 680 681 682 683 684 685 686 687 688 689 690 691 692 693 694 695 696 697 698 699 700
 701 702 703 704 705 706 707 708 709 710 711 712 713 714 715 716 717 718 719 720 721 722 723 724 725 726 727 728 729 730 731 732 733 734 735 736 737 738 739 740 741 742 743 744 745 746 747 748 749 750 751 752 753 754 755 756 757 758 759 760 761 762 763 764 765 766 767 768 769 770 771 772 773 774 775 776 777 778 779 780 781 782 783 784 785 786 787 788 789 790 791 792 793 794 795 796 797 798 799 800
 801 802 803 804 805 806 807 808 809 810 811 812 813 814 815 816 817 818 819 820 821 822 823 824 825 826 827 828 829 830 831 832 833 834 835 836 837 838 839 840 841 842 843 844 845 846 847 848 849 850 851 852 853 854 855 856 857 858 859 860 861 862 863 864 865 866 867 868 869 870 871 872 873 874 875 876 877 878 879 880 881 882 883 884 885 886 887 888 889 890 891 892 893 894 895 896 897 898 899 900
 901 902 903 904 905 906 907 908 909 910 911 912 913 914 915 916 917 918 919 920 921 922 923 924 925 926 927 928 929 930 931 932 933 934 935 936 937 938 939 940 941 942 943 944 945 946 947 948 949 950 951 952 953 954 955 956 957 958 959 960 961 962 963 964 965 966 967 968 969 970 971 972 973 974 975 976 977 978 979 980 981 982 983 984 985 986 987 988 989 990 991 992 993 994 995 996 997 998 999 1000



EIN - AUSGABELOGIK
 1340.041-01453



Anordnung der Bauelemente nach PWS W 170.023 Seite 51


55 wa gefertigt nach APA

Maßzahl in () gilt nicht für die Bearbeitung


*) Wertweise Bestückung


① Bei Einsatz von D492

② Bei Einsatz der Ausweich BE




STELLSPEICHER
1340.041-01455





FREQUENZAUFBEREITUNG 1
1340.041-01211 Sp



OSZILLATOR 1
1340.037-01251 Sp

V20u V22E1V-

Bereich

1	2	
+0,5	-12	V20/C
-11,5	0	V21/C
-12	+0,5	V22/C
0	-11,5	V23/C
-8...9	0	C45
0	-8...9	C47

US1

Bereich	Richtwert
1	2,7...10 V-
2	2,9...14 V-

16...17 V-

Bereich

a	b	
+0,5	+16,5	V13/C
-16	-12	V19/C

1340.037-01251-05¹

f1 = 70,2 ... 100,2 MHz

Uf1 = 80 ... 100 mV an 50 Ω

Uf1 = 50 ... 100 mV

Uf1 = 7...10 V


50 kHz

(Ret.)


10

note Leistung

u/v



OSZILLATOR 1
1340.037-01251




Technical drawing of a rectangular block. The left side shows a cross-section with a hatched base of height 15 and a total height of 30. The right side shows a side view with a hatched base of height 7 and a total height of 20. A table is located to the right of the drawing.


8	1	3	5	7
8	1	3	5	7

mit der Kon.


-30-




FREQUENZTEILER 1
1340.037-01252




OSZILLATOR 3
1340.039-01253 Sp





FREQUENZAUFBEREITUNG 2 und F1-DEMODULATOR
1340.041-01221 Sp




Kennnummer der Bauelemente
C 250T ± C 01


X01
auf die Kontakte gesehen


- EL 000 D; o. E100 C, D;
MH 8400
EL 074 D; o. E74 C, D;
MH 8474
E 121 D, C; o. SW 84121 N
B 109 D, C
- MAA 723
KP 3074
D
B
E
KT 326 B o. KT 326 BM
- SC236C
55219C, 5F235
EBC
- MB 105 B
SAV 12
AK
- Q 0.25 W
Q 0.3 W; 0.33 W;

OSZILLATOR 2
1340.037-01255 Sp




OSZILLATOR 2
1340.037-01255





FREQUENZTEILER 2
 1340.037-01256



Ausgang 10 MHz
Eingang 10/5/1 MHz
± 250 mV

Kennummer der Bauelemente
C 2401 & C 01

0,25 W
0,3 W



auf die Kontakte gesehen

MH 8490 o. UCA 8480n
E 110 D o. E 110 C
EL 080 D




SS218C

TCXO Typ +
10,0 MHz


Ansicht von unten

REFERENZFREQUENZ
1340.037-01254 Sp





REFERENZFREQUENZ
1340.037-01254

Gilt auch für Signalweg 1
1340.041-01312




SIGNALWEG 1
1340.041-01311 Sp

VORSELEKTOR 1 1340.037-01351 Sp



	1	2	3	
III	1,5 ... 3	1,5 ... 2,5	3 ... 3	MHz
IV	3 ... 6	3 ... 4	5 ... 6	MHz
V	6 ... 12	6 ... 8	10 ... 12	MHz
VI	12 ... 24	12 ... 16	20 ... 24	MHz

*) Abgleichstellung



VORSELEKTOR 1
1340.037-01351

Y-Signal (Antenne)

Abgleich-TP
= 30 MHz

Abgleich-TP
= 15 MHz (II)

Abgleich-HP
= 15 MHz (III)

zum Mischen 1
(14 kHz bis 30 MHz)
(Bereich I bis VII)


Bereich „Ein“: $\leq 1V$
Bereich „Aus“: $\approx 10V$

(P02)



zum Vorselektor 1
(15 bis 24 MHz)
(II bis VI)

Abgleich-HP
= 24 MHz (VIII) Ansicht 2

zum Vorselektor 2
(III bis VI)




VORSELEKTOR 2
1340.041-01352

[illegible]

1) 2) 3) 2) $\times$ SF 235 paarig,
 ΔT_c bei I_{0g} konst. $\leq 10\%$
 U_{FE} 45V, $I_c \sim 5mA$











4) Abgleichwert

MISCHER 1
1340.041-01353 Sp




MISCHER 1
1340.041-01353

Vom 2.3001 (70.2 MHz - Quarzfilter)



MISCHER 2 1340.041-01354 Sp

- 1) 2x SF 235 paargl.
 ΔZ_c bei S_{AE} Konst. $\leq 10\%$
 $U_{CE} 4.5V, I_c \sim 5mA$
- 2) Abgleichwert
 $\beta 40 \dots 120$
- 3) Finch-Off-Spannung $\sim 0.8 \dots 1.3V$ bei $I_D 100\mu A$ und $U_{DS} 10V$
- 4) Kenn-Nr. der Bauelemente
C 3401 = C01



Vom Stellselektor
Vorselektor-
(Grauer Bereich)

Abgleich
Verstärkung




Einstellen
Regelumfang

frei von Lötückständen
und Flussmittelresten
kontaktblank

Abgleich $Z_0 = 45 \dots 50 \Omega$

$U_{\text{ref}} = 0 \dots 1V$

18V





DREHIMPULSGEBER
1340.041-01431 Sp


MISCHER 2
1340.041-01354

INTERFACE „VORSELEKTORSTEUERUNG“

		Eingangs-Signal TTL-Pegel					Ausgangs-Signal ($< 1/18V$)										Bereich (Hz)	
+18V	X011	A2	A3	A4	A5	A6	B2	B3	B4	B5	B6	B7	B8	B9	B11	B12		
prob	I	0	0	1	-	-	<1	18	18	18	18	18	18	18	-	-	<15	
	II	0	1	0	-	-	18	<1	18	18	18	18	18	18	-	-	15 ... 30	
	III	0	1	1	-	-	18	18	<1	18	18	18	18	<1	-	-	15 ... 30	
	IV	1	0	0	-	-	18	18	18	<1	18	18	18	<1	-	-	3 ... 6	
	V	1	0	1	-	-	18	18	18	18	<1	18	18	<1	-	-	6 ... 12	
	VI	1	1	0	-	-	18	18	18	18	18	<1	18	<1	-	-	12 ... 24	
	VII	1	1	1	-	-	18	18	18	18	18	18	<1	18	-	-	≥ 24	
freq	1	-	-	-	1	0	-	-	-	-	-	-	-	-	<1	18	II 1 15 ...	
		-	-	-	-	-	-	-	-	-	-	-	-	-	-	II 1 6 ...		
		-	-	-	-	-	-	-	-	-	-	-	-	-	-	II 1 12 ...		
		-	-	-	-	-	-	-	-	-	-	-	-	-	-	II 2 2 ...		
	2	-	-	-	0	1	-	-	-	-	-	-	-	-	-	<1	18	II 2 6 ...
		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	II 2 3 ...	
		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	II 2 12 ...	
		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	II 2 6 ...	
	3	-	-	-	1	1	-	-	-	-	-	-	-	-	-	18	18	II 3 25 ...
		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	II 3 5 ...
		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	II 3 10 ...
		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	II 3 20 ...







TRÄGEROSZILLATOR
1340.037-01355 Sp

3,5 V =, R3E $U_E = 50 \text{ mV} \approx$
 13,5 V =, R3E $U_E = 200 \text{ mV} \approx$

3
 200.000 kHz, $\approx 7,5 \text{ V}$ - schwankend -
 15,5 V =, R3E $U_E = 50 \text{ mV} \approx$
 R3E 5 V =, R3E $U_E = 200 \text{ mV} \approx$
 200.000 kHz, $\approx 4 \text{ V}$ - schwankend -
 $f = 1,905 \text{ kHz}$
 3,5 Vss

3,5 Vss
 4,2 V =, R3E $U_E = 50 \text{ mV} \approx$
 2,2 V =, R3E $U_E = 200 \text{ mV} \approx$
 Minimumabgleich der
 Welligkeit für 198,095 kHz

3 Vss

1,3 V =

12 mV $\approx$

12,2 V =

R3E, 200.000 kHz
 (6 bis 7) V =
 schwankend

200 mV $\approx$

11,6 V =

$\approx 3 \text{ mV} \approx$

4,5 V =, F

$U_E = (50 \text{ bis } 250) \text{ mV} \approx$
 $f_E = 200 \text{ kHz} \pm \Delta f_E$

$U_E = 200 \text{ mV} \approx$
 $f_E = 200.000 \text{ kHz}$

200 mV $\approx$; F 0 bis 9,5 V =, A1A

$\approx 7,5 \text{ V} =$; R3E 200.000 kHz
 MOS-FET!

$\approx 13,8$; R3E 200.000 kHz

2,7 V =, F

4 (V27-V29)
 400 mV $\approx$; F

13,2 V =, F

13,5 V =, F

8,5 V =

Abgleich des Ziehberereiches
 des Quarzoszillator bei A1A
 (< 198,8 bis > 199,5) kHz

Maximumabgleich
 198,095 kHz Ausgangs-
 spannung

Maximumabgleich
 201,905 kHz Ausgangs-
 spannung

5,0 V =, A1A
 100 mV $\approx$, A1A

Minimumabgleich der
 Welligkeit für 201,905 kHz

6 V =

10 mV $\approx$; A1A

10 mV $\approx$; F

9,0 V =, R3E
 6,3 V =, A1A

Maximumabgleich
 für Ausgangsspannung
 A1A oder F $\text{---} F \text{---}$


$U_A = (80 \text{ bis } 170) \text{ mV}$ an 680 Ω
 $f_A \approx f_{U3}$

TRÄGERSZILLATOR 1340.037-01355

U1 5547 5547 -

U2 5547 5547 -

U3 5547 5547 -



0000-01

0000-01


0000-01

0000-01

0000-01


0000-01

0000-01



-58-


Bezeichnung: 01367




- 01357


ZF 2 / A
1340.041-01357 / 01367

gilt auch für
1340.041-01367




Pin	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
V01	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
V02	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
V03	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
V04	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
V05	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
V06	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
V07	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
V08	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
V09	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
V10	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15







-61-



DEMODULATOR und NF-TEIL
1340.039-01358 Sp




(16) Auf die Kontakte gesehen



(17) Ansicht von oben

(18) Ansicht von unten



(15)

(16)


(17)

(18)


(19)

(20)


(21)





F1-DEMODULATOR
1340.041-01258 Sp



F1-DEMODULATOR
1340.041-0125B





200 kHz / 1.7 kHz - UMSETZER
1340.041-01257

contained in tables, diagrams and figures of Receiver BKD 500

Order-No. of this list: 1340,042-01702 U1 (4)

Abgleich des Ziehbereiches	balancing of the pull-in range
Abgleich des Ziehbereiches des Quarzoszillators bei ...	balancing the pull-in range of the crystal oscillator with ...
Abgleichstellung	balancing position
Abgleichselemente	balancing elements
Abgleich, Abgleichwert	balancing, balancing value
Abhörverstärker	monitoring amplifier
Abschirmung	screening
Adressen-Dekoder	address decoder
Analysenoszillator	analysis oscillator
Ändern	change
Angriffspunkt für den Ziehler	point of application for extractor
Anschlußadapter	connection adapter
Ansicht von unten	view from below
Antenne oder Antennenverteiler	aerial or aerial distributor
Anzeige	display
Arbeitsweise des Phasendiskriminators	function of the phase discriminator
Aufbau	construction/assembly
auf die Anschlüsse gesehen	view of connections
auf die Kontakte gesehen	view of contacts
Ausgangsspannung	output voltage
Ausgangssignal	output signal
Ausgangsfrequenz im synchronisierten Zustand	output frequency in synchronized condition
Ausgangstreiber	output driver
Ausgangsverstärker	output amplifier
Auswerterschaltung	evaluator circuit
Bandbreite	bandwidth
Basisstrom gemessen über	base current measured via
Batteriebetrieb	battery operation
Batteriekabel	battery cable
Baugruppenübersicht	subassembly survey
Bedieneinheit	control unit

Befestigung für Bedieneinheit	fastening device for control unit
Befestigung für Frontplatte	fastening device for front panel
Begrenzer	limiter
bei falschen Pegeln werden die entsprechenden Leiterplatten geprüft	in case of wrong levels the corresponding pc boards are checked
Beispiel	example
Belastung	load
Bereich	range
Bereich 1 einschalten	switch on range 1
Bestückungsseite	complementation side
Betriebsspg.	operating voltage
Blockschaltbild PLL 1	block diagram PLL 1
Brücke(n)	bridge(s)
Coder	coder
Codierung der Steckverbindung "8-5"	coding of plug connection "8-5"
Dateneingänge	data inputs
Demodulator u. NF-Teil	demodulator and AF section
Diese Zeichnung besteht aus	this drawing consists of
Detektor, Langzeit-, Kurzzeit-	detector, long-term-, short-term-
Diodenplatte	diode board
Drehimpulsgeber	angular momentum generator
Ein- Ausgabe-Logik	input-output logic
Einfachstrom, Standleitungsbetrieb, 4 Draht-Anschluß	single current, point-to-point operation, 4-wire connection
Eingangspañ	input band filter
Eingangsfrequenz	input frequency
Eingangssignal	input signal
Eingangsschutz	input protection
Einschub	plug-in
Einstellbare Frequenzteilung	adjustable frequency division

Eingangsfrequenz ... Teil ... input frequency

Ausgangsfrequenz ...
im synchronisierten Zustand
von PLL 1 ... output frequency
in synchronized condition
of PLL 1

Teilerfaktor ... divider factor

Zählstart ... Ziffernwahl ... count start ... digit selection

Zählung ... rückwärts ... counting ... down

... set/adjust

... lungen (Sollwert) ... settings (setpoint value)

... reception

... ger EKD 500 ... receiver EKD 500

... sperre ... receive blocking

... steil ... receiving section

... ten in ... contained in

... richtung - Quarzfilter: ... direction of insertion - crystal
... akt = Mischer 1-Seite ... filter: colour point = side of mixer

... earth connection

... schraube ... earthing screw (side wall of casing)

... ungseinrichtungen ... supplementary devices

: - Frequenz falsch

wrong: - wrong frequency

- bei falschen Pegeln
werden die entsprechen-
den Leiterplatten
geprüft

- in case of wrong levels the
corresponding pc boards are
checked

- kein Ausgangsimpuls
f2/100

- no output pulse f2/100

- PLL 2 synchronisiert
nicht

- PLL 2 does not synchronize

- PLL 2 synchronisiert
aber Frequenz ist
falsch

- PLL 2 synchronizes but wrong
frequency

F₀ (FH)

capture aid

... deschlauchleitung

telecom plastic sheathed cable

... reiber

teleprinter

instantaneous

... on Lötückständen und
... telresten

free of soldering and flux
residuals

... z falsch

wrong frequency

... zabgleich ... frequency balancing

... zaufbereitung (FA)-

frequency processing survey

... ht

Frequenzeinstellung	frequency setting
Frequenzteiler	frequency divider
Frontplatte, vollst.	front plate, complete
für aktive Antenne	for active aerial
Für jede Taste kann der Code ...	code can be generated for each key if EXT FCT is pressed simultaneously
Gehäuse, vollst.	casing, complete
gesiebt	filtered
Gestell, mont.	rack, mounted
Gilt auch für Signalweg 1	also applicable for signal path 1
Gleichstromweiche (gedr. Schaltung)	dc filter (pc)
Haltekreis	holding circuit
HF-Generator	RF generator
HF-Kabel	RF cable
Hochpaß (HP)	high-pass
Hub	deviation
Impulsdiagramme für 2 Beispiele	pulse diagrams for 2 examples
- Ausgangssignal	- output signal
- Rücksetzsignal	- reset signal
- Eingangssignal	- input signal
Impulsschema des Frequenzdiskriminators	pulse scheme of the discriminator
Schaltfolge hervorgerufen durch Zeitverzögerung der Gatter	switching sequence caused by time delay of the gates
Kassettenaufnahme	cassette reception
Kassettenbefestigung	cassette fastening
Kassettendeckel (innere)	cassette lids (inner)
kein Ausgangsimpuls f2/100	no output pulse f2/100
Kenn-Nr. der Bauelemente	code No. of components
Kennzeichnung Farbpunkt "Ein"	marking/colour point "ON"
Klemmbrett	terminal board
Koder	coder
Koder für Oszillator 1-Bereiche	coder for oscillator 1 ranges
kontaktblank	bare contact
Kontrolle	test/check
Korrektur	correction
Kurzzeitdetektor	short-time detector

1. unter Eigentum
 2. Mängelung
 3. wird erfolgt

Lage der Meßpunkte	position of measuring points
LED Zeile 13stellig	LED row 13-digit
Leitungsseite	conductor side
Leitung	line
Leitungsverstärker	line amplifier
Linearisierung "E" - Anzeige	linearization "E" display
Maximumabgleich für Ausgangs- spannung ...	max. balancing for output voltage ...
Meßgröße	measuring/test value
Minimalabgleich der Welligkeit für ...	min. balancing of ripple for...
Mischer	mixer
Montageplatte, vorm.	assembly board, premounted
Netzanschluß	mains connection
Netzbetrieb	mains operation
Netzspannung	mains voltage
HF-Ausg.	AF output
HF-Leitungsausgang	AF line output
HF-Tiefpaß	AF low-pass
Mullage	zero position
offen	open
Offsetabgleich	offset balancing
Oszillator	oscillator
Oszillator defekt	oscillator faulty
paarig	in pairs
Pegelkontrolle	level check
Pegel, Pegelung	level, levelling
Pegelkorrektur	level correction
Periphere Geräte	peripheral units
Phasendetektor	phase detector
Phasendiskriminator	phase discriminator
Programm für die Fehlersuche	program for troubleshooting
Prüfe	check/test
PLL 2 synchronisiert nicht	PLL 2 does not synchronize
PLL 2 synchronisiert aber Frequenz ist falsch	PLL 2 synchronizes but wrong frequency

Prüfe und repariere	check and repair
- Koder	- coder
- Verstärker u. Mischer	- amplifier and mixer
- Verstärker	- amplifier
- Rücksetzeinheit	- reset unit
- Zähler	- counter
- Frequenzeinstellung	- frequency setting
- Einstellbare Frequenz-	- adjustable frequency division
teilung	
- Schalter u. Ver-	- switch and wiring
drahtung	
- 100:1 Teiler	- 100:1 divider
- 4:1 Teilung	- 4:1 division
Prüfprogramm Frequenzteiler 1/2	test program/frequency divider 1/2
Prüfprogramm Oszillator 3	test program/oscillator 3
- Oszillator 3 defekt	- oscillator 3 faulty
- hängt auf Spiegelwelle	- on image wave
- synchronisiert von...	- synchronized by ...
- prüfe Mischer	- test mixer
- prüfe 90°-Versatz	- test 90° offset at ...
an ...	
- prüfe Phasenvergleich	- test phase comparison
Prüfprogramm PLL 1	test program PLL 1
Prüfpunkt	test point
Prüfung des einstellbaren	test of the adjustable frequency
Frequenzteilers 1	divider 1
Referenzfrequenz	reference frequency
Regeleinsatz	control start
Regelgleichlauf A und B	sync control A and B
Regelspannung,	control voltage, control voltage
Regelspannungserzeuger	generator
Regelspannungs-Detektor	control voltage detector
Regelsteilheit	control slope
Regelumfang	control volume
Richtwert	setpoint value
Ruhestrom	rest current
Rücksetzeinheit	reset unit
Rücksetzsignal	reset signal
Rückwand, mont.	rear wall, mounted

Schaltfolge hervorgerufen durch Zeitverzögerung der Gatter	switching sequence caused by time delay of the gates
Schreibmaschine	teleprinter
Schalter	switch
S-Meter	S meter
Segmentanzeige	segment display
Selektion	selection
Selektionskurven "Vorselektor 2"	selection characteristics 'pre-selector 2'
Sendert	class of emission
Sendeteil	transmitting section
Signalweg (SW)	signal path
Spannungseinstellung	voltage adjustment
Speicher	store/memory
Spule	coil
synchronisiert nicht	does not synchronize
synchronisiert von	synchronized from
synchronisierter Zustand	synchronized condition
synchronisiert PLL 1 am Anfang und Ende des Bereiches	synchronizes PLL 1 at beginning and end of the range
Standleistungsbetrieb	point-to-point operation
Steckerplatte, vollst.	plug board, complete
Stellspeicher	register and interface
Stellspeichermatrix	register and interface matrix
Steuerbefehl	control instruction
Steuerrechner	control computer
Stromversorgungsteil (Seitenansicht)	power supply section (side view)
Schalter in Stellung " "	switch in position " "
Schaltregler, vollst.	switching controller, complete
Schwankend	fluctuating, varying
Tabelle	table
Takt	clock
Tastatur, vollst.	keyboard, complete
Tastencode	key code
Tastenfeld, bei Tastendruck	keyboard, with key depression
Taststufe	key stage
Teiler	divider
Teilerfaktor	divider factor

Test	test
Tiefpaß (TP)	low-pass
Transistorplatte	transistor board
Transverter, Transverterbetrieb	transverter, transverter operation
Trägeroszillator	carrier oscillator
Trägersynchronisation	carrier synchronization
Trägerverstärker	carrier amplifier
Treiber	driver
Trennverstärker	buffer amplifier
Triggereinstellung, Trigger	trigger setting, trigger
Trimmwert	trimming value
Umschalter LED-Zeile	changeover switch LED row
Umschaltung	changeover
Überlagerte Brummspannung	superposed hum voltage
verbunden	connected
Verdrahtung	wiring
Vereinfachter Übersichtsplan- Frequenzen u. Pegel von Referenz- frequenz	simplified general diagram - frequencies and levels of the reference frequency
Verstärker	amplifier
90° - Versatz	90° offset
Verstärkung	amplification
Verstärker - Mischer: Arbeits- punkte und HF-Pegel verbunden	amplifier - mixer: working points and RF levels connected
Vorselektor	preselector
Vorselektor-Teilbereiche	preselector subranges
Verzögerung	delay
Zählstart ... Ziffernwahl	counting start ... digital selection
Zählende	counting end
Zähler	counter
Zählung ... rückwärts	counting ... down
Zeitglied für Empfangssperre bei SCAN	tuning element for receive blocking with SCAN
ZF-Ausgang	IF output
ZF-Verstärker	IF amplifier
Ziffern im 8-4-2-1-Code	digits in 8-4-2-1 code
Ziffernwahl im 8-4-2-1-Code zu den Registern	digital selection in 8-4-2-1 code to the registers
Zur V24 - Interface	to the V24 interface